



User Instruction Manual

PUM601X

PUM901X

CONTENTS

- 1) WARNING**
- 2) INSTALLATION INSTRUCTIONS**
- 3) OPERATION**
- 4) LIGHT REPLACEMENT**
- 5) CHARCOAL FILTER INSTALLATION**
- 6) MAINTENANCE**
- 7) ATTENTION**
- 8) TROUBLESHOOTING**


1. WARNING

- Young children should be supervised to ensure that they do not play with the appliance.
- The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervised or instruction concerning use of the appliance by a responsible person for their safety.
- Your cooker hood is for domestic use only, not suitable for barbecue, fast - food shops, and other commercial use.
- Any installation work must be carried out by a qualified electrician or competent person.
- The cooker hood and its filter mesh should be cleaned regularly in order to keep in good working order.
- Before cleaning, always ensure that you have switched your cooker hood off.
- Do not flambé under the range hood.
- Clean the cooker hood according to the instruction manual, and keep the cooker hood away from the danger of flames.
- If there is any fault with your cooker hood, please call the customer service number in the Warranty Card.
- Please keep the room adequately ventilated when your cooker hood and gas hob are working.
- Do not exhaust the gas from cooker hood through the same heated flue which is for the gas from gas hob and other kitchen appliances.
- Before installation and usage, read all the instructions and make sure that the voltage (V) and the frequency (Hz) indicated on your cooker hood are exactly the same as the voltage (V) and the frequency (Hz) in your home.
- To ensure that you get the best Warranty experience for your cooker hood, please provide copies of the Warranty Card and purchase receipt, when booking warranty work with the Customer Service department.


2. INSTALLATION

Preparation



1. The cooker hood should be placed at a distance of 65-75cm (26-30inch) from the cooking surface for the best effect.
2. Drill a hole in the cupboard, 570*265(mm) for model PUM601X and 865*265(mm) for model PUM901X. Make sure the distance between the edge of the hole and the edge of the cupboard edge is at least 35mm.
3. Take off the filter and the two lamps. Remove the two screws on the panel. And then take off the panel.



60cm





90cm




Installation

Method 1


1. Use four ST4*8mm screws to fix the mounting bracket onto the hood. Then put two ST4*30mm screws into the wall. Hang the hood onto the wall.
2. Use ST4*14mm screws to tighten the hood to the cabinet. PUM601X needs ten screws. PUM901X needs twelve screws.






Method 2

1. Use four ST4*8mm screws to fix the mounting bracket onto the hood. Then put two ST4*30mm screws into the wall. Hang the hood onto the wall.
2. Use eight ST4*14mm screws to fix the hood onto the cabinet from the sides.



Method 3


1. Use four ST4*8mm screws to fix the mounting bracket onto the hood. Then put two ST4*30mm screws into the wall. Hang the hood onto the wall.
2. Use four M4*35mm screws, eight washers and four nuts to fix the hood onto the cabinet from the top.



And then connect the ducting pipes to the outlet. Install the lamps and filter back to the hood.


3. OPERATION:

- 1) Push the low button, indicated by a fan with 3 blades, and the motor will run at a low speed. An indicator light will also illuminate. Push it again and the motor will stop.
- 2) Push the medium button, indicated by a fan with 4 blades and the motor will run at a medium speed. An indicator light will also illuminate. Push it again and the motor will stop.
- 3) Push the high button, indicated by a fan with 5 blades and the motor will run at a high speed. An indicator light will also illuminate. Push it again and the motor will stop.
- 4) Push the light button; the indicating light on, and the two lighting lamps will come on. Push it again and the lamps will turn off.




4. LIGHT REPLACEMENT

To change the light, press the lamp cup, take out the bulb counter-clockwise. And then Insert a new lamp.



5. CHARCOAL FILTER INSTALLATION

To remove or install the charcoal filter, twist the charcoal filter in the direction shown below:



6. MAINTENANCE

1. The rangehood and its filter mesh should be cleaned regularly in order to keep in good working order. Because the grease filters are made of metal, do not clean the filters with detergents that will corrode metal products.

Clean the filters as below:


Method one:

Put the filter in water (40°C-50°C), pour in some grease-loosening detergent, soak it for about 2-3 minutes and then clean it with a soft brush. Do not brush too hard, as it may damage the filter.

Method two:

You can also put the filter into the dishwasher with detergent for cleaning. Set the temperature at around 60°C.

2. To protect the main body from corrosion over a long period of time, the rangehood should be cleaned with hot water plus soap or non corrosive detergent once a week. Do not use grinding detergent, or it will damage the body.
3. Keep the motor and other spare parts free from water, as this will cause damage to the appliance.
4. Disassembly and assembly the filter:




7. ATTENTION

- Rangehood uses 220-240V 50Hz power;
- Disconnect the power when you clean the rangehood;
- Do not detach the filter surround
- If the power cord or plug is damaged, contact service centre


PUM601X

Dimensional Drawing



PUM901X

Dimensional Drawing



8. TROUBLESHOOTING

Fault	Cause	Solution
Light on, but motor does not work	The leaf blocked	Get rid of the blocking
	The capacitor damaged	Replace capacitor
	The motor jammed bearing damaged	Replace motor
	The internal with of motor off or a bad smell from the motor	Replace motor
Light does not work, motor does not work	Beside the above mentioned, check the following:	
	Light damaged	Replace lights
	Power cord looses	Connect the wires as per the electric diagram
Oil leakage	One way valve and the air ventilation entrance are not tightly sealed	Take down the one way valve and seal with glue
	Leakage from the connection of U-shaped section and cover	Take U-shaped section down and seal with soap or paint
Shake of the body	The leaf damaged and causes shaking	Replace the leaf
	The motor is not tightly hanged	Lock the motor tightly
	The body is not tightly hanged	Fixed the body tightly
Insufficient suction	The distance between the body and the gas top too long	Readjust the distance
	Too much ventilation from open doors or windows	Choose a new place and resemble the machine
The machine inclines	The fixing screw not tight enough	Tighten the hanging screw and make it horizontal
	The hanging screw not tight enough	Tighten the hanging screw and make it horizontal

Warranty

THIS WARRANTY IS VALID IN AUSTRALIA ONLY

Note:

Please complete the following details when you have unpacked the product and **retain** this card with the purchase invoice or sales docket.

Warranty:

This product is covered by a Warranty in addition to all rights available to you by statute.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

The Warranty is for a period of two years (24 months) from the date of purchase for Parts and Labour, however, Dishwashers will have a 10 Year Parts and Labour Warranty on the Electric Wash Motor.

The Warranty period for Front load washers and dryers will carry a full 5 year warranty and a 10 year parts and labour warranty on the Electric Wash Motor Only.

Refrigeration appliances will have an additional three years (36 months) Warranty, after the initial 24 months, for Parts only on the Sealed System eg; compressor, condenser, evaporator, filter dryer and pipe work, subject to the following conditions;

The conditions mentioned above are;

1. that the purchaser carefully follows all instructions packed with the product;
2. that the purchaser carefully follows the installation instructions provided and complies with the electrical wiring regulations, gas and/or plumbing codes;
3. that the purchaser carefully follows the instructions provided in the owner's handbook relating to the proper use and care of the product and does not use the product for any purpose other than the Domestic, indoor use, for which it has been designed.
4. that the product was purchased and installed in Australia;
5. that this Warranty does not extend to;
 - a) Optional glass lids for hobs apart from claims which relate to mechanical or physical damage thereof at the date of purchase;
 - b) Light globes (with the exception of microwave oven globes);
 - c) Damage to ceramic glass caused by liquid or solid spillovers, lack of maintenance or impact. Please read the booklet explaining about liquids containing **sugar**;
 - d) Damage to the surface coatings caused by cleaning or maintenance using products not recommended by the owners handbook;
 - e) Defects caused by normal wear and tear, accident, negligence, alteration or misuse.
 - f) A product dismantled, repaired or serviced by any serviceperson other than an authorised employee or agent of Smeg Australia Pty Ltd;
 - g) The servicing of Freestanding Microwaves under this Warranty does not cover in home service and is limited to the appliance being taken to the nearest Service Agent.
 - h) The provision of service under this Warranty is limited by the boundary of the nearest agent's area. Travelling cost incurred for service outside this area is not covered by this Warranty and will incur commercial cost to be paid by the customer regulated by the number of kilometres travelled beyond the service area.

For service, please contact your local Smeg Australia Pty Ltd office or dealer/retailer from whom you purchased the product. If you are unable to establish the date of purchase, or if the fault is not covered by this Warranty, or if the product is found to be in working order, you will be required to bear all service call charges.

CONTACTS:

SYDNEY – HEAD OFFICE.....Ph. (02) 86674888 Fax (02) 86674800
QUEENSLAND.....Ph. (07) 32660444 Fax (07) 32667511
NEWCASTLE.....Ph. (02) 49609266 Fax (02) 49609277
CANBERRA (Contact Wagga Wagga).....Ph. (02) 69228600 Fax (02) 69228611
WAGGA WAGGA.....Ph. (02) 69228600 Fax (02) 69228611
VICTORIA.....Ph. (03) 90941999 Fax (03) 90941990
TASMANIA.....Ph. (03) 63348166 Fax (03) 63348177
SOUTH AUSTRALIA.....Ph. (08) 83461888 Fax (08) 83401034
WESTERN AUSTRALIA.....Ph. (08) 93898000 Fax (08) 93898088

DETAILS:

Model No.....
Serial No:
Date of Purchase:
Retailer:
Invoice/Docket No:
Customer Name:
Customer Telephone:
Customer Address:
.....

Smeg Australia Pty Ltd, 2 – 8 Baker Street, Banksmeadow. N.S.W. 2019 (www.smeg.com.au)

ABN No.33 146 901 082. ACN No.146 901 082

