



**Mechanical Services handover documentation**

**The Patterson**

**3-15 Archer St**

**Toowong**

**QLD**

<b>DESCRIPTION</b>
<b>Company Information</b>
<b>Description of the Works</b>
<b>Operation &amp; Maintenance Procedures</b>
<b>Manufacturers Literature</b>
<b>Warranties</b>
<b>Certification</b>
<b>As Built Drawings</b>

**Office:** 2/30 Access Crescent, Coolum Beach, QLD 4573

**Postal:** PO Box 6017, Maroochydore, Qld 4558

**Email:** [admin@portcityairconditioning.com.au](mailto:admin@portcityairconditioning.com.au)

**Phone:** 1300 PORT CITY / 07 4972 3355 **Fax:** 07 4972 1791

**Website:** <http://www.portcitygroup.com.au/>

ABN: 99 717 077 615 / QBCC: 1184073 / ARCTICK: AU12994 / ELEC: 73329



## SECTION 1

### Company Information

Port City Air is pleased to present this handover manual on completion of

**The Patterson**

**3-15 Archer St**

**Toowong**



### **PCA Contact Details:**

**Office:** 2/30 Access Crescent, Coolum Beach, QLD 4573

**Postal:** PO Box 6017, Maroochydore, Qld 4558

**Email:** [admin@portcityairconditioning.com.au](mailto:admin@portcityairconditioning.com.au)

**Phone:** 0754 434 095

**Website:** <http://www.portcityair.com.au>

ABN: 99 717 077 615 / QBCC: 1184073 / ARCTICK: AU12994 / ELEC: 73329

### **Supplier Contact Details:**

Daikin Air Conditioning General Enquiries : 1300 368 300

Fantech Fans : (07) 3299 9888





## SECTION 2

### Description of works

**Supply and Installation of Car Park, Bin store, Fire Pump Room supply and Exhaust air system from B2 to Level 3**

**Supply and installation of Daikin Air Conditioning and Ventilation systems from Wellness Centre, Lobby, Wine Room & all apartments from Level 4 to 15**

**A/C EQUIPMENT SCHEDULE**

REF. NO.	MAKE	MODEL	TYPE	TOTAL COOLING	SENSIBLE COOLING	HEATING CAPACITY	DBWB	S/A	PHASE	PIPE	SOUND	MCA	DIMENSIONS	WEIGHT	NOTE
				Kw		Kw	°C	L/s	ph / V / Hz	mm	dB(A)	A	HxWxD	Kg	
CU-A-L4 TO L8 & L11	DAIKIN	RXYM24A4VA	CONDENSING UNIT	9.8 (-18.8%)	-	12.3	-	-	240V 1ph	9.5x15.9	-	16.5	940*990*320	71	L4 TO L8 & L11
FCU-401.1	DAIKIN	FXDQ63TV13	DUCTED UNIT	5.7	4.7	7.2	27.0 / 19.0	325	220V 1ph	9.5x15.9	33-37	1.8	1100*200*450	24	L4 TO L8 & L11
FCU-401.2	DAIKIN	FXDQ25TV13	DUCTED UNIT	2.3	2.1	2.9	27.0 / 19.0	150	220V 1ph	6.4x12.7	28-33	0.8	700*200*450	18	L4 TO L8 & L11
FCU-401.3	DAIKIN	FXDQ20TV13	DUCTED UNIT	1.8	1.7	2.3	27.0 / 19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700*200*450	18	L4 TO L8 & L11
CU-A-L9	DAIKIN	RXYM24A4VA	CONDENSING UNIT	9.6 (-20.7%)	-	12.3	-	-	240V 1ph	9.5x15.9	-	16.5	940*990*320	71	L9
FCU-901.1	DAIKIN	FXDQ63TV13	DUCTED UNIT	5.6	4.6	7.1	27.0 / 19.0	325	220V 1ph	9.5x15.9	33-37	1.8	1100*200*450	24	L9
FCU-901.2	DAIKIN	FXDQ25TV13	DUCTED UNIT	2.2	2	2.9	27.0 / 19.0	150	220V 1ph	6.4x12.7	28-33	0.8	700*200*450	18	L9
FCU-901.3	DAIKIN	FXDQ20TV13	DUCTED UNIT	1.8	1.7	2.3	27.0 / 19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700*200*450	18	L9
CU-B1-L4 TO L8 & L11	DAIKIN	RXYM24A4VA	CONDENSING UNIT	10 (-17.6%)	-	12.4	-	-	240V 1ph	9.5x15.9	-	16.5	940*990*320	71	L4 TO L8 & L11
FCU-402.1	DAIKIN	FXDQ63TV13	DUCTED UNIT	5.8	4.7	7.2	27.0 / 19.0	325	220V 1ph	9.5x15.9	33-37	1.8	1100*200*450	24	L4 TO L8 & L11
FCU-402.2	DAIKIN	FXDQ25TV13	DUCTED UNIT	2.3	2.1	2.9	27.0 / 19.0	150	220V 1ph	6.4x12.7	28-33	0.8	700*200*450	18	L4 TO L8 & L11
FCU-402.3	DAIKIN	FXDQ20TV13	DUCTED UNIT	1.9	1.7	2.3	27.0 / 19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700*200*450	18	L4 TO L8 & L11
CU-B1-L9	DAIKIN	RXYM24A4VA	CONDENSING UNIT	9.7 (-19.6%)	-	12.3	-	-	240V 1ph	9.5x15.9	-	16.5	940*990*320	71	L9
FCU-902.1	DAIKIN	FXDQ63TV13	DUCTED UNIT	5.7	4.7	7.2	27.0 / 19.0	325	220V 1ph	9.5x15.9	33-37	1.8	1100*200*450	24	L9
FCU-902.2	DAIKIN	FXDQ25TV13	DUCTED UNIT	2.3	2	2.9	27.0 / 19.0	150	220V 1ph	6.4x12.7	28-33	0.8	700*200*450	18	L9
FCU-902.3	DAIKIN	FXDQ20TV13	DUCTED UNIT	1.8	1.7	2.3	27.0 / 19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700*200*450	18	L9
CU-B2-L4 TO L6	DAIKIN	RXYM24A4VA	CONDENSING UNIT	9.9 (-18%)	-	12.4	-	-	240V 1ph	9.5x15.9	-	16.5	940*990*320	71	L4 TO L6
FCU-403.1	DAIKIN	FXDQ63TV13	DUCTED UNIT	5.8	4.7	7.2	27.0 / 19.0	325	220V 1ph	9.5x15.9	33-37	1.8	1100*200*450	24	L4 TO L6
FCU-403.2	DAIKIN	FXDQ25TV13	DUCTED UNIT	2.3	2.1	2.9	27.0 / 19.0	150	220V 1ph	6.4x12.7	28-33	0.8	700*200*450	18	L4 TO L6
FCU-403.3	DAIKIN	FXDQ20TV13	DUCTED UNIT	1.8	1.7	2.3	27.0 / 19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700*200*450	18	L4 TO L6
CU-B2-L7	DAIKIN	RXYM24A4VA	CONDENSING UNIT	9.6 (-18%)	-	12.3	-	-	240V 1ph	9.5x15.9	-	16.5	940*990*320	71	L7
FCU-703.1	DAIKIN	FXDQ63TV13	DUCTED UNIT	5.6	4.6	7.1	27.0 / 19.0	325	220V 1ph	9.5x15.9	33-37	1.8	1100*200*450	24	L7
FCU-703.2	DAIKIN	FXDQ25TV13	DUCTED UNIT	2.2	2	2.9	27.0 / 19.0	150	220V 1ph	6.4x12.7	28-33	0.8	700*200*450	18	L7
FCU-703.3	DAIKIN	FXDQ20TV13	DUCTED UNIT	1.8	1.7	2.3	27.0 / 19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700*200*450	18	L7
CU-B2-L8	DAIKIN	RXYM24A4VA	CONDENSING UNIT	9.9 (-18.5%)	-	12.4	-	-	240V 1ph	9.5x15.9	-	16.5	940*990*320	71	L8
FCU-803.1	DAIKIN	FXDQ63TV13	DUCTED UNIT	5.7	4.7	7.2	27.0 / 19.0	325	220V 1ph	9.5x15.9	33-37	1.8	1100*200*450	24	L8
FCU-803.2	DAIKIN	FXDQ25TV13	DUCTED UNIT	2.3	2.1	2.9	27.0 / 19.0	150	220V 1ph	6.4x12.7	28-33	0.8	700*200*450	18	L8
FCU-803.3	DAIKIN	FXDQ20TV13	DUCTED UNIT	1.8	1.7	2.3	27.0 / 19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700*200*450	18	L8
CU-B2-L9	DAIKIN	RXYM24A4VA	CONDENSING UNIT	9.7 (-18%)	-	12.3	-	-	240V 1ph	9.5x15.9	-	16.5	940*990*320	71	L9
FCU-903.1	DAIKIN	FXDQ63TV13	DUCTED UNIT	5.6	4.7	7.2	27.0 / 19.0	325	220V 1ph	9.5x15.9	33-37	1.8	1100*200*450	24	L9
FCU-903.2	DAIKIN	FXDQ25TV13	DUCTED UNIT	2.3	2	2.9	27.0 / 19.0	150	220V 1ph	6.4x12.7	28-33	0.8	700*200*450	18	L9
FCU-903.3	DAIKIN	FXDQ20TV13	DUCTED UNIT	1.8	1.7	2.3	27.0 / 19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700*200*450	18	L9
CU-B2-L11	DAIKIN	RXYM24A4VA	CONDENSING UNIT	10.3 (-19%)	-	12.5	-	-	240V 1ph	9.5x15.9	-	16.5	940*990*320	71	L11
FCU-1103.1	DAIKIN	FXDQ63TV13	DUCTED UNIT	6	4.8	7.2	27.0 / 19.0	325	220V 1ph	9.5x15.9	33-37	1.8	1100*200*450	24	L11
FCU-1103.2	DAIKIN	FXDQ25TV13	DUCTED UNIT	2.4	2.1	2.9	27.0 / 19.0	150	220V 1ph	6.4x12.7	28-33	0.8	700*200*450	18	L11
FCU-1103.3	DAIKIN	FXDQ20TV13	DUCTED UNIT	1.9	1.7	2.3	27.0 / 19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700*200*450	18	L11

**A/C EQUIPMENT SCHEDULE**

CU-C-L4 & L8 & L8	DAIKIN	RXYM04A4M4	CONDENSING UNIT	10.5(-26.7%)	-	12.5	-	-	240V 1ph	9.5x15.9	-	16.5	940*990*320	71	L4 & L8 & L8
FCU-404.1	DAIKIN	FXDQ63TV3	DUCTED UNIT	5.1	4.5	6.1	27.0/19.0	325	220V 1ph	9.5x15.9	33-37	1.8	1100*200*450	24	L4 & L8 & L8
FCU-404.2	DAIKIN	FXDQ25TV3	DUCTED UNIT	2.1	2	2.4	27.0/19.0	150	220V 1ph	6.4x12.7	28-33	0.8	700*200*450	18	L4 & L8 & L8
FCU-404.3	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.8	1.8	2	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700*200*450	18	L4 & L8 & L8
FCU-404.4	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.8	1.8	2	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700*200*450	18	L4 & L8 & L8
CU-C-L5	DAIKIN	RXYM04A4M4	CONDENSING UNIT	10.5(-26.7%)	-	12.5	-	-	240V 1ph	9.5x15.9	-	16.5	940*990*320	71	L5
FCU-504.1	DAIKIN	FXDQ63TV3	DUCTED UNIT	5.2	4.5	6.1	27.0/19.0	325	220V 1ph	9.5x15.9	33-37	1.8	1100*200*450	24	L5
FCU-504.2	DAIKIN	FXDQ25TV3	DUCTED UNIT	2.1	2	2.5	27.0/19.0	150	220V 1ph	6.4x12.7	28-33	0.8	700*200*450	18	L5
FCU-504.3	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.7	1.8	2	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700*200*450	18	L5
FCU-504.4	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.7	1.8	2	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700*200*450	18	L5
CU-C-L7	DAIKIN	RSUYQ5A6M4	CONDENSING UNIT	11 (-22.9%)	-	15.3	-	-	240V 1ph	9.5x15.9	-	27	870x1100x460	98	L7
FCU-704.1	DAIKIN	FXDQ63TV3	DUCTED UNIT	5.4	4.3	7.5	27.0/19.0	325	220V 1ph	9.5x15.9	33-37	1.8	1100*200*450	24	L7
FCU-704.2	DAIKIN	FXDQ25TV3	DUCTED UNIT	2.1	1.7	3	27.0/19.0	150	220V 1ph	6.4x12.7	28-33	0.8	700*200*450	18	L7
FCU-704.3	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.7	1.4	2.4	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700*200*450	18	L7
FCU-704.4	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.7	1.4	2.4	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700*200*450	18	L7
CU-C-L9	DAIKIN	RXYM04A4M4	CONDENSING UNIT	10.4 (-27.2%)	-	12.5	-	-	240V 1ph	9.5x15.9	-	16.5	940*990*320	71	L9
FCU-904.1	DAIKIN	FXDQ63TV3	DUCTED UNIT	5	4.4	6.1	27.0/19.0	325	220V 1ph	9.5x15.9	33-37	1.8	1100*200*450	24	L9
FCU-904.2	DAIKIN	FXDQ25TV3	DUCTED UNIT	2	1.9	2.4	27.0/19.0	150	220V 1ph	6.4x12.7	28-33	0.8	700*200*450	18	L9
FCU-904.3	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.8	1.8	1.9	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700*200*450	18	L9
FCU-904.4	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.8	1.8	1.9	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700*200*450	18	L9
CU-C-L11	DAIKIN	RXYM04A4M4	CONDENSING UNIT	11.2	-	12.7	-	-	240V 1ph	9.5x15.9	-	16.5	940*990*320	71	L11
FCU-1104.1	DAIKIN	FXDQ63TV3	DUCTED UNIT	5.5	4.6	6.2	27.0/19.0	325	220V 1ph	9.5x15.9	33-37	1.8	1100*200*450	24	L11
FCU-1104.2	DAIKIN	FXDQ25TV3	DUCTED UNIT	2.2	2	2.5	27.0/19.0	150	220V 1ph	6.4x12.7	28-33	0.8	700*200*450	18	L11
FCU-1104.3	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.8	1.7	2	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700*200*450	18	L11
FCU-1104.4	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.8	1.7	2	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700*200*450	18	L11
CU-D-L4 TO 6	DAIKIN	RXYM04A4M4	CONDENSING UNIT	10.4 (-27%)	-	12.5	-	-	240V 1ph	9.5x15.9	-	16.5	940*990*320	71	L4 TO L6
FCU-405.1	DAIKIN	FXDQ63TV3	DUCTED UNIT	5.1	4.5	6.1	27.0/19.0	325	220V 1ph	9.5x15.9	33-37	1.8	1100*200*450	24	L4 TO L6
FCU-405.2	DAIKIN	FXDQ25TV3	DUCTED UNIT	2	2	2.4	27.0/19.0	150	220V 1ph	6.4x12.7	28-33	0.8	700*200*450	18	L4 TO L6
FCU-405.3	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.8	1.8	2	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700*200*450	18	L4 TO L6
FCU-405.4	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.8	1.8	2	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700*200*450	18	L4 TO L6
CU-D-L7	DAIKIN	RSUYQ5A6M4	CONDENSING UNIT	10.9 (-23.9%)	-	15.3	-	-	240V 1ph	9.5x15.9	-	27	870x1100x460	98	L7
FCU-705.1	DAIKIN	FXDQ63TV3	DUCTED UNIT	5.3	4.3	7.5	27.0/19.0	325	220V 1ph	9.5x15.9	33-37	1.8	1100*200*450	24	L7
FCU-705.2	DAIKIN	FXDQ25TV3	DUCTED UNIT	2.1	1.7	3	27.0/19.0	150	220V 1ph	6.4x12.7	28-33	0.8	700*200*450	18	L7
FCU-705.3	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.7	1.3	2.4	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700*200*450	18	L7
FCU-705.4	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.7	1.3	2.4	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700*200*450	18	L7
CU-D-L8 & L9	DAIKIN	RSUYQ5A6M4	CONDENSING UNIT	12.9 (-9.4%)	-	13	-	-	240V 1ph	9.5x15.9	-	27	870x1100x460	98	L8 & L9
FCU-804.1	DAIKIN	FXDQ63TV3	DUCTED UNIT	5.4	4.3	7.5	27.0/19.0	325	220V 1ph	9.5x15.9	33-37	1.8	1100*200*450	24	L8 & L9
FCU-804.2	DAIKIN	FXDQ25TV3	DUCTED UNIT	2.1	1.7	3	27.0/19.0	150	220V 1ph	6.4x12.7	28-33	0.8	700*200*450	18	L8 & L9
FCU-804.3	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.7	1.4	2.4	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700*200*450	18	L8 & L9
FCU-804.4	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.7	1.4	2.4	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700*200*450	18	L8 & L9
CU-D-L11	DAIKIN	RXYM04A4M4	CONDENSING UNIT	12.9 (-9.4%)	-	13	-	-	240V 1ph	9.5x15.9	-	16.5	940*990*320	71	L11
FCU-1104.1	DAIKIN	FXDQ63TV3	DUCTED UNIT	5.4	4.6	6.2	27.0/19.0	325	220V 1ph	9.5x15.9	33-37	1.8	1100*200*450	24	L11
FCU-1104.2	DAIKIN	FXDQ25TV3	DUCTED UNIT	2.2	2	2.5	27.0/19.0	150	220V 1ph	6.4x12.7	28-33	0.8	700*200*450	18	L11
FCU-1104.3	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.7	1.7	2	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700*200*450	18	L11
FCU-1104.4	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.7	1.7	2	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700*200*450	18	L11
CU-E-L4 TO L5	DAIKIN	RXYM04A4M4	CONDENSING UNIT	9.6 (-21%)	-	12.3	-	-	240V 1ph	9.5x15.9	-	16.5	940*990*320	71	L4 TO L5
FCU-406.1	DAIKIN	FXDQ63TV3	DUCTED UNIT	5.6	4.6	7.1	27.0/19.0	325	220V 1ph	9.5x15.9	33-37	1.8	1100*200*450	24	L4 TO L5
FCU-406.2	DAIKIN	FXDQ25TV3	DUCTED UNIT	2.2	2	2.9	27.0/19.0	150	220V 1ph	6.4x12.7	28-33	0.8	700*200*450	18	L4 TO L5
FCU-406.3	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.8	1.7	2.3	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700*200*450	18	L4 TO L5
CU-E-L6	DAIKIN	RSUYQ4A4M4	CONDENSING UNIT	9.1(-25.2%)	-	12	-	-	240V 1ph	9.5x15.9	-	20	870x1100x460	95	L6
FCU-606.1	DAIKIN	FXDQ63TV3	DUCTED UNIT	5.3	4.3	7	27.0/19.0	325	220V 1ph	9.5x15.9	33-37	1.8	1100*200*450	24	L6
FCU-606.2	DAIKIN	FXDQ25TV3	DUCTED UNIT	2.1	1.7	2.8	27.0/19.0	150	220V 1ph	6.4x12.7	28-33	0.8	700*200*450	18	L6
FCU-606.3	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.7	1.3	2.2	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700*200*450	18	L6
CU-E-L7 & L8	DAIKIN	RSUYQ4A4M4	CONDENSING UNIT	8.8 (-27.2%)	-	11.9	-	-	240V 1ph	9.5x15.9	-	16.5	870x1100x460	95	L7 & L8
FCU-706.1	DAIKIN	FXDQ63TV3	DUCTED UNIT	5.1	4.2	6.9	27.0/19.0	325	220V 1ph	9.5x15.9	33-37	1.8	1100*200*450	24	L7 & L8
FCU-706.2	DAIKIN	FXDQ25TV3	DUCTED UNIT	2	1.6	2.8	27.0/19.0	150	220V 1ph	6.4x12.7	28-33	0.8	700*200*450	18	L7 & L8
FCU-706.3	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.8	1.3	2.2	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700*200*450	18	L7 & L8
CU-E-L9	DAIKIN	RSUYQ4A4M4	CONDENSING UNIT	8.9 (-9.6%)	-	12	-	-	240V 1ph	9.5x15.9	-	16.5	870x1100x460	95	L9
FCU-906.1	DAIKIN	FXDQ63TV3	DUCTED UNIT	5.2	4.3	7	27.0/19.0	325	220V 1ph	9.5x15.9	33-37	1.8	1100*200*450	24	L9
FCU-906.2	DAIKIN	FXDQ25TV3	DUCTED UNIT	2.1	1.7	2.8	27.0/19.0	150	220V 1ph	6.4x12.7	28-33	0.8	700*200*450	18	L9
FCU-906.3	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.7	1.3	2.2	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700*200*450	18	L9
CU-E-L11	DAIKIN	RXYM04A4M4	CONDENSING UNIT	10.1 (-16.8%)	-	12.4	-	-	240V 1ph	9.5x15.9	-	16.5	940*990*320	71	L11
FCU-1106.1	DAIKIN	FXDQ63TV3	DUCTED UNIT	5.9	4.7	7.2	27.0/19.0	325	220V 1ph	9.5x15.9	33-37	1.8	1100*200*450	24	L11
FCU-1106.2	DAIKIN	FXDQ25TV3	DUCTED UNIT	2.3	2.1	2.9	27.0/19.0	150	220V 1ph	6.4x12.7	28-33	0.8	700*200*450	18	L11
FCU-1106.3	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.9	1.7	2.3	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700*200*450	18	L11
CU-1001-L10	DAIKIN	RXYM05B5M	CONDENSING UNIT	12.6 (-23.5%)	-	14.7	-	-	240V 1ph	9.5x15.9	-	27	990*940*320	78	LEVEL 10
FCU-1001.1	DAIKIN	FXDQ63TV3	DUCTED UNIT	5.4	4.5	6.2	27.0/19.0	325	220V 1ph	9.5x15.9	33-37	1.8	1100*200*450	24	LEVEL 10
FCU-1001.2	DAIKIN	FXDQ25TV3	DUCTED UNIT	2.1	2	2.5	27.0/19.0	150	220V 1ph	6.4x12.7	28-33	0.8	700*200*450	18	

**A/C EQUIPMENT SCHEDULE**

REF. NO.	MAKE	MODEL	SERVED AREA	TOTAL COOLING	SENSIBLE COOLING	HEATING COOLING	S/A	POWER	PIPE SIZE	DIMENSIONS	WEIGHT				
				Kw	Kw	Kw	L/s		mm	HxWxD	Kg				
CU-A112	DAIKIN	RXYM04A4M	CONDENSING UNIT	10.1 (-16.4%)	-	12.4	-	-	240V 1ph	9.5x15.9	16.5	940x990x320	71	LEVEL 12	
FCU-1201.1	DAIKIN	FXDQ63TV3	DUCTED UNIT	5.9	4.8	7.2	27.0/19.0	325	220V 1ph	9.5x15.9	33-37	1.8	1100x200x450	24	LEVEL 12
FCU-1201.2	DAIKIN	FXDQ25TV3	DUCTED UNIT	2.4	2.1	2.9	27.0/19.0	150	220V 1ph	6.4x12.7	28-33	0.8	700x200x450	18	LEVEL 12
FCU-1201.3	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.9	1.7	2.3	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700x200x450	18	LEVEL 12
CU-B1-L12	DAIKIN	RXYM04A4M	CONDENSING UNIT	10.2 (-15.4%)	-	12.4	-	-	240V 1ph	9.5x15.9	-	16.5	940x990x320	71	LEVEL 12
FCU-1202.1	DAIKIN	FXDQ63TV3	DUCTED UNIT	5.9	4.8	7.2	27.0/19.0	325	220V 1ph	9.5x15.9	33-37	1.8	1100x200x450	24	LEVEL 12
FCU-1202.2	DAIKIN	FXDQ25TV3	DUCTED UNIT	2.4	2.1	2.9	27.0/19.0	150	220V 1ph	6.4x12.7	28-33	0.8	700x200x450	18	LEVEL 12
FCU-1202.3	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.9	1.7	2.3	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700x200x450	18	LEVEL 12
CU-B2-L12	DAIKIN	RXYM04A4M	CONDENSING UNIT	10.6 (-12.4%)	-	12.5	-	-	240V 1ph	9.5x15.9	-	16.5	940x990x320	71	LEVEL 12
FCU-1203.1	DAIKIN	FXDQ63TV3	DUCTED UNIT	6.2	4.9	7.3	27.0/19.0	325	220V 1ph	9.5x15.9	33-37	1.8	1100x200x450	24	LEVEL 12
FCU-1203.2	DAIKIN	FXDQ25TV3	DUCTED UNIT	2.5	2.1	2.9	27.0/19.0	150	220V 1ph	6.4x12.7	28-33	0.8	700x200x450	18	LEVEL 12
FCU-1203.3	DAIKIN	FXDQ20TV3	DUCTED UNIT	2	1.8	2.3	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700x200x450	18	LEVEL 12
CU-1204-L12	DAIKIN	RSUY06A4M	CONDENSING UNIT	15.4	-	17.8	-	-	400V 3ph	9.5x19.1	-	18.5	870x1100x480	98	LEVEL 12
FCU-1204.1	DAIKIN	FXDQ40TV3	DUCTED UNIT	3.2	2.8	3.8	27.0/19.0	210	220V 1ph	6.4x12.7	29-34	1.9	900x200x450	21	LEVEL 12
FCU-1204.2	DAIKIN	FXDQ25TV3	DUCTED UNIT	2	1.8	2.3	27.0/19.0	150	220V 1ph	6.4x12.7	28-33	0.8	700x200x450	18	LEVEL 12
FCU-1204.3	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.6	1.3	1.8	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700x200x450	18	LEVEL 12
FCU-1204.4	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.6	1.3	1.8	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700x200x450	18	LEVEL 12
FCU-1204.5	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.6	1.3	1.8	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700x200x450	18	LEVEL 12
FCU-1204.6	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.6	1.3	1.8	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700x200x450	18	LEVEL 12
FCU-1204.7	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.6	1.3	1.8	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700x200x450	18	LEVEL 12
CU-E-L12	DAIKIN	RXYM04A4M	CONDENSING UNIT	10.3 (-14.7%)	-	12.5	-	-	240V 1ph	9.5x15.9	-	16.5	940x990x320	71	LEVEL 12
FCU-1206.1	DAIKIN	FXDQ63TV3	DUCTED UNIT	6	4.8	7.3	27.0/19.0	325	220V 1ph	9.5x15.9	33-37	1.8	1100x200x450	24	LEVEL 12
FCU-1206.2	DAIKIN	FXDQ25TV3	DUCTED UNIT	2.4	2.1	2.9	27.0/19.0	150	220V 1ph	6.4x12.7	28-33	0.8	700x200x450	18	LEVEL 12
FCU-1206.3	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.9	1.7	2.3	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700x200x450	18	LEVEL 12
CU-1301-L13	DAIKIN	RXYM05B5M	CONDENSING UNIT	12.5 (-24.5%)	-	14.7	-	-	240V 1ph	9.5x15.9	-	27	990x940x320	78	LEVEL 13
FCU-1301.1	DAIKIN	FXDQ63TV3	DUCTED UNIT	5.3	4.5	6.2	27.0/19.0	325	220V 1ph	9.5x15.9	33-37	1.8	1100x200x450	24	LEVEL 13
FCU-1301.2	DAIKIN	FXDQ25TV3	DUCTED UNIT	2.1	2	2.5	27.0/19.0	150	220V 1ph	6.4x12.7	28-33	0.8	700x200x450	18	LEVEL 13
FCU-1301.3	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.7	1.6	2	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700x200x450	18	LEVEL 13
FCU-1301.4	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.7	1.6	2	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700x200x450	18	LEVEL 13
FCU-1301.5	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.7	1.6	2	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700x200x450	18	LEVEL 13
CU-B2-L13	DAIKIN	RXYM04A4M	CONDENSING UNIT	10.4 (-14.1%)	-	12.5	-	-	240V 1ph	9.5x15.9	-	16.5	940x990x320	71	LEVEL 13
FCU-1303.1	DAIKIN	FXDQ63TV3	DUCTED UNIT	6	4.8	7.3	27.0/19.0	325	220V 1ph	9.5x15.9	33-37	1.8	1100x200x450	24	LEVEL 13
FCU-1303.2	DAIKIN	FXDQ25TV3	DUCTED UNIT	2.4	2.1	2.9	27.0/19.0	150	220V 1ph	6.4x12.7	28-33	0.8	700x200x450	18	LEVEL 13
FCU-1303.3	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.9	1.7	2.3	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700x200x450	18	LEVEL 13
CU-1304-L13	DAIKIN	RSUY06A4M	CONDENSING UNIT	15.3	-	17.7	-	-	400V 3ph	9.5x19.1	-	18.5	870x1100x480	98	LEVEL 13
FCU-1304.1	DAIKIN	FXDQ40TV3	DUCTED UNIT	3.1	2.8	3.8	27.0/19.0	210	220V 1ph	6.4x12.7	29-34	1.9	900x200x450	21	LEVEL 13
FCU-1304.2	DAIKIN	FXDQ25TV3	DUCTED UNIT	2	1.8	2.3	27.0/19.0	150	220V 1ph	6.4x12.7	28-33	0.8	700x200x450	18	LEVEL 13
FCU-1304.3	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.6	1.3	1.8	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700x200x450	18	LEVEL 13
FCU-1304.4	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.6	1.3	1.8	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700x200x450	18	LEVEL 13
FCU-1304.5	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.6	1.3	1.8	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700x200x450	18	LEVEL 13
FCU-1304.6	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.6	1.3	1.8	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700x200x450	18	LEVEL 13
FCU-1304.7	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.6	1.3	1.8	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700x200x450	18	LEVEL 13
CU-E-L13	DAIKIN	RXYM04A4M	CONDENSING UNIT	10.2 (-15.8%)	-	12.4	-	-	240V 1ph	9.5x15.9	-	16.5	940x990x320	71	LEVEL 13
FCU-1306.1	DAIKIN	FXDQ63TV3	DUCTED UNIT	5.9	4.8	7.2	27.0/19.0	325	220V 1ph	9.5x15.9	33-37	1.8	1100x200x450	24	LEVEL 13
FCU-1306.2	DAIKIN	FXDQ25TV3	DUCTED UNIT	2.4	2.1	2.9	27.0/19.0	150	220V 1ph	6.4x12.7	28-33	0.8	700x200x450	18	LEVEL 13
FCU-1306.3	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.9	1.7	2.3	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700x200x450	18	LEVEL 13
CU-F-L14 & L15	DAIKIN	RXYM06B5M	CONDENSING UNIT	15.6 (-23%)	-	16	-	-	240V 1ph	9.5x19.1	-	27	990x940x320	80	LEVEL 14 & 15
FCU-1401.1	DAIKIN	FXDQ63TV3	DUCTED UNIT	5.4	4.6	5.6	27.0/19.0	325	220V 1ph	9.5x15.9	33-37	1.8	1100x200x450	24	LEVEL 14 & 15
FCU-1401.2	DAIKIN	FXDQ32TV3	DUCTED UNIT	2.4	2.4	2.8	27.0/19.0	150	220V 1ph	6.4x12.7	28-33	0.9	700x200x450	18	LEVEL 14 & 15
FCU-1401.3	DAIKIN	FXDQ25TV3	DUCTED UNIT	2.2	2	2.2	27.0/19.0	150	220V 1ph	6.4x12.7	28-33	0.8	700x200x450	18	LEVEL 14 & 15
FCU-1401.4	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.7	1.7	1.8	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700x200x450	18	LEVEL 14 & 15
FCU-1401.5	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.7	1.7	1.8	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700x200x450	18	LEVEL 14 & 15
FCU-1401.6	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.7	1.7	1.8	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700x200x450	18	LEVEL 14 & 15
CU-G-L14 & L15	DAIKIN	RXYM06B5M	CONDENSING UNIT	16 (-15.8%)	-	16.1	-	-	240V 1ph	9.5x19.1	-	27	990x940x320	80	LEVEL 14 & 15
FCU-1402.1	DAIKIN	FXS06P4V6	DUCTED UNIT	7.5	5.8	7.6	27.0/19.0	383	220V 1ph	9.5x15.9	30-37.5	1.8	1000x245x800	37	LEVEL 14 & 15
FCU-1402.2	DAIKIN	FXDQ25TV3	DUCTED UNIT	2.4	2.1	2.4	27.0/19.0	150	220V 1ph	6.4x12.7	28-33	0.8	700x200x450	18	LEVEL 14 & 15
FCU-1402.3	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.9	1.7	1.9	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700x200x450	18	LEVEL 14 & 15
FCU-1402.4	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.9	1.7	1.9	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700x200x450	18	LEVEL 14 & 15
FCU-1402.5	DAIKIN	FXDQ25TV3	DUCTED UNIT	2.4	2.1	2.4	27.0/19.0	150	220V 1ph	6.4x12.7	28-33	0.8	700x200x450	18	LEVEL 14 & 15
CU-H-L14 & L15	DAIKIN	RSUY06A4M	CONDENSING UNIT	15.2	-	17.7	-	-	400V 3ph	9.5x19.1	-	18.5	870x1100x480	98	LEVEL 14 & 15
FCU-1403.1	DAIKIN	FXDQ40TV3	DUCTED UNIT	3.2	2.8	3.7	27.0/19.0	210	220V 1ph	6.4x12.7	29-34	1.9	900x200x450	21	LEVEL 14 & 15
FCU-1403.2	DAIKIN	FXDQ40TV3	DUCTED UNIT	3.2	2.8	3.7	27.0/19.0	210	220V 1ph	6.4x12.7	29-34	1.9	900x200x450	21	LEVEL 14 & 15
FCU-1403.3	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.6	1.3	1.9	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700x200x450	18	LEVEL 14 & 15
FCU-1403.4	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.6	1.3	1.9	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700x200x450	18	LEVEL 14 & 15
FCU-1403.5	DAIKIN	FXDQ20TV3	DUCTED UNIT	1.6	1.3	1.9	27.0/19.0	135	220V 1ph	6.4x12.7	28-32	0.6	700x200x450	18	LEVEL 14 & 15
FCU-1403.6	DAIKIN	FXDQ32TV3	DUCTED UNIT	2.5	2.1										



### FAN SCHEDULE - LEVEL 4 TO 9 & 11

REF. NO.	MAKE	MODEL	TYPE	QTY.	VOL	PRS	SPEED	MOTOR	PHASE	NOISE	WEIGHT	LOCATION
EF-1	FANTECH	ECL29-150RDW	Velocity Series	84	25	120	950	0.04	220 / 1 / 50	39	3	ENSUITES/BATHROOMS
EF-2	FANTECH	RESPF150	Response Series	42	40	120	960	0.06	240 / 1 / 50	37	3.25	ENSUITES/BATHROOMS

### FAN SCHEDULE - LEVEL 10

REF. NO.	MAKE	MODEL	TYPE	QTY.	VOL	PRS	SPEED	MOTOR	PHASE	NOISE	WEIGHT	LOCATION
					L/s	Pa	r/min	Kw	V / Ph / Hz	dB(A) @ 3m	Kg	
EF-2	FANTECH	RESPF150	Response Series	5	40	120	960	0.06	240 / 1 / 50	37	3.25	ENSUITES/BATHROOMS
EF-4	FANTECH	RESPF150	Response Series	2	25	150	1920	0.06	240 / 1 / 50	39	2.2	ENSUITES/BATHROOMS

### FAN SCHEDULE - LEVEL 12

REF. NO.	MAKE	MODEL	TYPE	QTY.	VOL	PRS	SPEED	MOTOR	PHASE	NOISE	WEIGHT	LOCATION
					L/s	Pa	r/min	Kw	V / Ph / Hz	dB(A) @ 3m	Kg	
EF-2	FANTECH	RESPF150	Response Series	6	40	120	1920	0.06	240 / 1 / 50	39	2.2	ENSUITES/BATHROOMS
EF-4	FANTECH	RESPF150	Response Series	1	25	150	1920	0.06	240 / 1 / 50	39	2.2	ENSUITES/BATHROOMS

### FAN SCHEDULE - LEVEL 13

REF. NO.	MAKE	MODEL	TYPE	QTY.	VOL	PRS	SPEED	MOTOR	PHASE	NOISE	WEIGHT	LOCATION
					L/s	Pa	r/min	Kw	V / Ph / Hz	dB(A) @ 3m	Kg	

### FAN SCHEDULE - LEVEL 14 & 15

REF. NO.	MAKE	MODEL	TYPE	QTY.	VOL	PRS	SPEED	MOTOR	PHASE	NOISE	WEIGHT	LOCATION
					L/s	Pa	r/min	Kw	V / Ph / Hz	dB(A) @ 3m	Kg	
EF-1	FANTECH	ECL29-150RDW	Velocity Series	14	25	40	950	0.04	220 / 1 / 50	39	3	ENSUITES/BATHROOMS
EF-2	FANTECH	RESPF150	Response Series	6	40	120	950	0.06	220 / 1 / 50	38	3.3	ENSUITES/BATHROOMS
EF-4	FANTECH	RESPF150	Response Series	8	25	120	950	0.06	220 / 1 / 50	38	3.3	ENSUITES/BATHROOMS

**Office:** 2/30 Access Crescent, Coolum Beach, QLD 4573  
**Postal:** PO Box 6017, Maroochydore, Qld 4558  
**Email:** [admin@portcityairconditioning.com.au](mailto:admin@portcityairconditioning.com.au)  
**Phone:** 1300 PORT CITY / 07 4972 3355 **Fax:** 07 4972 1791

**After Hours Emergency Phone:** 0439 665 398  
**Website:** <http://www.portcitygroup.com.au/>



### Section 3

#### Operation & Maintenance Procedures

Please see following pages containing.

Operation manual for Daikin wall controller.

PCA Maintenance advise.

& troubleshooting information.

**Office:** 2/30 Access Crescent, Coolum Beach, QLD 4573

**Postal:** PO Box 6017, Maroochydore, Qld 4558

**Email:** [admin@portcityairconditioning.com.au](mailto:admin@portcityairconditioning.com.au)

**Phone:** 1300 PORT CITY / 07 4972 3355 **Fax:** 07 4972 1791

**After Hours Emergency Phone:** 0439 665 398

**Website:** <http://www.portcitygroup.com.au/>

# WIRED REMOTE CONTROLLER

## OPERATION MANUAL



BRC1E63

- Thank you for purchasing this product.
- This manual describes safety precautions required for the use of the product.

**Read this manual carefully and be sure you understand the information before using the product.**

Keep this manual where it is readily accessible after reading it through. If another user operates the product in the future, be sure to hand over this manual to the new user.

Refer to the operation manuals attached to the indoor and outdoor units, etc.

# Contents

## Notices

Safety Precautions	
– Items to be Strictly Observed – .....	2
Button Location and Descriptions.....	5
Names and Functions.....	7

## Basic Operation (Use of Direct Buttons)

Cool/Heat/Auto/Fan Operation .....	10
Dry Operation .....	14
Setback.....	16
Ventilation Operation .....	17
Setting the Cool/Heat Selection Eligibility.....	18
Key Lock .....	20

## Quick Reference Main Menu

Main Menu Items .....	21
-----------------------	----

## Menu Manipulation

Manipulating the Main Menu Screen .....	25
Circulation Airflow .....	26
Individual Air Direction.....	27
Quick Start (SPLIT system only) .....	30
Ventilation .....	32
Energy Saving Options.....	34
Schedule.....	43
Filter Auto Clean.....	49
Maintenance Information .....	50
Configuration .....	51
Current Settings.....	59
Clock & Calendar.....	60
Language.....	64

## Maintenance

Reset Filter Indicator .....	65
Cleaning of Remote Controller .....	66

## Reference Information



Malfunction (Error) Code Display .....	67
After-sales Service .....	68


# Safety Precautions – Items to be Strictly Observed –

This product is not intended for use by children or infirm persons without supervision. Children should be supervised to ensure that they do not play with the product.

**Read the safety precautions carefully for the proper use of the product.**

- This manual classifies the precautions into WARNINGS and CAUTIONS. Be sure to follow all the precautions below: They are all important for ensuring safety.

 <b>WARNING</b>	Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
 <b>CAUTION</b>	Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.

 <b>WARNING</b>	
<ul style="list-style-type: none"><li>• <b>Do not install the remote controller by yourself.</b> Improper installation may result in electric shocks or a fire. Consult your local dealer.</li></ul>	
<ul style="list-style-type: none"><li>• <b>Do not modify or repair the remote controller.</b> It may result in electric shocks or a fire. Consult your local dealer.</li></ul>	
<ul style="list-style-type: none"><li>• <b>Do not relocate or reinstall the remote controller by yourself.</b> Improper installation may result in electric shocks or a fire. Consult your local dealer.</li></ul>	
<ul style="list-style-type: none"><li>• <b>Do not use flammable materials such as hairspray or insecticide near the product.</b> It may result in electric shocks or a fire.</li></ul>	
<ul style="list-style-type: none"><li>• <b>Do not wipe the product with benzene, thinner, chemical dustcloth, etc.</b> The product may get discolored or the coating peeled off. The use of organic solvents may cause cracking of the product, electric shocks or a fire.</li></ul>	





## CAUTION

- **Do not allow children to play with the remote controller.**  
Accidental operation by children may result in health impairment.
- **Do not disassemble the product.**  
Touching the interior parts may result in electric shocks or a fire.  
Consult your local dealer for internal inspections and adjustments.
- **Do not press the button of the remote controller with a hard, pointed object.**  
The remote controller may be damaged.
- **Do not pull or twist the electric wire of the remote controller.**  
It may cause the unit to malfunction.
- **Do not operate with wet hands to avoid electric shocks or a fire.**
- **Do not wash the remote controller.**  
It may cause electric leakage and result in electric shocks or a fire.
- **Do not locate the remote controller wherever there is a risk of wetting.**  
If water gets into the remote controller there is a risk of electric leakage and damage to electronic components.  
It may result in electric shocks or a fire.



## ■ Disposal requirements

Your product and the batteries supplied with the controller are marked with this symbol. This symbol means that electrical and electronic products and batteries shall not be mixed with unsorted household waste.

For batteries, a chemical symbol can be printed beneath the symbol. This chemical symbol means that the battery contains a heavy metal above a certain concentration.

Possible chemical symbols are:


■ Pb: lead (>0.004%)

Do not try to dismantle the system yourself: the dismantling of the product, treatment of the refrigerant, of oil and of other parts must be done by a qualified installer in accordance with relevant local and national legislation. Units and waste batteries must be treated at a specialized treatment facility for re-use, recycling and recovery.

By ensuring correct disposal, you will help to prevent potential negative consequences for the environment and human health.

Please contact the installer or local authority for more information.

# Button Location and Descriptions



Basic operations (i.e., ON/OFF, Operation Mode, Airflow Rate (Airflow level/Fan Speed), Airflow Direction and Set Temperature) are manipulable directly by the above button.

Advanced settings are manipulable from the Menu screen displayed by the Menu/Enter button.

## NOTE

- Do not press the buttons on the remote controller with a hard, pointed objects. Otherwise, the remote controller may be damaged or malfunction.

## 1. Mode Selector button

---

- Use to select the operation mode of your preference. **(Refer to page 10.)**  
\* Available modes vary with the connecting model.

## 2. Airflow Setting button

---

- Used to indicate the Airflow Rate (Airflow level/Fan Speed)/Airflow Direction screen. **(Refer to page 11.)**  
\* Available fan speed and airflow direction vary with the connecting model.

## 3. Menu/Enter button

---

- Used to indicate the Main Menu. **(Refer to page 21 for the menu items.)**
- Used to enter the setting item selected.

## 4. Up button “▲”

---

- Used to raise the set temperature.
- Use to highlight the item above the current selection.  
(The highlighted items will be scrolled continuously when the button is kept pressed.)
- Used to change the item selected.  
\* Be sure to press the part with the symbol “▲”

## 5. Down button “▼”

---

- Used to lower the set temperature.
- Use to highlight the item below the current selection.  
(The highlighted items will be scrolled continuously when the button is kept pressed.)
- Used to change the item selected.  
\* Be sure to press the part with the symbol “▼”

## 6. Right button “▶”

---

- Used to highlight the next items on the right-hand side.
- Display contents are changed to next screen per page.  
\* Be sure to press the part with the symbol “▶”

## 7. Left button “◀”

---

- Used to highlight the next items on the left-hand side.
- Display contents are changed to previous screen per page.  
\* Be sure to press the part with the symbol “◀”

## 8. ON/OFF button

---

- Press this button and system will start.
- Press this button again and system will stop.

## 9. Operation lamp (Green)

---

- This lamp lights up during operation.
- This lamp blinks if a malfunction occurs.

## 10. Cancel button

---

- Used to return to the previous screen.

## 11. LCD (with backlight)

---

- The backlight will be lit for approximately 30 seconds by pressing any operation button. Press the button while the backlight is lit. (Excluding the ON/OFF button)
- If 2 remote controllers are used to control a single indoor unit, the backlight of the remote controller accessed first will be lit.

# Names and Functions

## Basic Screen

- Basic screen are two types of Standard display screen and Detailed display screen. The Standard display screen is set by default.
- To switch to the Detailed display, select the “Detailed” in the Main Menu. (Refer to page 56.)
- The contents on the screen vary with the operation mode of the connecting model. (The following display will appear when the air conditioner is in Automatic operation.)

### Standard display screen

11. Changeover Under Control

10. Centralized Control

1. Operation mode: Auto

3. Airflow Direction (Displayed only when the air conditioner is in operation.)

2. Airflow Rate (Airflow level/Fan Speed)

7. Ventilation/Air purifying

12. Setback

9. Timer Enabled

8. Key Locked

4. Set/Setback Temperature display

5. Defrost/Hot start

6. Message: This function not available

<Standard display example>

### Detailed display screen

- The clock, and selectable display items appear on the detailed display screen in addition to the items appearing on the standard display screen.

13. Clock (12/24 hours time display)

4. Set/Setback Temperature display

14. Selectable Display Item (with room temperature selected)

<Detailed display example 1>

2. Airflow Rate (Airflow level/Fan Speed) is not appear (No airflow rate control function)

3. Airflow Direction is not appear (No airflow direction function)

13. Clock (No clock setting)

15. Timer Disabled/Reset Clock

14. Selectable Display Item (No selectable display item selected)

<Detailed display example 2>

## 1. Operation Mode

---

- Displays the present operation mode, “Cool”, “Heat”, “Vent”, “Fan”, “Dry” or “Auto”.

## 2. Airflow Rate (Airflow level/ Fan Speed)

---

- Displays the airflow rate that is set for the indoor unit.
- The airflow rate will not be displayed if the indoor unit does not have airflow rate control function.

## 3. Airflow Direction “”

---

- Displayed when the airflow direction and swing are set (Refer to page 12).
- This icon is not displayed if the indoor unit does not have a function to set airflow directions.

## 4. Set/Setback Temperature display

---

- When the air conditioner is turned on, “Set to” indicates the set temperatures that are set for the air conditioner.
- When the air conditioner is turned off, “Setback” indicates the setback temperatures that are set for the air conditioner.

## 5. Defrost/Hot start “” (Refer to page 13.)

---

Displays if the Defrost/Hot start operation is active. If ventilating operation “” is displayed:

- Displayed when a Heat Reclaim Ventilator is connected.  
For details, refer to the Operation Manual of the Heat Reclaim Ventilator.

## 6. Message

---

The following messages are displayed.

“This function not available.”

- Displayed for a few seconds when an operation button is pressed and the indoor unit does not have the corresponding function.

- If a number of indoor units are in operation, the message will appear only if none of the indoor units is provided with the corresponding function, i.e., the message will not appear if at least one of the indoor units is provided with the corresponding function.

“Error: Push Menu button”

“Warning: Push Menu button”

- Displayed if an error or warning is detected (Refer to page 67).

“Quick Start” (Split system only)

- Displayed if the quick cooling/heating function is turned on (Refer to page 30).

“Time to clean filter”



“Time to clean element”

“Time to clean filter and element”

- Displayed when the time to clean the filter or element has come (Refer to page 65).

## 7. Ventilation/Air Purifying

---

- Displayed when a Heat Reclaim Ventilator is connected.
- **Ventilation Mode icon.** “”  
These icons indicate the current ventilation mode (Heat Reclaim Ventilator only) (AUTOMATIC, ENERGY RECLAIM VENTILATION, BYPASS).
- **Air purifying icon** “”  
This icon indicates that the Air Purifying unit (optional accessory) is in operation.

## 8. Key Locked “” (Refer to page 20.)

---

- Displayed when the key lock is set.

## 9. Timer Enabled “” (Refer to page 40 and 48.)

---

- Displayed if the Schedule timer or OFF timer is enabled.

## 10. Centralized Control “”

---

- Displayed if the system is under the management of centralized control equipment (optional accessories) and the operation of the system through the remote controller is prohibited.

## 11. Changeover Under Control “”

---

(VRV only)

- Displayed if the remote controller has no cool/heat selection eligibility. (Refer to page 18).

## 12. Setback “” (Refer to page 16.)

---

- The setback icon blinks when the air conditioner is turned on under the setback control.

## 13. Clock (12/24 hours time display)

---

- Displayed when the clock is set (Refer to page 60).
- If the clock is not set, “-- : --” will be displayed.

## 14. Selectable Display Item

---

- Displayed when the detailed display is selected (Refer to page 56).
- No detailed items are selected by default.

## 15. Timer Disabled/Reset Clock “”

---

- Displayed when the clock needs to be reset.
- The schedule timer function will not work unless the clock is reset.


# Basic Operation (Use of Direct Buttons)

## How to follow the operation manual

### Operation screen display

Describes screens that will be displayed on the remote controller.

1




### Operation procedure

Explains a button operation procedure.

- Display the Main Menu screen. (Refer to page 25.)
- Press "▼▲" buttons to select **Schedule**. Press Menu/Enter button to display the Schedule screen.
- Before setting the schedule, the clock must be set.
- If the clock has not been set, a screen like the one on the left will appear.
- Press "◀▶" buttons to select **Yes** and press Menu/Enter button.
- The Date & Time screen will appear.
- Set the current year, month, day, and time. (Refer to "Clock & Calendar" on page 60)

### Operation button

Describes the positions of buttons to be pressed.




## Cool/Heat/Auto/Fan Operation

### Preparation

- For mechanical protection purposes, turn on the power to the air conditioner at least 6 hours before starting the operation.

### Operation

1



Basic screen

- Press Mode Selector button several times until the desired mode, Cool, Heat, Fan or Auto is selected.



- \* Unavailable operation modes are not displayed.
- \* Only the Cool or Fan mode can be selected if the air conditioner is a cooling only model.

### Note

- The cooling or heating mode cannot be selected if the icon "☒" (Changeover Under Control) is displayed on the remote controller. Refer to page 18 if the icon "☒" display blinks.




2




- Press ON/OFF button.  
The Operation lamp (green) will be lit and the system will start operating.



3




- The set temperature will increase by 1°C when “▲” button is pressed and decrease by 1°C when “▼” button is pressed.





\* No temperature settings are possible while operating in Fan mode.

4




< Airflow Rate (Airflow level/Fan Speed) or Airflow Direction Setting >

- Press Airflow setting button.
- To select Air volume or Direction setting, press “◀▶” buttons.




5



<Airflow Rate Adjustment>

- With level selected, set the desired airflow rate from **Lv.1 (L)**, **Lv.2**, **Lv.3 (M)**, **Lv.4**, **Lv.5 (H)** or **Auto** using the “▼ ▲” buttons.



\* Depending on the type of indoor unit, the adjustment levels may be two levels of **Lv.2** and **Lv.4** or three levels of **Lv.2**, **Lv.3 (M)**, and **Lv.4**, or five levels of **Lv.1 (L)**, **Lv.2**, **Lv.3 (M)**, **Lv.4**, and **Lv.5 (H)**


\* For equipment protection purposes, the indoor unit may control airflow rate automatically.

\* According to the room temperature, the indoor unit may control airflow rate automatically.

The fan may stop operating, which, however, is not a failure.

\* It may take time until a change of the airflow rate is completed.


\* In **Auto** setting, the airflow rate is adjusted automatically according to set temperature and room temperature. In Fan mode, the airflow rate setting is always at Lv.5 (H).



### <Airflow Direction Setting>



- With **Direction** selected, set the desired airflow direction from, **Position 0**, **Position 1**, **Position 2**, **Position 3**, **Position 4**, **Swing**, and **Auto** using the “**▼▲**” buttons.




Airflow direction setting (up/down)

#### Note

- Airflow direction appears on the screen as below.




Up/down direction



Left/right direction

- 0 : Position 0
- 1 : Position 1
- 2 : Position 2
- 3 : Position 3
- 4 : Position 4



Airflow direction setting (left/right)

- When you set one of positions 0 to 4, the airflow direction flap stay in a fixed position.
- Selecting **Swing** will cause the airflow direction flap to swing position 0 to 4. For the swing setting only, all positions will be displayed.
- Setting **Auto** will varied airflow direction by room temperature and the presence or absence of the person. However, in Fan mode, the airflow direction flap will be to position 0. (This function may not be available depending on the type of indoor unit.)

- Press Menu/Enter button to confirm the settings and return to the Basic screen.



## Movement of airflow direction flap (blade)

Under the operation conditions shown below, airflow direction is controlled automatically. Actual operation may thus be different from what is displayed on the remote controller.

#### Operation condition

- Room temperature is higher than the set temperature (in Heat/Auto mode). (Discharge horizontally so that it does not discharge directly toward your body.)
- When the air conditioner goes into Heating Operation or Defrost Operation (in Heat/Auto mode). (Discharges horizontally to avoid a cold draft for the room occupants.)
- Under continuous operation with the airflow discharges horizontally (in Cool/Auto mode). (Discharges in the automatic set direction for a period of time to prevent condensation on the horizontal flap.)
- Under continuous operation with the airflow discharges downward (in Cool/Auto mode). (Discharges in the automatic set direction for a period of time to prevent condensation on the horizontal flap.)

# 6



- When the ON/OFF button is pressed again, the air conditioner will stop operating and the Operation lamp will turn off.



- \* When the air conditioner is stopped while in the Heating Operation, the fan will continue to operate for approximately 1 minute to remove residual heat from the indoor unit.

### Note

- To prevent water leakage or system failure, do not turn off the power immediately. Wait at least 5 minutes for the drain pump to finish draining residual water from the indoor unit.

## Characteristic of Cooling Operation (in Cool/Auto mode)

- When operating continuously at horizontally or downward airflow direction, air blows in the automatically set direction for a period of time to prevent condensation on the horizontal flap.  
(The remote controller displays the airflow direction that is set.)
- If the Cooling Operation is used when the room temperature is low, frost forms on the heat exchanger of the indoor unit. This can decrease the cooling capacity. In this case, the air conditioner automatically switches to the Defrost Operation for a while. During the Defrost Operation, the low airflow rate or a gentle wind is used to prevent the discharge of melt water.  
(The remote controller displays the airflow rate that is set.)
- When the outdoor air temperature is high, it takes some time until the room temperature reaches the set temperature.

## Characteristics of Heating Operation (in Heat/Auto mode)

### Starting Operation

- Heating Operation generally requires a longer time to reach the set temperature compared with Cooling Operation. It is recommended to start operating in advance by utilizing the timer.

### The air conditioner automatically controls the following operation to prevent the reduction of heating capacity and space comfort.

#### Defrost Operation (Frost removal operation for the outdoor unit)

- The air conditioner will automatically go into Defrost Operation to prevent frost accumulation at the outdoor unit and loss of heating capacity.
- The indoor unit fan will stop, and “❄️/🔥❄️” (Defrost/Hot start) will be displayed on the remote controller.
- The air conditioner will return to normal operation after approximately 6 to 8 minutes (Max 10 minutes).

#### Hot start

- When the air conditioner goes into Heating Operation or Defrost Operation, the indoor unit fan will stop in order to prevent a cold draft. (In that case, “❄️/🔥❄️” (Defrost/Hot start) will be displayed on the remote controller.)

## Regarding outdoor air temperature and heating capacity

- The heating capacity will drop with a decrease in outdoor air temperature.  
If the heating effect is insufficient, it is recommended to use another heating appliance in combination with the air conditioner.  
(When a combustion appliance is used, ventilate the room regularly.)  
Do not use the combustion appliance in places where the combustion appliance is exposed to the wind from the air conditioner.
- This air conditioner is a hot air circulation type to warm the whole room. Therefore, it takes some time for the room to become warm after the system starts operating.  
When the room temperature exceeds the set temperature, the indoor unit discharges a gentle breeze (switches to gentle wind). The airflow direction becomes horizontal.  
(The remote controller displays the airflow rate and airflow direction that are set.)
- If the hot air stays around the ceiling and your feet feel cold, the use of a circulator is recommended.  
For details, consult your local dealer.


## Dry Operation

### Preparation

- For mechanical protection purposes, turn on the power to the air conditioner at least 6 hours before starting the operation.
- Dry mode may not be selected if the remote controller has no eligibility to select cooling/heating mode (Refer to page 19 for details).

### Operation

1



- Press Mode Selector button several times until Dry mode is selected.



- \* Dry mode may not be available depending on the type of indoor unit.

2



- Press ON/OFF button.  
The Operation lamp (green) will be lit and the air conditioner will start operating.



- \* The air conditioner controls temperature and airflow rate automatically. Therefore, set temperature or airflow rate settings are not available while the air conditioner is in operation.

---

# 3

- To set airflow direction refer to page 11.

---

# 4



- When ON/OFF button is pressed again, the air conditioner will stop operating and the Operation lamp will be turned off.




### Note

- To prevent water leakage or system failure, do not turn off the power immediately. Wait at least 5 minutes for the drain pump to finish draining residual water from the indoor unit.

## Characteristics of Dry Operation

Dry mode repeats the weak cooling operation intermittently to dehumidify the room without dropping the room temperature as much as possible for the prevention of excessive cooling.



## Setback

The Setback function will maintain the room temperature in a specific range during unoccupied periods.

### Note

- This function will temporarily start an air conditioner that was previously turned off by the user or turned off from a schedule setting/off timer.
- This function is disabled by default. This function can be changed enable/disable by Main Menu. (Refer to page 34)

For example:

Setback temperature: cool 35°C, Heat 10°C
Recovery Differential: cool -2°C, Heat +2°C


- If the room temperature drops below 10°C, the air conditioner starts operating in Heating automatically. As soon as it reaches 12°C, the air conditioner returns to its original status.
- If the room temperature goes above 35°C, the air conditioner starts operating in Cooling automatically. As soon as it reaches 33°C, the air conditioner returns to its original status.


The differential can be adjusted in the Setback condition menu (Refer to page 36).

The setback temperature can be set on Basic screen during the air conditioner is turned off. Or the setback temperature can be set in the schedule (Refer to page 46).

**Operation** The setback cannot be enabled when a centralized control equipment is connected.

1



The Setback icon “” blinks when the air conditioner is turned on under the Setback control.


# Ventilation Operation When Air Conditioner Interlocked with Heat Reclaim Ventilator

## Preparation

- For equipment protection purposes, turn on the power to the air conditioner at least 6 hours before starting the operation.

## Operation

1



- Press Mode Selector button several times until Vent mode is selected.



- \* Vent mode is for single operation of Heat Reclaim Ventilator for the season when cooling/heating is unnecessary.

2

- The Ventilation mode can be changed from the Main Menu. (Refer to page 33).

- \* Ventilation mode: Auto, Energy Reclaim Ventilation and Bypass

3

- The Ventilation rate can be changed from the Main Menu. (Refer to page 32).

- \* Ventilation rate: Low or High

4



- Press ON/OFF button. The Operation lamp (green) will be lit and the Heat Reclaim Ventilator will start operating.



5



- When ON/OFF button is pressed again, the Heat Reclaim Ventilator will stop operating and the Operation lamp will be turned off.





# Setting the Cool/Heat Selection Eligibility


(VRV only)

Refer to “Cool/Heat Selection Eligibility” on page 19 for an explanation of the cool/heat selection eligibility.


## Setting Changes


1



- Press Mode Selector button on the remote controller that has cool/heat selection eligibility for at least 4 seconds. (During backlight lit)  
A remote controller will not display “” (Changeover Under Control) if a cool/heat selection eligibility is granted to the remote controller.



- The icon “” on each remote controller of indoor units connected to the same outdoor unit or BS unit will start blinking.



- \* Vent mode setting changes are possible regardless of the cool/heat selection eligibility.
- \* If a cool/heat selection eligibility is set in the “Cool/Heat selector” (★), all the remote controllers will display the icon “”. In this case, no cool/heat selection eligibility can be set in the remote controllers.
- ★Refer to the Operation Manual attached to the outdoor unit for the details of the “Cool/Heat selector”.



- Set a cool/heat selection eligibility as follows.

The icon “” (Changeover Under Control) will blink on all remote controllers when the power is turned on for the first time.

## Selection Settings

2





- Press Mode Selector button on the remote controller for which the selection eligibility to be set.  
Then the cool/heat selection eligibility will be set and the icon “” will disappear.  
The icon “” will appear on the other remote controllers.






# 3



- Press Mode Selector button on the remote controller that has the cool/heat selection eligibility (the remote controller without the icon “”) several times until the desired mode is selected.  
The display will change to “Fan”, “Dry”, “Auto”, “Cool”, “Heat” each time the button is pressed.
- The display “Auto” will appear for the Heat Recovery system only.  
Simultaneously, the other remote controllers will follow suit and change the display automatically.

## Cool/Heat Selection Eligibility


- The “Cool”, “Heat”, “Auto” can be set by only the remote controller that has the cool/heat selection eligibility.  
(The display “Auto” will appear for the Heat Recovery System only.)



## Precautions for Setting Cool/Heat Selection Eligibility

- The cool/heat selection eligibility needs to be set for a single remote controller in the following case.


### (Heat Pump System)



**A number of indoor units are connected to a single outdoor unit.**

Set the Cool/Heat/Fan mode selection eligibility in one of the remote controllers.

### (Heat Recovery System)




**A number of indoor units are connected to a single BS unit.**

Set the Cool/Heat/Auto/Fan mode selection eligibility in one of the remote controllers.

## Key Lock

**Operation** Make settings and cancel settings in the Basic screen.

1





Basic screen

- Continue pressing Menu/Enter button for at least 4 seconds. (During backlight lit)



2



- “” will appear.
- All buttons are disabled when the keys are locked.
- To cancel the Key lock, continue pressing Menu/Enter button for at least 4 seconds. (During backlight lit)

# Quick Reference of Main Menu Items

## ■ Main Menu Items

Setting and display items		Description	Reference page
<b>Circulation Airflow</b> (Note 1, 4)		Control Airflow and Air Direction automatic, and send Airflow to the room generally. When release from the Circulation Airflow, you can set except the Airflow - Air Direction to be "Auto" or set the Circulation Airflow as <b>Enable</b> .	26
<b>Air Flow Direction</b> (only if the individual airflow function is installed)	<b>Individual setting</b>	Used to set an Airflow direction for maximum 4 flaps individually. <ul style="list-style-type: none"> <li>• In case of Sprit system, maximum 4 units (unit A, B, C, D)</li> <li>• In case of VRV, maximum 16 units (unit 0 to 15)</li> </ul>	27
	<b>Individual setting list</b>	Used to see the table for setting for maximum 4 flaps.	28
	<b>Reset All Indivi Setting</b>	Used to clear all of the individual settings.	29
	<b>Airflow direction range</b> (only available for floor standing type indoor unit (FVQ series))	Auto swing direction is selectable from 3 patterns to suit the layout of the room. <b>Standard, Right blow or Left blow</b>	29
<b>Quick Start</b> (SPLIT system only)		Used to set the room to a comfortable temperature quickly (unless the system is not in Dry or Fan operation). <ul style="list-style-type: none"> <li>• The maximum quick cooling/heating operation period is 30 minutes.</li> </ul>	30
<b>Ventilation</b> (Ventilation operation settings for Heat Reclaim Ventilator)	<b>Ventilation Rate</b>	Used to set to <b>Low</b> or <b>High</b> .	32
	<b>Ventilation Mode</b>	Used to set <b>Automatic, Energy Reclaim Ventilation, and Bypass</b> .	33
<b>Energy Saving Options</b>	<b>Energy Saving List</b>	<b>Enable</b> or <b>Disable</b> can be set up about the following menus.	34
	<b>Setpoint Range</b>	The set temperature range can be restricted. It is possible to restrict the temperature range based on a model and the mode of operation.	35
	<b>Setback Condition</b>	Determine the point when air conditioner is turned off again from the setback control. (recovery differential).	36
	<b>Sensing Sensor (Low)</b> (only if the sensing sensor is installed) (Note 2, 3)	When no people are detected during a continuously fixed time, the function will automatically change the air conditioning target temperature. If people are detected, it will return to the normal set temperature.	37
	<b>Sensing Sensor (Stop)</b> (only if the sensing sensor is installed) (Note 2, 3)	When no people are detected during a continuously fixed time, the function will automatically stop the air conditioner.	38

Setting and display items		Description	Reference page
<b>Energy Saving Options</b>	<b>Setpoint Auto Reset</b>	Even if the set temperature is changed, it returns to the preset temperature after progress of a defined period of time.	39
	<b>Off Timer</b>	After you turn on the air conditioner, it will automatically turn off in a defined period of time. <ul style="list-style-type: none"> <li>• Possible to set in 10 minutes increments from 30 to 180 minutes.</li> </ul>	40
	<b>Auto Display Off (All series correspond)</b>	While operation stopping, can turn off the LCD display. It will be displayed again if press any button. <p><b>Note:</b> Can be selected 10 minutes, 30 minutes, 60 minutes, and OFF, initial setting is 30 minutes.</p>	41
	<b>Energy consumption</b>	An energy consumption until now is displayed. This enables you to evaluate the trend of the energy consumption. <p><b>Note:</b> This function availability is depending on type of indoor unit.</p> <p><b>Note:</b> This function is not available in case more than 1 indoor unit are connected in group to the remote controller.</p> <p><b>Note:</b> Displayed energy consumption is not result of a kWh measurement, but results from a calculation with running data of the air conditioner. Some factors in this calculation are absolute values, but other factors merely result from interpolations with tolerance. This explains why the readout may deviate from the actual electricity consumption.</p>	42
<b>Schedule</b>	<b>Enable/Disable</b>	Enable or Disable of a schedule function can be changed.	48
	<b>Select Schedule</b>	The schedule number that must be active can be selected (schedule nr 1, 2 or 3).	44
	<b>Holidays</b>	Convenient holiday settings and temporary closure settings are possible.	45
	<b>Settings</b>	<ul style="list-style-type: none"> <li>• Set the startup time and operation stop time.</li> <li>• ON: Startup time, cooling and heating setting temperature can be configured.</li> <li>• OFF: Operation stop time, cooling and heating setback setting temperature can be configured. (---: Indicates that the setback function is disabled for this time period.)</li> <li>_: Indicates that the setting temperature and setback setting temperature for this time period is not specified. The last active setting temperature will be utilized.</li> <li>• Up to 5 actions can be set for each day.</li> </ul>	46
<b>Filter Auto Clean</b>		This function is available only on the model whose panel has filter auto clean function. For detailed operation refer to the operation manual of these models.	49

Setting and display items		Description	Reference page
<b>Maintenance Information</b>		<b>Used to display the service contact and model information.</b>	50
<b>Configuration</b>	<b>Quiet Operation Mode &lt;Outdoor unit&gt;</b> (sky air only)	<b>Setting period of time to operate priority on the quiet operation sound.</b> <ul style="list-style-type: none"> <li>• Period of start operate quiet operation sound ~ finish is able to set in unit of 30 minutes.</li> </ul>	51
	<b>Auto Airflow</b> (only model that have human detection sensor)	When set this function, at Air Direction Automatic setting, when detected human, it can change air direction to blow human or avoid from human.	54
	<b>Draft Prevention</b> (only model that have human detection sensor)	The draft prevention function can be enabled or disabled.	55
	<b>Display</b>	<b>Used to set to standard or detailed display mode.</b> <ul style="list-style-type: none"> <li>• Display Standard or detailed display</li> <li>• Detailed display settings Selectable from the display room temperature, outdoor air temperature, system or None.</li> </ul>	56
	<b>Contrast Adjustment</b>	<b>Used to make LCD contrast adjustment.</b>	58
<b>Current Settings</b>		<b>Used to display a list of current settings for available items.</b>	59
<b>Clock &amp; Calendar</b>	<b>Date &amp; Time</b>	<b>Used to configure date and time settings and corrections.</b> <ul style="list-style-type: none"> <li>• The default time display is 24H.</li> <li>• The clock will maintain accuracy to within <math>\pm 30</math> seconds per month.</li> <li>• If there is a power failure for a period not exceeding 48 hours, the clock will continue working with the built-in backup power supply.</li> </ul>	60
	<b>12H/24H Clock</b>	The time can be displayed in either a 12 hour or 24 hour time format.	62
	<b>Daylight Saving Time</b> (Note 5)	Used to set Daylight Saving Time to ON or OFF.	63
<b>Language</b>		The displayed language can be selected from the following language. (English/Deutsch/Français/Italiano/Español/Português/Nederlands)	64

Note: 1. Available setting items vary with the model connected.

Only the available setting items appear in the menu.

2. This function cannot be used at the time of group control.

3. In case of the simultaneous operation system, the system is controlled by the sensing sensor mounted in the master indoor unit.


4. Indoor unit inside group is all possible to set only in case of correspond to this function.

5. This function can be used only when Daylight Saving Time is enable.

## Menu Items of Sub Remote Controller

If 2 remote controllers are in control of a single indoor unit, the following menu items are not set in the sub remote controller. Set them in the main remote controller.

- Circulation Airflow
- Air Flow Direction
- Energy Saving Options
- Schedule
- Setback
- Filter Auto Clean
- Auto Airflow




# Menu Manipulation

## Manipulating the Main Menu Screen

### ■ Display Method for Main Menu

#### Operation

1




Basic screen

- Press Menu/Enter button.



2




Main Menu screen

- The Main Menu screen will appear.

← Instructions for manipulating the buttons will appear.

3

- Select items from the Main Menu.
  1. Press “▼▲” buttons to select the desired item to be set.
  2. Press Menu/Enter button to display the selected settings screen.



4

- To go back to the Basic screen from the Main Menu screen, press the Cancel button.



### Caution

- While setting items, if a button is not pressed for 5 minutes, the screen will automatically go back to the Basic screen.


# Circulation Airflow

## ■ Circulation Airflow Setting Method


In case of air direction individual setting is disable, Circulation Airflow cannot be used. Depends on model that does not have Circulation Airflow function and combination between option part, will not display the Circulation Airflow.

### Operation


1




- Display the Main Menu screen (Refer to page 25).
- Press “▼▲” buttons to select **Circulation Airflow**. Press Menu/Enter button to display the Circulation Airflow screen.




2




- Press “▼▲” buttons to change the setting to **Disable** or **Enable**. Press Menu/Enter button after selecting the item. The confirmation screen will appear.



3




- Press “◀▶” buttons to select **Yes**. Press Menu/Enter button to confirm the settings and return to the Basic screen.



\* In case setting Circulation Airflow to be **Disable**, “Circulation” while operation of which Cooling · Heating · Auto will be displayed.

\* In case of group connection, it may take time until setting will be reflected.

\* In case of Circulation Airflow is setting as **Enable**, both Airflow · Air Direction when auto will be displayed as Auto.



is icon shows Auto.

### Note:

- Circulation Airflow when operation start, will be repeated mutually horizontal blow and downward blowing (Heating), swing (Cool/Heat). Unit will be judge automatically by temperature and time, and switch to normal the Airflow · Air Direction Auto operation. In this time, remote control screen will continue “Circulation”.
- In case would like to stop the Circulation Airflow operation while setting the Circulation Airflow disable, to press “Airflow/Air Direction” in the Basic screen, and change the Circulation Airflow again, to change both the Airflow · Air Direction from the Airflow/Air Direction setting screen to be **Auto**, or select **Disable** again from the Menu screen.




# Individual Air Direction

## ■ Individual Setting


### Operation

1




Main Menu screen

- Display the Main Menu screen (Refer to page 25).
- Select **Individual Air Direction** in the Main Menu.
- Press Menu/Enter button to display the Individual Air Direction settings screen.




2




- Select **Individual setting**.
- Press Menu/Enter button.




3




- Press “▼▲” buttons to select the unit and outlet mark.
- In case of four outlets, you can control each one of 4 flaps (ex. the following marks are beside each air outlet. □, □ □, □ □ □, □ □ □ □) individually.
- In case of SPLIT system, maximum 4 units (unit A, B, C, D) can be set.  
In case of VRV system, maximum 16 units for each group (unit 0 to 15) can be set.




4




- Press “▶” button to select airflow direction setting.
- Press “▼▲” buttons to change the following settings: **No Ind. Set** **Position 0** **Position 1** **Position 2** **Position 3** **Position 4** **Swing**.  
**No Ind. Set**: No Individual Setting.
- Press Menu/Enter button to confirm the settings and return to the Basic screen.



5




Basic screen


- If individual airflow direction is set, the Individual Airflow Direction icon “” is displayed in the Basic screen.


## ■ Individual Setting List

### Operation


1





- Display the Individual Air Direction screen (Refer to page 27).
- Press “▲” buttons to select **Individual Setting List**.
- Press Menu/Enter button.



2




- A table shows the current settings. Press “▲” buttons to go to the next unit.
- Press Cancel button to return to the Main Menu screen.




# Reset All Indivi Setting

## Operation


1




- Display the Individual Air Direction (Refer to page 27).
- Press “▼▲” buttons to select **Reset All Indivi Setting**.
- Press Menu/Enter button.



2






- Press “◀▶” buttons to select **Yes**.
- Press Menu/Enter button to confirm the reset and return to the Main Menu screen.




# Airflow Direction Range (Floor standing type indoor unit only)

- Air direction range can be selected by the remote controller depending on the installed location of the air conditioner.
- Air direction range has the following 3 patterns.




## Operation


1




- Display the Individual Air Direction screen (Refer to page 27).
- Press “▼▲” buttons to select **Airflow Direction Range**.
- Press Menu/Enter button.




2




- Press “▼▲” buttons to select the unit No..
- \*For simultaneous operation system, individual setup for each indoor unit is possible by connecting the remote controller to each unit at the time of installation.
- For the remote controllers with grouping connection, maximum 16 units (0-15 as unit number) are configurable.





# 3




- Press “▶” button to select air range setting.



- Set the desired air range from **Standard**, **Right Blow** or **Left Blow** by using “▼▲” buttons.



- Press Menu/Enter button to confirm the settings and return to the Basic screen.




## Quick Start (SPLIT system only)



### ■ Quick Start On

#### Operation

# 1



- While operating in Cooling, Heating, or Auto mode, display the Main Menu screen (Refer to page 25).
- Press “▼▲” buttons to select **Quick Start** on the Main Menu screen. Press Menu/Enter button to return to the Basic screen.





- “Quick Start” will appear on the Basic screen.
- Quick Start is now on.




# ■ Quick Start Off

## Operation

2



- While Quick Start is displayed on the Basic screen, display the Main Menu screen (Refer to page 25).
- Press “▼▲” buttons to select **Quick Start**. Press Menu/Enter button to return to the Basic screen.
- “Quick Start” will no longer appear on the Basic screen.
- Quick Start is now off.



## Quick Start

### Quick Start

The airflow rate of indoor unit is automatically controlled, increasing the capacity of the outdoor unit and quickly bringing the room to a comfortable temperature.


- Airflow rate display disappear and airflow rate can no longer be switched.
- Cannot be set when in fan and dry modes.
- Quick Start will operate for a maximum of 30 minutes before the air conditioner automatically returns to normal operation.
- Activating mode selector will return the air conditioner to normal operation.
- In heating mode, airflow rate will increase and the air outlet temperature may decrease. Adjust the operation as desired.

# Ventilation



## ■ Display Method for Ventilation Screen

### Operation

1




- Display the Main Menu screen. (Refer to page 25.)
  - Press “▼▲” buttons to select **Ventilation**. (For models with no ventilation function, **Ventilation** will not be displayed.)
- Press Menu/Enter button to display the Ventilation screen.




## ■ Changing the Ventilation Rate

### Operation


1



- Display the Ventilation settings screen (Refer to above).
- Press “▼▲” buttons to select **Ventilation Rate**. Press Menu/Enter button to display the Ventilation rate screen.



2




- Press “▼▲” buttons to change the setting to **Low** or **High**.

\* Only modes that can be set are displayed.



Low ↔ High

3




- Select the desired ventilation rate. Press Menu/Enter button to confirm the settings and return to the Basic screen. (Press Cancel button to return to the previous screen without changing the ventilation rate.)




# ■ Changing the Ventilation Mode

## Operation


1




- Display the ventilation screen. (Refer to page 32.)
- Press “▼▲” buttons to select **Ventilation Mode**. Press Menu/Enter button to display the Ventilation mode screen.




2




- Press “▼▲” buttons to change the settings in order as shown below.



\* Only modes that can be set are displayed.



3



- Select the desired ventilation mode. Press Menu/Enter button to confirm the settings and return to the Basic screen. (Press the Cancel button to return to the previous screen without changing the ventilation mode.)



## Ventilation Mode

### Automatic mode

Using information from the air conditioner (cooling, heating, fan and set temperature) and the Heat Reclaim Ventilator unit (indoor and outdoor air temperatures), mode is automatically changed between Energy reclaim ventilation and Bypass.

### Energy reclaim ventilation mode

Outdoor air is supplied to the room with undergoing heat exchange.

### Bypass mode



Outdoor air is supplied to the room without undergoing heat exchange.

# Energy Saving Options


## ■ Display Method for Energy Saving Options Screen

### Operation

1




- Display the Main Menu screen. (Refer to page 25.)
- Press “▼▲” buttons to select **Energy Saving Options**. Press Menu/Enter button to display the Energy Saving Options screen.




## ■ Energy Saving List

### Operation


1




- Display the Energy Saving Options screen (Refer to above).
- Press “▼▲” buttons to select **Energy Saving List**. Press Menu/Enter button to display the Energy Saving List screen.




2




- Press “▼▲” buttons to change the setting to **ON** or **OFF**. (**ON** : Enable, **OFF** : Disable)
- Press “◀▶” buttons to move the cursor. Press Menu/Enter button after selecting the item. The confirmation screen will appear.



3



- Press “◀▶” buttons to select **Yes** on the confirmation screen. Press Menu/Enter button to confirm the settings and return to the Basic screen.







# ■ Setpoint Range

## Operation


1




- Display the Energy Saving Options screen (Refer to page 34).
- Press “▼▲” buttons to select **Setpoint Range**. Press Menu/Enter button to display the Setpoint Range screen.




2




- Press “▼▲” buttons to change the temperature setting range of cooling and heating.
- Press “◀▶” buttons to move the cursor. Press Menu/Enter button after selecting the item. The confirmation screen will appear.



3




- Press “◀▶” buttons to select **Yes**. Press Menu/Enter button to confirm the settings and return to the Basic screen.




# ■ Setback Condition

## Operation


1




- Display the Energy Saving Options screen (Refer to page 34).
- Press “▼▲” buttons to select **Setback Condition**. Press Menu/Enter button to display the Setback Condition screen.




2




- Press “▼▲” buttons to change the temperature differential of the Setback.
- Press “◀▶” buttons to move the cursor. Press Menu/Enter button after selecting the item. The confirmation screen will appear.



3



- Press “◀▶” buttons to select **Yes**. Press Menu/Enter button to confirm the settings and return to the Basic screen.




# ■ Sensing Sensor (Low)

This function cannot be used at the time of group control.


In case of the simultaneous operation system, the system is controlled by the sensing sensor mounted in the master indoor unit.

## Operation


1



- Display the Energy Saving Options screen (Refer to page 34).
- Press “▼▲” buttons to select **Sensing Sensor (Low)**. Press Menu/Enter button to display the Sensing Sensor (Low) screen.



2




- Press “▼▲” buttons to change the setting value of saving energy operation when the sensor detects the absence.
- Press “◀▶” buttons to move the cursor. Press Menu/Enter button after selecting the item. The confirmation screen will appear.


(Example)

Adjust Cool SP	: 1.0°C
Adjust Time Cool	: 30 min
Limit Cool SP	: 30°C


- If it is determined that there is no person in the room by sensor during Cooling Operation, the set temperature will automatically shift by 1°C every 30 minutes until the set temperature is 30°C. (On Basic screen, set temperature does not change.)



3



- Press “◀▶” buttons to select **Yes**. Press Menu/Enter button to confirm the settings and return to the Basic screen.




# ■ Sensing Sensor (Stop)

This function cannot be used at the time of group control.


In case of the simultaneous operation system, the system is controlled by the sensing sensor mounted in the master indoor unit.

## Operation


1




- Display the Energy Saving Options screen (Refer to page 34).
- Press “▼▲” buttons to select **Sensing Sensor (Stop)**. Press Menu/Enter button to display the Sensing Sensor (Stop) screen.




2




- Press “▼▲” buttons to set the saving energy operation when the sensor detects the absence.
- Press “◀▶” buttons to move the cursor. Press Menu/Enter button after selecting the item. The confirmation screen will appear.



3




- Press “◀▶” buttons to select **Yes**. Press Menu/Enter button to confirm the settings and return to the Basic screen.




# ■ Setpoint Auto Reset

## Operation


1




- Display the Energy Saving Options screen (Refer to page 34).
- Press “▼▲” buttons to select **Setpoint Auto Reset**. Press Menu/Enter button to display the Setpoint Auto Reset screen.




2




- Press “▼▲” buttons to set preset temperature and timing for the auto reset of the setpoint.
- Press “◀▶” buttons to move the cursor. Press Menu/Enter button after selecting the item. The confirmation screen will appear.



3




- Press “◀▶” buttons to select **Yes**. Press Menu/Enter button to confirm the settings and return to the Basic screen.




# ■ Off Timer

## Operation


1




- Display the Energy Saving Options screen. (Refer to page 34.)
- Press “▼▲” buttons to select the **Off Timer**. Press Menu/Enter button to display the Off Timer screen.




2




- Press “▼▲” buttons to set the time from operation start until the unit automatically stops. Selections can be made in increments of 10 minutes from 30 to 180 minutes. Holding down the button causes the number to change continuously.
- Select the desired time and press Menu/Enter button. The confirmation screen will appear.



3




- Press “◀▶” button to select **Yes**. Press Menu/Enter button to confirm the Off Timer settings and return to the Basic screen.




# ■ Auto Display Off

## Operation


1




- Display the Energy Saving Options screen. (Refer to page 34.)
- Press “▼▲” buttons to select **Auto Display Off**. Press Menu/Enter button to display the Auto Display Off screen.




2




- Press “▼▲” buttons to set the Auto Display Off from **10 min**, **30 min**, **60 min** or **OFF**. Press Menu/Enter button after selecting the item. The confirmation screen will appear.



3




- Press “◀▶” button to select **Yes**. Press Menu/Enter button to confirm the settings and return to the Basic screen.




# Energy Consumption

**Operation** This item may not be available depend on the connecting model.




1



- Display the Energy Saving Options screen (Refer to page 34).
- Press “▼▲” buttons to select **Energy Consumption**. Press Menu/Enter button to display the Energy Consumption screen.




2



- Press “◀▶” buttons to move the indicating screen. Today > Yesterday > This week (1 week) > Last week (1 week) > This year (1 year) > Last year. Change the items and values located in the upper right of the indication area using “▼▲” buttons.

Press Cancel button to return to the previous screen.






# Schedule



## ■ Display Method for Schedule Screen

**Operation** The Schedule cannot be enabled when a centralized control equipment is connected.


1




- Display the Main Menu screen. (Refer to page 25.)
- Press “▼▲” buttons to select **Schedule**. Press Menu/Enter button to display the Schedule screen.




- Before setting the schedule, the clock must be set.
- If the clock has not been set, a screen like the one on the left will appear. Press “◀▶” buttons to select **Yes** and press Menu/Enter button.




- The Date & Time screen will appear.
- Set the current Year, Month, Day, and Time. (Refer to “Clock & Calendar” on page 60.)



2




- Press “▼▲” buttons to select the desired item on the Schedule screen and press Menu/Enter button.




# ■ Select Schedule

**Operation** This function can be stored in the schedule of 3 patterns.


1




- Display the Schedule screen. (Refer to page 43.)
- Press "▼▲" buttons to select **Schedule nr set**. Press Menu/Enter button to display the Schedule nr set screen.




2




- Press "▼▲" buttons to select **Schedule nr 1**, **Schedule nr 2**, or **Schedule nr 3**. Press Menu/Enter button after selecting the item. The confirmation screen will appear.



3



- Press "◀▶" buttons to select **Yes**. Press the Menu/Enter button to confirm the daily patterns in the schedule and return to the Basic screen.




# ■Holidays


(The schedule timer will be disabled for days that have been set as holiday.)

## Operation


1




- Display the Schedule screen. (Refer to page 43.)
- Press “▼▲” buttons to select **Holidays**. Press Menu/Enter button to display the Holiday setting screen.



2




- Press “◀▶” buttons to select the desired day. Press “▼▲” buttons to display “✓” to make the holiday settings. Press “▼▲” buttons to switch the setting between set and release.



Multiple days can be selected as holidays.

Note: To enable the schedule timer for the day selected as a holiday, the holiday setting must be released.


3





- To complete the holiday settings, press Menu/Enter button. The confirmation screen will appear.



4



- Press “▶” button to select **Yes**. Press Menu/Enter button to confirm the holiday settings and return to the Basic screen.




### Note:

- Holidays that are set will be displayed on the Schedule screen.


# ■ Schedule Settings

## Operation

1




- Display the Schedule screen. (Refer to page 43.)
- Press “▼▲” buttons to select **Settings**. Press Menu/Enter button to display the Schedule screen.




NOTE: The Schedule Settings of the selected schedule number can be changed. To change the schedule number refer to “Schedule Nr Set” on page 44.


2





- Press “▼▲” buttons to select the day of the week to be set.




3





- Set the time for the selected day.
- Press “◀▶” buttons to move the highlighted item and press “▼▲” buttons to set the desired time. Each press of “▼▲” buttons moves the numbers by 1 hour or 1 minute.



4



- Press the “◀▶” buttons to move the highlighted item and press “▼▲” buttons to configure ON/OFF/-- settings. --, ON, or OFF changes in sequence when “▼▲” buttons are pressed.



### “Act” column:

- ON : The set temperature can be configured.
- OFF: The setback temperature can be configured.
- : The set temperature and setback temperature become disabled.

Schedule nr 1				
	Time	Act	Cool	Heat
Mon	6:00	ON	28°C	21°C
	8:00	OFF	---	---
	---	---	---	---
	---	---	---	---
	---	---	---	---
		Return	Setting	↔

- The cooling and heating set temperature for both ON and OFF (Setback) are configured.

**“Cool” and “Heat” column:**

“—”: Indicates that the set temperature and setback temperature for this time period is not specified. The last active set temperature will be utilized.


“--”: Indicates that the setback function is disabled for this time period.

5

Schedule nr 1				
	Time	Act	Cool	Heat
Mon	6:00	ON	28°C	21°C
	8:00	OFF	35°C	10°C
	17:30	ON	28°C	21°C
	22:00	---	---	---
		Return	Setting	↔

A maximum of 5 actions per day can be set.

- Press the Menu/Enter button when settings for each day are completed. The confirmation screen will appear.



Schedule nr 1				
	Time	Act	Cool	Heat
Mon	6:00	ON	28°C	21°C
	8:00	OFF	35°C	10°C
	17:30	ON	28°C	21°C
	22:00	OFF	35°C	10°C
		Return	Setting	↔

Schedule nr 1				
	Time	Act	Cool	Heat
Tue	---	---	---	---
	---	---	---	---
	---	---	---	---
	---	---	---	---
		Return	Setting	↔

**Note:**

- To copy the settings for the previous day, press the Mode Selector button so that the existing settings will be copied.

Example: The contents for Monday are copied by pressing the Mode Selector button after selecting Tuesday.




Schedule nr 1				
	Time	Act	Cool	Heat
Tue	6:00	ON	28°C	21°C
	8:00	OFF	35°C	10°C
	17:30	ON	28°C	21°C
	22:00	OFF	35°C	10°C
	---	---	---	---
		Return	Setting	↔

6

Schedule	
Save the settings?	
Yes	No
Return      Setting	

- Press “◀▶” buttons to select **Yes**. Press the Menu/Enter button to confirm the settings for each day and return to the Basic screen.







## Enabling or disabling the schedule

### Operation


1




- Display the Schedule screen. (Refer to page 43.)
- Press “▼▲” buttons to select **Enable/Disable**. Press Menu/Enter button to display the Enable/Disable screen.



2




- Press “▼▲” buttons to select **Enable** or **Disable** on the Enable/Disable screen. Press Menu/Enter button after selecting the item. The confirmation screen will appear.




NOTE: The Schedule number selected is Enabled. To change the Schedule number see “Schedule Nr Set” on page 44.

3




- Press “◀▶” buttons to select **Yes**. Press Menu/Enter button to confirm the Enable/Disable setting for the schedule and return to the Basic screen.




# Filter Auto Clean

## Operation


1



- Display the Main Menu screen. (Refer to page 25.)
- Press “▼▲” buttons to select **Filter Auto Clean** and press Menu/Enter button.



2




- Filter Auto Clean time zone setting can be set.
- This function is available only on the model whose panel has Filter Auto Clean function.
- For detailed operation, refer to the operation manual of these models.

# Maintenance Information


## ■ Display Method for Maintenance Information

### Operation


1



- Display the Main Menu screen. (Refer to page 25.)
- Press “▼▲” buttons to select **Maintenance Information** and press Menu/Enter button.



2



- The phone number for the contact is displayed at the top of the screen. (If it has not yet registered by installer, it will not displayed.)
  - The model name of the indoor and outdoor units of your product will be displayed on the bottom of the screen. (For some models the product code may be displayed instead of model name.)
- \* The model name will not displayed if the Printed Circuit Board of the air conditioner has been replaced.

- \* The Malfunction (Error) code history may also be displayed. If it is not blinking, the unit is working properly. The Malfunction (Error) code history is no longer displayed if you press ON/OFF button for more than 4 seconds.






# Configuration


## ■ Display Method for Configuration Screen

### Operation

1




- Display the Main Menu screen. (Refer to page 25.)
- Press “▼▲” buttons to select **Configuration**. Press Menu/Enter button to display the Configuration screen.





## ■ Quiet Operation Mode <Outdoor unit> (SkyAir only)

### Operation



1




- Display the Configuration screen. (Refer to above.)
- Press “▼▲” buttons to select **Quiet Operation Mode**. Press Menu/Enter button to display the Quiet Operation Mode screen.




- Before setting the Quiet Operation Mode, the clock must be set.
- If the clock has not been set, a screen like the one on the left will appear. Press “◀▶” buttons to select **Yes** and press Menu/Enter button
- The Date & Time screen will appear.
- Set the current Year, Month, Day and Time. (Refer to “Clock & Calendar” on page 60.)




2




- Press “▼▲” buttons to select **Settings**. Press Menu/Enter button to display the Quiet Operation Mode screen.




3




- Press “◀▶” buttons to select the Start time or Finish time.  
Press “▼▲” buttons to set the Start time, can set by unit of 30 minutes.  
If continue pressing, it will change continuously.




4




- Press “◀▶” buttons to select the Finish time.  
Press “▼▲” buttons to set the Finish time, can set by unit of 30 minutes.  
If continue pressing, it will change continuously.
- Press Menu/Enter button after selecting the item.  
The confirmation screen will appear.



5



- Press “◀▶” buttons to select **Yes**.  
Press the Menu/Enter button to confirm the Quiet Operation Mode settings and return to the Basic screen.







## Enabling or disabling the Quiet Operation Mode

### Operation


1





- Display the Quiet Operation Mode screen. (Refer to page 51.)
- Press “▼▲” buttons to select **Enable/Disable**. Press Menu/Enter button to display the Enable/Disable screen.



2



- Press “▼▲” buttons to select **Enable** or **Disable** on the Enable/Disable screen. Press Menu/Enter button after selecting the item. The confirmation screen will appear.
- Press “◀▶” buttons to select **Yes**. Press Menu/Enter button to confirm the Enable/Disable setting for the Quiet Operation Mode and return to the Basic screen.




# ■ Auto Airflow


## Cool and Heat Condition setting method

**Operation** Menu will be displayed only corresponded model.


1




- Display the Configuration screen. (Refer to page 51.)
- Press “▼▲” buttons to select **Auto Airflow**. Press Menu/Enter button to display the Active Draft screen.



2




- Press “▼▲” buttons to select **Cool Condition**. Press Menu/Enter button to display the Condition Setting screen.





\* In case of heating, select the Heat Condition

3




- Press “▼▲” buttons to select **OFF**, **Draft Prevention** or **Direct Air**. Press Menu/Enter button after selecting the item. The confirmation screen will appear.
- Press “◀▶” buttons to select **Yes**. Press Menu/Enter button to confirm the enable/disable setting for the Auto Airflow and return to the Basic screen.




# ■ Draft Prevention

## Operation


1




- Display the Configuration screen. (Refer to page 51.)
- Press “▼▲” buttons to select **Draft Prevention**. Press Menu/Enter button to display the Draft Prevention screen.




2




- Press “▼▲” buttons to select **Enable** or **Disable**. Press Menu/Enter button after selecting the item. The confirmation screen will appear.



3



- Press “◀▶” buttons to select **Yes**. Press Menu/Enter button to confirm the Enable/Disable setting for the Draft Prevention and return to the Basic screen.




# ■ Display

## Display Mode


### Operation

---


1




- Display the Configuration screen.  
(Refer to page 51.)
- Press “▼▲” buttons to select **Display**.  
Press Menu/Enter button to display the Display screen.



2




- Press “▼▲” buttons to select **Display Mode**.  
Press Menu/Enter button to display the Display Mode screen.



3




- Press “▼▲” buttons to select **Standard** or **Detailed**.
- Then, press Menu/Enter button to confirm settings and return to the Basic screen.




# Setting the detailed display item selection

## Operation


1




- Display the Display screen. (Refer to page 56.)
- Press “▼▲” buttons to select **Display Item**. Press Menu/Enter button to display the Display Item screen.



2



- Press “▼▲” buttons to display the following.



\* Some models may not display these items even if they are selected.

- Be sure to read the following notes regarding display of room temperature and outdoor air temperature.

### Room Temp

..... The temperature detected near the remote controller.  
 The temperature may be affected by the location of the remote controller.

### Outside Air Temp

..... The temperature detected near the outdoor unit.  
 The temperature may be affected by factors such as the location of the outdoor unit (in direct sunlight, e.g.) and unit operation during defrosting.


- After setting, press Menu/Enter button to confirm settings and return to the Basic screen.



# ■ Contrast Adjustment

## Operation

1




• Display the Configuration screen. (Refer to page 51.)


• Press “▼▲” buttons to select

### **Contrast Adjustment.**

Press Menu/Enter button to display the Contrast Adjustment screen.




2



• On the Contrast Adjustment screen, press “▼▲” buttons until you reach the desired contrast.

After setting, press Menu/Enter button and return to the Basic screen.






# Current Settings


## ■ Manipulating the Current Settings

### Operation


1




- Display the Main Menu screen. (See page 25.)
- Press “▼▲” buttons to select **Current Settings** and press Menu/Enter button.



2



- A list of the current setting status will appear. Press “◀▶” buttons to go to the next item.
- Press Cancel button to return to the Main Menu screen.



#### Display items

Circulation Airflow	Quick Start
Ventilation Rate	Quiet Operation Mode
Ventilation Mode	Display Mode
Schedule	Display Item
Auto Display Off	Filter Auto Clean


\* Display items may differ depending on the model.  
Only the items that can be set are displayed.

# Clock & Calendar


## ■ Display Method for Clock & Calendar Screen

### Operation

1




- Display the Main Menu screen. (Refer to page 25.)
- Press “▼▲” buttons to select **Clock & Calendar**. Press Menu/Enter button to display the Clock & Calendar screen.




## ■ Date & time

### Operation


1




- Display the Clock & Calendar screen. (Refer to above.)
- Press “▼▲” buttons to select **Date & Time**. Press Menu/Enter button to display the Date & Time screen.




2




- Select “Year” with “◀▶” buttons. Change the year with “▼▲” buttons. Holding down the button causes the number to change continuously.



3




- Select “Month” with “◀▶” buttons. Change the month with “▼▲” buttons. Holding down the button causes the number to change continuously.




---

# 4




- Select “Day” with “◀▶” buttons.  
Change the day with “▼▲” buttons.  
Holding down the button causes the number to change continuously.  
Days of the week change automatically.




---

# 5




- Select “Hour” with “◀▶” buttons.  
Change the hour with “▼▲” buttons.  
Holding down the button causes the number to change continuously.




---

# 6




- Select “Minute” with “◀▶” buttons.  
Change the minute with “▼▲” buttons.  
Holding down the button causes the number to change continuously.
- Press Menu/Enter button.  
The confirmation screen will appear.




---

# 7



- Press “◀▶” button to select **Yes**.  
Press Menu/Enter button to confirm the clock and return to the Basic screen.


\* When setting the schedule, the display returns to the Schedule screen.




# ■ 12H/24H Clock

## Operation


1




- Display the Clock & Calendar screen. (Refer to page 60)
- Press “▼▲” buttons to select **12H/24H Clock**. Press Menu/Enter button to display the 12H/24H Clock screen.




2




- By default, the time display is set to the 24H format.
- Press “▼▲” buttons to select **12H** or **24H**.
  - Press Menu/Enter button after selecting the item. The confirmation screen will appear.



3




- Press “◀▶” buttons to select **Yes**. Press the Menu/Enter button to confirm the 12H or 24H and return to the Basic screen.



# ■ Daylight Saving Time


## Operation

1



- Display the Clock & Calendar screen. (Refer to page 60.)
- Press “▼▲” buttons to select **Daylight Saving Time**.


Press Menu/Enter button to display the Daylight Saving Time screen.




2




- Press “▼▲” buttons to select **ON** or **OFF**.
- Press Menu/Enter button after selecting the item. The confirmation screen will appear.



3



- Press “◀▶” buttons to select **Yes**. Press the Menu/Enter button to confirm the Daylight Saving Time and return to the Basic screen.




# Language


## ■ Selectable Languages

### Operation


1




- Display the Main Menu screen. (Refer to page 25.)
- Press “▼▲” buttons to select **Language** and press the Menu/Enter button.



2



- Press “▼▲” buttons to select the preferred language from following.  
English/Deutsch/Français/Italiano/Español/  
Português/Nederlands
- Press Menu/Enter button to confirm settings and return to the Basic screen.




# Maintenance

## Reset Filter Indicator

### Operation

1



- When the time to clean the filter or element has come, one of the following messages will appear on the bottom of the Basic screen.  
“Time to clean filter”  
“Time to clean filter & element”  
“Time to clean element”


- Wash, clean, or replace the filter or element.  
For details, refer to the operation manual attached to the indoor unit.

2



- Reset the filter indicator when the filter or element is washed, cleaned, or replaced.
- Press Menu/Enter button.  
The Main Menu screen will appear.



3



- Press “▼▲” buttons to select **Reset Filter Indicator** and press Menu/Enter button.



- The message shown in Step 1 will disappear from the Basic screen.



## Caution

- **Do not wash the remote controller.**  
Doing so may cause electric leakage and result in electric shocks or a fire.
  - **Be sure to stop the operation of the air conditioner and turn off the power at the time of maintenance.**  
Failure to do so may result in electric shocks or injury.
- 

## Cleaning of Remote Controller

- Wipe the surface part of the remote controller with a dry cloth when it become dirty.
- If the dirt on the surface cannot be removed, soak the cloth in neutral detergent diluted with water, squeeze the cloth tightly, and clean the surface. Wipe the surface with a dry cloth then.

### Note

- Do not use any paint thinner, organic solvent, or strong acid.



## Warning

- **Do not use flammable materials (e.g., hairspray or insecticide) near the air conditioner.**  
**Do not clean remote controller with organic solvents such as benzine or paint thinner.**  
The use of organic solvents may cause crack damage to the product, electric shocks or a fire.
-



# Reference Information

## Malfunction (Error) Code Display

### Contact Your Dealer in the Following Cases


#### Warning

- **When the air conditioner is malfunctioning (e.g., giving off a burning odor), stop the air conditioner and turn off the power.**

Continued operation under such circumstances may result in failure, electric shocks or a fire. Contact your local dealer.

#### Operation

1



- If a malfunction occurs, either one of the following messages will appear on the Basic screen during operation.


“Error: Push Menu button.”

\* The Operation lamp will blink.


“Warning: Push Menu button.”

\* The Operation lamp will not blink.

- Press Menu/Enter button.



2



- The Error code blinks and the contact address and model name will appear.
- Notify your local dealer of the Error code and Model name.

# After-sales Service



## Warning

- **Do not disassemble, modify, or repair the remote controller.**  
It may cause electric shocks or a fire.  
Consult your local dealer.
- **Do not relocate or reinstall the remote controller by yourself.**  
Improper installation may cause electric shocks or a fire.  
Consult your local dealer.

## ■ Advise the Repairer of the Following Items


- Model name
- Date of installation
- Failure conditions: As precise as possible.
- Your address, name, and telephone number

## ■ Relocation

The relocation of the remote controller requires special technology. Consult your local dealer. Actual expenses required for the relocation of the remote controller will be charged.

## ■ Inquiry about After-sales Service

Contact your local dealer.





# ***DAIKIN INDUSTRIES, LTD.***

Head office:

Umeda Center Bldg., 2-4-12, Nakazaki-Nishi,  
Kita-ku, Osaka, 530-8323 Japan

Tokyo office:

JR Shinagawa East Bldg., 2-18-1, Konan,  
Minato-ku, Tokyo, 108-0075 Japan  
[http://www.daikin.com/global\\_ac/](http://www.daikin.com/global_ac/)



## Comprehensive Maintenance Activities

### **BENEFITS** from regular / scheduled preventative maintenance:

1. *Increase energy efficiency – in turn decreasing energy consumption*
2. *Increase system performance – Revitalise & Refresh system capacity*
3. *Improves the air quality – Reducing illness & respiratory problems*
4. *Improves the overall cleanliness & appearance of the system*
5. *Improves system longevity – Increase system lifespan*
6. *Can pick up potential problems before they create costly damages*

### **ACTIVITIES** carried out during preventative maintenance include:

1. *Check refrigerant gas pressures and operating temperatures*
2. *Check reversing valve operation (heating & cooling modes)*
3. *Check fan rotation, mountings and bolts*
4. *Clean indoor unit casing, louvers & filters*
5. *Clean indoor fan barrel to ensure maximum air flow*
6. *Clean indoor coil with acid based solution to remove mould & bacteria*
7. *Treat indoor coil with an anti-bacterial Tea Tree deodorant*
8. *Clean large debris from outdoor coil*
9. *Clean and flush drains from build-up and blockages*
10. *Clean & check all electrical systems and PC boards, ensuring safe operations*

### **PORT CITY AIRCONDITIONING** employs experienced & professional refrigeration mechanics trained to:

1. *Complete system maintenance within 30 – 40 minutes*
2. *Utilise drop sheets and a vacuum to ensure no mess*
3. *Leave the establishment exactly how they found it*
4. *Inform client of any repairs required before commencing*



# Chiller

Detail code		0	1	2	3	4	5	6	7	8	9	A	C	E	F	H	J	
Division																		
Indoor Unit	A		Malfunction of indoor unit PCB			Malfunction of freezing protection					Malfunction of electronic expansion valve	Malfunction of electronic expansion valve						
	C					Malfunction of liquid pipe thermistor for heat exchanger	Malfunction of gas pipe thermistor for heat exchanger											
Outdoor Unit	E	Protection devices activated (unified)	Defect of outdoor unit PCB	Missing of earth leakage detection core	Actuation of high pressure switch (HPS)	Actuation of low pressure switch (LPS)	Inverter compressor motor or overheat	STD compressor motor overcurrent/lock	Malfunction of outdoor unit fan motor system	Overcurrent of inverter compressor	Malfunction of electronic expansion valve coil							
	F				Malfunction of discharge pipe temperature								Abnormal high pressure actuation of HPS					
	H	Malfunction of sensor system of compressor	Malfunction of room temperature sensor or humidifier unit damper	Malfunction of power supply sensor	Malfunction of high pressure switch (HPS)	Malfunction of low pressure switch (LPS)	Malfunction of compressor motor overload thermistor	Malfunction of position detection sensor	Malfunction of outdoor unit fan motor signal	Malfunction of compressor input (CT) system	Malfunction of outdoor air thermistor	Malfunction of discharge air thermistor	Malfunction of (hot) water temperature thermistor					
	U	Miswiring of thermistor	Malfunction of pressure sensor	Malfunction of current sensor of compressor	Malfunction of discharge pipe thermistor	Malfunction of low pressure equivalent saturated temperature sensor system	Malfunction of suction pipe thermistor	Malfunction of heat exchanger thermistor	Malfunction of thermistor (Refrigerant circuit)	Malfunction of thermistor (Refrigerant circuit)	Malfunction of thermistor (Refrigerant circuit)	Malfunction of high pressure sensor	Malfunction of low pressure sensor					
	L	Malfunction of inverter system	Malfunction of inverter PCB		EI. compo. box temperature rise	Malfunction of inverter radiation fin temperature rise	Inverter instantaneous overcurrent (DC output)	Inverter instantaneous overcurrent (AC output)	Total input overcurrent	Malfunction of overcurrent inverter compressor	Malfunction of inverter compressor startup error (Stall prevention)	Malfunction of power transistor	Malfunction of transmission between control and inverter PCB					
	P	Shortage of refrigerant amount (thermal storage unit)	Power voltage imbalance or inverter PCB	Automatic refrigerant charge operation stop	Reactor temperature abnormality	Malfunction of radiation fin temperature sensor												Improper combination between inverter and fan driver
System	U	Shortage of refrigerant	Reverse phase, open phase	Malfunction of power supply or instantaneous power failure	Check operation not executed or transmission error	Malfunction of transmission between indoor and outdoor unit	Malfunction of transmission between indoor unit and remote controller	Malfunction of transmission between indoor units	Malfunction of transmission between outdoor units or outdoor storage unit	Malfunction of transmission between remote controllers	Malfunction of transmission (other system)	Improper combination of indoor and outdoor units	Malfunction of setting of centralized control equipment address	Malfunction of transmission between indoor unit and centralized control equipment			Malfunction of transmission (accessory device)	
Others	7	System No. 2 Compressor overheat	System No. 2 Compressor overcurrent	System No. 2 Fan motor overcurrent	System No. 2 Actuation of high pressure switch (HPS)	System No. 2 Actuation of low pressure switch (LPS)	System No. 2 Malfunction of low pressure sensor	System No. 2 Malfunction of high pressure sensor	System No. 1 Malfunction of fan inter lock	System No. 2 Malfunction of fan inter lock		System No. 2 Malfunction of compressor current sensor	Malfunction of pump inter lock					
	8	Malfunction of entering water temperature thermistor	Malfunction of leaving water temperature thermistor or drain pipe heater	System No. 1 Malfunction of refrigerant thermistor	System No. 2 Malfunction of refrigerant thermistor	System No. 1 Malfunction of heat exchanger thermistor	System No. 2 Malfunction of heat exchanger thermistor	System No. 1 Malfunction of discharge pipe thermistor	System No. 2 Malfunction of discharge pipe temperature	Malfunction of brazed-plate heat exchanger freezing	Malfunction of dehumidification or leaving water temperature thermistor		System No. 1 Malfunction of suction pipe thermistor 1 for heating	System No. 1 Malfunction of suction pipe thermistor 2 for heating	Abnormal hot water high temperature			
	9	Abnormal chilled water quantity or abnormal AXP	System No. 2 Malfunction of electronic expansion valve	System No. 2 Malfunction of suction pipe thermistor			System No. 1 Malfunction of inverter system	System No. 2 Malfunction of inverter system	Malfunction of thermal storage unit	Malfunction of thermal storage brine pump	Malfunction of thermal storage brine tank		System No. 2 Malfunction of suction pipe thermistor 1 for heating	System No. 2 Malfunction of suction pipe thermistor 2 for heating				

# Fan Coil

Detail code		0	1	2	3	4	5	6	7	8	9	A	C	E	F	H	J
Division																	
Indoor Unit	A				Malfunction of drain level system	Malfunction of freezing protection										Malfunction of dust collector of air cleaner	
	C					Malfunction of liquid pipe thermistor for heat exchanger					Malfunction of suction air thermistor						Malfunction of thermostat sensor in remote controller
System	U		Reverse phase, open phase	Malfunction of power supply or instantaneous power failure	Check operation not executed or transmission error	Malfunction of transmission between indoor and outdoor unit	Malfunction of transmission between indoor unit and remote controller	Malfunction of transmission between indoor units	Malfunction of transmission between outdoor units or outdoor storage unit	Malfunction of transmission between remote controllers	Malfunction of transmission (other system)	Improper combination of indoor and outdoor units	Malfunction of setting of centralized control equipment address	Malfunction of transmission between indoor unit and centralized control equipment			
	M		Malfunction of central remote controller PCB								Malfunction of transmission between optional controllers for centralized control	Improper combination of optional controllers for centralized control	Address duplication, improper setting				



# Simple Self-Diagnosis by Malfunction Code

Malfunction code	Malfunction Contents	Supposed causes	Objects						
			RA	SkyAir	VRV	Package	Heat reclaim ventilator	Chiller	Fan Coil
<b>R0</b>	External protection device activated	External protection device connected to the terminal strip T1-T2 of indoor unit is activated		○	○	○			
<b>R1</b>	Malfunction of indoor unit PCB	Defective indoor unit PCB External factor (Noise etc.)	○	○	○	○	○	○	
<b>R3</b>	Drain Level Control System Abnormality	Drain clogging, upward slope, etc. Defective drain pump Defective float switch or short circuit connector	○	○	○		○	○	
<b>R4</b>	Malfunction of freezing protection	Shortage of water volume Low water temperature setting Defective water temperature thermistor	○	○	○	○		○	○
<b>R5</b>	High pressure control in heating, freeze-up protection control in cooling	Clogged air filter of indoor unit and short circuit Defect of indoor unit heat exchanger thermistor	○	○	○	○			
<b>R6</b>	Malfunction of fan motor	Broken wires in, short circuit of, or disconnection of connectors from the fan motor harness Defective fan motor Defective indoor unit PCB	○	○	○	○	○		
<b>R7</b>	Malfunction of swing flap motor	Defective swing flap motor Defective indoor unit PCB Defective connection cable Defective airflow direction adjusting flap-cam		○	○				
<b>R8</b>	Malfunction of power supply or AC input overcurrent	Defective power supply voltage Defective connection on signal line Defective wiring		○	○		○		
<b>R9</b>	Malfunction of electronic expansion valve	Defective electronic expansion valve coil Defective indoor unit PCB Defective relay cables		○	○	○	○	○	
<b>RR</b>	Heater overheat	26WH is activated				○		○	
<b>RF</b>	Malfunction of a humidifier system	Humidifier unit (optional accessory) leaking Defective drain piping (upward slope, etc.) Defective indoor unit PCB			○	○			
<b>RH</b>	Malfunction of dust collector of air cleaner	Defect of dust collecting element Stained insulator part Defect of high voltage power supply unit Defect of indoor unit PCB	○	○	○				○
<b>RU</b>	Malfunction of capacity setting (Indoor unit PCB)	The capacity setting adaptor was not installed when replacing PCB. Defective indoor unit PCB		○	○	○			
<b>C1</b>	Failure of transmission (between indoor unit PCB and sub PCB)	Defective connection of the connector between indoor unit PCB		○	○				
<b>C4</b>	Malfunction of liquid pipe thermistor for heat exchanger	Defective thermistor for liquid pipe Defective indoor unit PCB Defective connector contact	○	○	○	○	○	○	○
<b>C5</b>	Malfunction of gas pipe thermistor for heat exchanger	Defective thermistor for gas pipe Defective indoor unit PCB Defective connector contact	○	○	○	○	○	○	○
<b>C6</b>	Malfunction of fan motor sensor or fan control driver	Defective fan PCB Defective connection of capacity setting adaptor Field setting error		○	○				
<b>C7</b>	Front panel driving motor fault	Defective front panel driving motor Defective limit switch	○						
<b>C9</b>	Malfunction of suction air thermistor	Defective thermistor for suction air Defective indoor unit PCB Defective connector contact	○	○	○	○	○		○
<b>CR</b>	Malfunction of discharge air thermistor	Defective thermistor for discharge air Defective indoor unit PCB Defective connector contact	○	○	○	○			
<b>CC</b>	Malfunction of humidity sensor system	Defective humidity sensor Defective connector contact	○	○		○			
<b>CU</b>	Room temperature thermistor in remote controller abnormality	Defective room temperature thermistor in remote controller Defective remote controller PCB External factor (Noise etc.)	○	○	○	○			○

Malfunction code	Malfunction Contents	Supposed causes	Objects						
			RA	SkyAir	VRV	Package	Heat reclaim ventilator	Chiller	Fan Coil
<b>E0</b>	Protection devices activated (unified)	Protection device connected to outdoor unit PCB actuated Defective protection device connector contact		○	○				○
<b>E1</b>	Defective outdoor unit PCB	Defective outdoor unit PCB Defective connection of inside/ outside relay wires	○	○	○	○			○
<b>E3</b>	Actuation of high pressure switch (HPS)	Dirty outdoor unit heat exchanger Defective high pressure switch Clogged refrigerant piping Defective connector contact	○	○	○	○			
<b>E3</b>	System No.1 Actuation of high pressure switch (HPS)	Dirty outdoor unit heat exchanger Shortage of water volume Clogged refrigerant piping Defective connector contact Defective HPS							○
<b>E4</b>	Actuation of low pressure switch (LPS)	Abnormally drop in low pressure Defective low pressure sensor Defective outdoor unit PCB Defective connector contact		○	○	○			○
<b>E5</b>	Inverter compressor motor or overheat	Inverter compressor lock High differential pressure Defective inverter PCB UVW connection error Defective connector contact	○	○	○	○			○
<b>E6</b>	STD compressor motor overcurrent/lock	Defective compressor Defective control PCB The stop valve is not opened	○	○	○	○			
<b>E6</b>	System No.1 Compressor overcurrent	Defective electronic expansion valve Shortage of refrigerant amount Defective compressor							○
<b>E7</b>	Malfunction of outdoor unit fan motor system	Fan motor failure Neglect to connect or defective connection of harness/ connector between the fan motor and the PCB Fan does not rotate due to foreign matters caught in it	○	○	○	○			○
<b>E8</b>	Overcurrent of inverter compressor	Defective compressor Defective inverter main circuit capacitor Defect of outdoor unit PCB Defect of power transistor	○						○
<b>E9</b>	Malfunction of electronic expansion valve coil	Disconnection of connectors from electronic expansion valves Defective electronic expansion valve coil Defective outdoor unit control PCB		○	○	○			○
<b>E9</b>	Malfunction of four way valve or cool/heat switchin	Defective four way valve Shortage of gas Defective outdoor unit PCB Defective thermistor	○						
<b>E0</b>	Malfunction of entering water temperature	Cooling water temperature abnormality Defective outdoor unit PCB Defective thermistor			○				
<b>F3</b>	Malfunction of discharge pipe temperature	Defective discharge pipe thermistor Abnormal discharge pipe temperature Defective outdoor unit control PCB Defective connector contact	○	○	○	○			○
<b>F6</b>	Abnormal high pressure or refrigerant overcharged	Refrigerant overcharged Disconnection of heat exchanger deicer thermistor Disconnection of outdoor air thermistor Disconnection of liquid pipe temperature thermistor Defective outdoor unit PCB	○	○	○	○			
<b>H0</b>	Malfunction of sensor system of compressor	Harness is disconnected, or defective connection Defective PCB	○						○
<b>H1</b>	Malfunction of room temperature sensor or humidifier unit damper	Defective limit switch Defective damper	○						○
<b>H3</b>	Malfunction of high pressure switch (HPS)	Defective high pressure switch Broken wire Defective outdoor unit PCB Defective connector contact	○	○	○	○			○
<b>H4</b>	Malfunction of low pressure switch (LPS)	Defective low pressure switch Broken wire Defective outdoor unit PCB Defective connector contact		○	○				○

# Simple Self-Diagnosis by Malfunction Code

Malfunction code	Malfunction Contents	Supposed causes	Objects						
			RA	SkyAir	VRV	Package	Heat reclaim ventilator	Chiller	Fan Coil
H5	Malfunction of compressor motor overload thermistor	Defect of compressor motor overload thermistor Defective connector contact	○					○	
H6	Malfunction of position detection sensor	Faulty contact of compress or cable Defective compressor Defective outdoor unit PCB	○			○			○
H7	Malfunction of outdoor unit fan motor signal	Abnormal signal from fan motor (Circuit failure) Disconnection/Short circuit in fan motor leads or disconnection of connector Defective inverter PCB		○	○	○			○
H8	Malfunction of compressor input (CT) system	Defective power transistor Defective reactor Faulty wiring of inverter system Defective outdoor unit PCB	○						○
H9	Malfunction of outdoor air thermistor	Defective connection of thermistor Defective outdoor unit PCB Defective outdoor air thermistor	○	○	○	○			○
HC	Malfunction of (hot) water temperature thermistor	Defective connection of thermistor Defective outdoor unit PCB Defective water temperature thermistor		○	○				○
HF	Alarm in thermal storage unit or storage controller	Thermal storage group defective wiring Defective setting Excess of thermal storage tank numbers			○				
HU	Malfunction of thermal storage tank water level	Low water level Defective switch setting Water level detecting sensor failure Defective connector contact	○	○	○	○			
J1	Malfunction of pressure sensor	Defective pressure sensor connector contact Defective pressure sensor Defective outdoor unit PCB			○	○			○
J2	Malfunction of current sensor of compressor	Defective current sensor Defective compressor Defective outdoor unit PCB	○	○	○	○			○
J3	Malfunction of discharge pipe thermistor	Defective connection of thermistor Defective discharge pipe thermistor Defective outdoor unit PCB	○	○	○	○			○
J4	Malfunction of low pressure equivalent saturated temperature sensor system	Defective connection of thermistor Defective thermistor Defective outdoor unit PCB			○				○
J5	Malfunction of suction pipe thermistor	Defective connection of thermistor Defective suction pipe thermistor Defective outdoor unit PCB		○	○	○			○
J6	Malfunction of heat exchanger thermistor	Defective connection of thermistor Defective heat exchanger thermistor Defective outdoor unit PCB	○	○	○	○			○
J7	Malfunction of thermistor (Refrigerant circuit)	Defective connection of thermistor Defective liquid pipe thermistor Defective outdoor unit PCB			○	○			○
J8	Malfunction of thermistor (Refrigerant circuit)	Defective connection of thermistor Defective liquid pipe thermistor Defective outdoor unit PCB	○	○	○	○			○
J9	Malfunction of thermistor (Refrigerant circuit)	Defective connection of thermistor Defective gas pipe thermistor Defective outdoor unit PCB	○	○	○	○			○
JA	Malfunction of high pressure sensor	Defective connector contact Connection of low pressure sensor in mistake for high pressure sensor Defective high pressure sensor Defective outdoor unit PCB		○	○	○			○
JE	Malfunction of low pressure sensor	Defective connector contact Connection of high pressure sensor in mistake for low pressure sensor Defective low pressure sensor Defective outdoor unit PCB		○	○	○			○

Malfunction code	Malfunction Contents	Supposed causes	Objects						
			RA	SkyAir	VRV	Package	Heat reclaim ventilator	Chiller	Fan Coil
JE	Malfunction of oil pressure sensor or sub-tank thermistor	Defective connector contact Defective sub-tank thermistor Defective outdoor unit PCB			○				
JF	Malfunction of oil level sensor or heating heat exchanger thermistor	Defective connector contact Defective heat exchanger thermistor Defective outdoor unit PCB			○				
LG	Malfunction of inverter system	Shortage of power supply capacity Defective power transistor Defective outdoor unit PCB			○				○
LI	Malfunction of inverter PCB	Defective compressor wiring Defective outdoor unit fan motor Blown fuse Defective inverter PCB		○	○	○			○
L3	El.compo. box temperature rise	Fin temperature rise due to short circuit Defective outdoor unit fan motor Defective power transistor Defective outdoor unit PCB	○	○	○				○
L4	Malfunction of inverter radiation fin temperature rise	Fin temperature rise due to short circuit Defective fin thermistor	○	○	○	○			○
L5	Inverter instantaneous overcurrent (DC output)	Defective compressor coil (such as wiring disconnection or insulation failure) Compressor startup failure (mechanical lock) Defective inverter PCB	○	○	○	○			○
L6	Inverter instantaneous overcurrent (AC output)	Overcharge of refrigerant amount Shortage of power supply capacity Defective compressor Defective inverter unit			○				○
L8	Malfunction of overcurrent inverter compressor	Compressor overloaded Wiring disconnection in compressor coil Disconnection of compressor wiring Defective inverter PCB	○	○	○	○			○
L9	Malfunction of inverter compressor startup error (Stall prevention)	The stop valve is not opened Defective compressor Error in wire connections to compressor Large differential pressure before compressor startup Defective inverter PCB		○	○	○			○
LA	Malfunction of power transistor	Defective power transistor Defective compressor Defective inverter PCB			○				○
LC	Malfunction of transmission between control and inverter PCB	Defective connection between the inverter PCB and the control PCB External factors (e.g. noise) Defective inverter compressor Defective control PCB (transmission block)	○	○	○	○			○
MI	Malfunction of central remote controller PCB	Defective central remote controller PCB	○	○	○	○			○
MB	Malfunction of transmission between optional controllers for centralized control	Other centralized control power disconnection Centralized control reset switch ON Defective transmission wiring Central remote controller address change	○	○	○	○			○
MA	Improper combination of optional controllers for centralized control	Improper combination of optional controllers for centralized control More than one master controller is connected Faulty setting of centralized control Defect of centralized control	○	○	○	○			○
MC	Address duplication, improper setting	Address duplication of central remote controller	○	○	○	○			○
PD	Shortage of refrigerant amount (thermal storage unit)	Shortage of refrigerant Clogged refrigerant piping			○				○
PI	Power voltage imbalance or inverter PCB	Open phase Interphase voltage imbalance Defective capacitor in the main circuit Defective wiring in the main circuit Defective inverter PCB		○	○	○			○

# Simple Self-Diagnosis by Malfunction Code

Malfunction code	Malfunction Contents	Supposed causes	Objects							
			RA	SkyAir	VRV	Package	Heat reclaim ventilator	Chiller	Fan Coil	
Outdoor Unit	P2	Automatic refrigerant charge operation stop		○	○	○		○		
	P3	Malfunction of thermistor in switch box	Defective connection of thermistor Defective reactor thermistor Defective inverter PCB	○	○	○	○		○	
	P4	Malfunction of radiation fin temperature sensor	Defective radiation fin temperature thermistor Defective inverter PCB Defective INV. compressor Defective fan motor	○	○	○	○		○	
	P8	Heat exchanger freezing protection during automatic refrigerant charging	(Close the refrigerant cylinder. Start again from step 1.)		○	○	○			
	P9	Malfunction of fan motor (humidifier unit)	Defective fan motor Defective outdoor unit PCB Broken relay harness Defective connector contact	○						
	P9	Automatic refrigerant charge operation completed	—		○	○	○	○		
	PR	Refrigerant cylinder during automatic refrigerant charging	Refrigerant cylinder of master unit is empty		○	○	○			
	PR	Broken wire of heater (humidifier unit)	Defective heater unit Defective thermistor Defective outdoor unit PCB	○						
	PC	Refrigerant cylinder during automatic refrigerant charging	Refrigerant cylinder of slave unit 2 is empty			○	○			
	PE	Automatic refrigerant charge operation nearly completed	—		○	○	○			
	PH	Refrigerant cylinder during automatic refrigerant charging	Defective heater unit Defective connector contact Defective thermistor Defective outdoor unit PCB	○		○	○			
	PU	Malfunction of capacity setting (Outdoor unit PCB)	Capacity setting adaptor is not installed Improper capacity setting adaptor Defective outdoor unit PCB		○					
	PU	Improper combination between inverter and fan driver	Mis-matching of type of PCB Improper (or no) field setting after replacing outdoor unit main PCB		○	○	○		○	
	System	U0	Shortage of refrigerant	Refrigerant shortage and refrigerant clogging (wrong piping) Defective thermistor Defective low pressure sensor Defective outdoor unit main PCB	○	○	○	○		○
U1		Reverse phase, open phase	Power supply reverse phase T phase open phase Defective outdoor unit PCB (A1P)	○	○	○	○	○	○	○
U2		Malfunction of power supply or instantaneous power failure	Abnormal power supply voltage Instantaneous power failure Defective main circuit wiring	○	○	○	○		○	○
U3		Check operation not executed or transmission error	Check operation is not executed.	○	○	○	○	○	○	○
U4		Malfunction of transmission between indoor and outdoor unit	Short circuit in indoor-outdoor or outdoor-outdoor transmission wiring (F1 / F2), or wrong wiring Outdoor unit power supply is OFF System address does not match Defective indoor unit PCB Defective outdoor unit PCB	○	○	○	○	○	○	○
U5		Malfunction of transmission between indoor unit and remote controller	Transmission error between indoor unit and remote controller Connection of 2 main remote controllers (when using 2 remote controllers) Defective indoor unit PCB Defective remote controller PCB Transmission error caused by noise	○	○	○	○		○	○
U6		Malfunction of transmission between indoor units	Faulty wiring External factor (Noise etc.) Defective indoor unit PCB			○	○		○	○

Malfunction code	Malfunction Contents	Supposed causes	Objects							
			RA	SkyAir	VRV	Package	Heat reclaim ventilator	Chiller	Fan Coil	
System	U7	Malfunction of transmission between outdoor units or outdoor storage unit	○		○	○		○	○	
	U8	Malfunction of transmission between remote controllers		○	○	○	○	○	○	
	U9	Malfunction of transmission (other system)			○	○	○		○	
	UA	Defect of indoor/outdoor power supply	○							
	UA	Improper combination of indoor and outdoor units		○	○	○			○	
	UA	Remote temperature setting wire disconnection					○			
	UC	Malfunction of setting of centralized control equipment address	Address duplication of centralized control equipment Defective indoor unit PCB		○	○	○	○	○	○
	UE	Malfunction of transmission between indoor unit and centralized control equipment	Transmission error between optional controllers for centralized control equipment and indoor unit Connector for setting main controller is disconnected.(or disconnection of connector for independent / combined use changeover switch.) Defective PCB for central remote controller Defective indoor unit PCB		○	○	○	○	○	○
	UF	System is not set yet	Improper connection of transmission wiring between indoor-outdoor units and outdoor-outdoor units Failure to execute check operation Defective indoor unit PCB Stop valve is not opened		○	○	○	○		
	UH	Malfunction of system	Improper connection of transmission wiring between indoor-outdoor units and outdoor-outdoor units Defective indoor unit PCB Defective outdoor unit PCB	○		○	○			
	UU	Malfunction of transmission (accessory device)	Defect of accessory devices Faulty wiring	○	○	○	○		○	
	Others	60	External protection device activated (Heat reclaim ventilator)						○	
		64	Malfunction of indoor air thermistor (Heat reclaim ventilator)						○	
		65	Malfunction of outdoor air thermistor (Heat reclaim ventilator)						○	
68		Malfunction of damper system (Heat reclaim ventilator)						○		
70		System No. 2 Compressor overheat	Shortage of refrigerant amount Defective connector contact Leakage of four way valve						○	
71		System No. 2 Compressor overcurrent	Shortage of refrigerant amount Short circuit Defective compressor						○	

# Simple Self-Diagnosis by Malfunction Code

Malfunction code	Malfunction Contents	Supposed causes	Objects							
			RA	SkyAir	VRV	Package	Heat reclaim ventilator	Chiller	Fan Coil	
Others	72	System No. 2 Fan motor overcurrent	Defective fan motor connector contact Defective fan motor Defective PCB						○	
	73	System No. 2 Actuation of high pressure switch (HPS)	Dirty heat exchanger Shortage of water volume Clogged refrigerant piping Defective connector contact Defective HPS						○	
	74	System No. 2 Actuation of low pressure switch (LPS)	Clogged refrigerant piping Defective connector contact Shortage of gas Defective LPS						○	
	75	System No. 2 Malfunction of low pressure sensor	Defective connector contact Defective low pressure sensor Defective PCB						○	
	76	System No. 2 Malfunction of high pressure sensor	Defective connector contact Defective high pressure sensor Defective PCB						○	
	77	System No. 1 Malfunction of fan inter lock	Defective relay contact Broken wire						○	
	78	System No. 2 Malfunction of fan inter lock	Defective relay contact Broken wire						○	
	79	System No. 2 Malfunction of compressor current sensor	Defective current sensor Defective compressor Defective outdoor unit PCB						○	
	7C	System No. 2 Malfunction of pump inter lock	Cooling water pump interlock actuated						○	
	80	Malfunction of entering water temperature thermistor	Defective connector contact Defective entering water temperature thermistor						○	
	81	Malfunction of leaving water temperature thermistor or drain pipe heater	Defective connector contact Defective leaving water temperature thermistor						○	
	82	System No. 1 Malfunction of refrigerant thermistor	Defective connector contact Defective refrigerant thermistor						○	
	83	System No. 2 Malfunction of refrigerant thermistor	Defective connector contact Defective refrigerant thermistor						○	
	84	System No. 1 Malfunction of heat exchanger thermistor	Defective connector contact Defective heat exchanger thermistor						○	
	85	System No. 2 Malfunction of heat exchanger thermistor	Defective connector contact Defective heat exchanger thermistor						○	
	86	System No. 1 Malfunction of discharge pipe thermistor	Defective connecting connector Defective discharge pipe thermistor						○	
	88	System No. 2 Malfunction of discharge pipe temperature	Shortage of gas Defective discharge pipe thermistor Defective connector contact Clogged refrigerant piping						○	
	89	Malfunction of brazed-plate heat exchanger freezing	Dirty heat exchanger Shortage of refrigerant amount Defective thermistor						○	
	8A	System No. 2 Malfunction of leaving water temperature thermistor	Defective connector contact Defective leaving water temperature thermistor						○	
	8E	System No. 1 Malfunction of suction pipe thermistor 1 for heating	Defective connector contact Defective suction pipe thermistor						○	
8F	System No. 1 Malfunction of suction pipe thermistor 2 for heating	Defective connector contact Defective suction pipe thermistor						○		



Malfunction code	Malfunction Contents	Supposed causes	Objects							
			RA	SkyAir	VRV	Package	Heat reclaim ventilator	Chiller	Fan Coil	
Others	84	Abnormal hot water high temperature	Three way valve malfunction Defective thermistor Defect of water temperature setting						○	
	90	Abnormal chilled water quantity or abnormal AXP	Shortage of water volume Disconnection of AXP						○	
	91	System No. 2 Malfunction of electronic expansion valve	Defective connector contact Defective electronic expansion valve coil						○	
	92	System No. 2 Malfunction of suction pipe thermistor	Defective connector contact Defective suction pipe thermistor						○	
	94	Malfunction of transmission (between heat reclaim ventilator and fan unit)	Defective fan unit PCB Defective connecting wire between (1) and (2)					○		
	95	System No. 1 Malfunction of inverter system	Defective fan inverter unit						○	
	96	System No. 2 Malfunction of inverter system	Defective fan inverter unit						○	
	97	Malfunction of thermal storage unit	Defective thermal storage unit						○	
	98	Malfunction of thermal storage brine pump	Actuation of thermal storage brine pump overcurrent (OC)						○	
	99	Malfunction of thermal storage brine tank	Low water level of thermal storage brine tank						○	

# Self-Diagnosis by Remote Controller (SkyAir, VRV)

## <Wired Remote Controller>

### In case of BRC1C62



- If operation stops due to malfunction, the remote controller's operation LED blinks, and a malfunction code is displayed.
- Even if operation stops, malfunction contents are displayed when the inspection mode is entered.
  - \* While in check mode, hold the ON/OFF button for four seconds or more, the malfunction history will be cleared. (The malfunction code will blink, and the operation mode will switch from check mode to normal mode.)



Inspection/Test button Malfunction code  
\* Location of buttons varies by model type.

### In case of BRC1E62

- If operation stops due to malfunction, the remote controller's operation indicator blinks. The message "Error: Press Menu Button" will appear at the bottom of the screen.
- Press Menu/Enter button, and malfunction code will be displayed.
  - \* Press Menu/Enter button, and malfunction history will be displayed in Main Menu mode.



\* While in malfunction code display mode on the left, press ON/OFF button for four seconds or more, the malfunction history will be cleared.

## <Wireless Remote Controller>

- If operation stops due to a malfunction, the operation indicating LED on the light reception section flashes.
- The malfunction code can be displayed by following the procedure.

- Press the INSPECTION/TEST button to select "Inspection."
  - The equipment enters the inspection mode. The "Unit" indication lights and the Unit No. display shows a flashing "0" indication.
- Set the Unit No.
  - Press the UP or DOWN button and change the Unit No. display until the buzzer (\*1) is generated from the indoor unit.

\*1 Number of beeps

- 3 short beeps** : Conduct all of the following operations.
- 1 short beep** : Conduct steps 3 and 4. Continue the operation in step 4 until a buzzer remains ON. The continuous buzzer indicates that the malfunction code is confirmed.

**Continuous beep** : No abnormality.

- Press the MODE selector button.
  - The left "0" (upper digit) indication of the malfunction code flashes.
- Malfunction code upper digit diagnosis
  - Press the UP or DOWN button and change the malfunction code upper digit until the malfunction code matching buzzer (\*2) is generated.
    - The upper digit of the code changes as shown below when the UP and DOWN buttons are pressed.
- Malfunction code lower digit diagnosis
  - Press the UP or DOWN button and change the malfunction code lower digit until the continuous malfunction code matching buzzer (\*2) is generated.
    - The lower digit of the code changes as shown below when the UP and DOWN buttons are pressed.

0 1 2 3 4 5 6 7 8 9 A B C D E F


⇨ "Advance" button ⇩ "Backward" button

\*2 Number of beeps


- Continuous beep** : Both upper and lower digits matched. (Malfunction code confirmed.)
- 2 short beeps** : Upper digit matched.
- 1 short beep** : Lower digit matched.

0 1 2 3 4 5 6 7 8 9 A B C D E F

⇨ "Advance" button ⇩ "Backward" button



\* Location of buttons varies by the model type.






# Self-Diagnosis by Remote Controller (Residential Air-conditioner)

## In case of ARC474

### [Check Method]

With the wireless remote controller supplied with the unit, or sold separately, malfunction codes by failure diagnosis can be confirmed. (hold the timer cancel button down for 5 seconds.)




1. Hold the timer cancel button down for 5 seconds, with the remote controller set toward the indoor unit.
2. The temperature display on the remote controller changes to the error code display and a long beep notifies this indication change.

### Note:

To cancel indication of malfunction code, hold the timer cancel button down for 5 seconds. The code display also cancels itself if the button is not pressed for 1 minute.

## In case of ARC455A, ARC452A, ARC433B, ARC423A, ARC417A [Check Method 1]

1. When the timer cancel button is held down for 5 seconds, a "00" indication flashes on the temperature display section.
  2. Press the timer cancel button repeatedly until a continuous beep is generated
- The code indication changes in the sequence shown below, and notifies with a long beep.



### <In case of ARC433B67, 68, 69, 76>


No.	Code	No.	Code	No.	Code
1	00	12	07	23	00
2	04	13	08	24	01
3	03	14	03	25	04
4	06	15	03	26	03
5	05	16	01	27	04
6	06	17	04	28	06
7	05	18	05	29	07
8	06	19	08	30	02
9	09	20	06	31	04
10	00	21	08	32	08
11	07	22	05	33	08

### Note:

1. A short beep and two consecutive beeps indicate non-corresponding codes.
2. To cancel the code display, hold the timer cancel button down for 5 seconds. The code display also cancels itself if the button is not pressed for 1 minute.

### [Check Method 2]

1. Press the 3 buttons (TEMP▲, TEMP▼, MODE) simultaneously to enter the diagnosis mode.
- The figure of the ten's place blinks.
- ★ Try again from the start when the figure does not blink.



2. Press TEMP▲ or ▼ button and change the figure until you hear the sound of "beep" or "pi pi".
3. Diagnose by the sound.
  - ★ "1 short beep": The figure of the ten's place does not accord with the malfunction code.
  - ★ "2 short beep": The figure of the ten's place accords with the error code but the one's not.
  - ★ "1 long beep": The both figures of the ten's and one's place accord with the malfunction code.
4. Press the MODE button.
 

The figure of the one's place blinks.
5. Press the TEMP button.
 

Press TEMP▲ or ▼ button and change the figure until you hear the sound of "long beep".
6. Diagnose by the sound.
  - ★ "1 short beep": The figure of the ten's place does not accord with the malfunction code.
  - ★ "2 short beep": The figure of the ten's place accords with the error code but the one's not.
  - ★ "1 long beep": The both figures of the ten's and one's place accord with the error code.
7. Determine the malfunction code.
 

The digits indicated when you hear the "long beep" sound are error code.
8. Press the MODE button to exit from the diagnosis mode.
 

The display "7" means the trial operation mode.
9. Press the ON/OFF button twice to return to the normal mode.

### Note:

When the remote controller is left untouched for 60 seconds, it returns to the normal mode.



## Section 4

### Manufacturers Literature

In the following pages please see manufacturers information from Daikin and Fantech

**Office:** 2/30 Access Crescent, Coolum Beach, QLD 4573

**Postal:** PO Box 6017, Maroochydore, Qld 4558

**Email:** [admin@portcityairconditioning.com.au](mailto:admin@portcityairconditioning.com.au)

**Phone:** 1300 PORT CITY / 07 4972 3355 **Fax:** 07 4972 1791

**After Hours Emergency Phone:** 0439 665 398

**Website:** <http://www.portcitygroup.com.au/>

ABN: 99 717 077 615 / QBCC: 1184073 / ARCTICK: AU12994 / ELEC: 73329

# Engineering Data

FXDQ-TV1C(A)

50 Hz

**R-410A**







# FXDQ-TV1C(A)

## Slim Ceiling Mounted Duct Type (Compact Series)

### 50 Hz

1. Lineup.....	2
2. Specifications .....	3
3. Dimensions.....	6
4. Piping Diagrams .....	9
5. Wiring Diagrams .....	10
6. Electric Characteristics .....	12
7. Safety Devices Setting .....	14
8. Capacity Tables.....	15
8.1 Cooling Capacity for Te: Auto .....	15
8.2 Cooling Capacity for Te: 6°C .....	15
8.3 Cooling Capacity for Te: 9°C .....	16
8.4 Heating Capacity.....	16
9. Fan Performances.....	17
10. Sound Levels.....	23
11. Centre of Gravity .....	26
12. Accessories .....	28
12.1 Optional Accessories (for Controls) .....	28
13. Installation Manual .....	29

# 1. Lineup

Capacity range	2.2 kW	2.8 kW	3.6 kW	4.5 kW	5.6 kW	7.1 kW
Capacity index	20	25	31.25	40	50	62.5
FXDQ	20TV1C	25TV1C	32TV1C	40TV1C	50TV1C	63TV1C
	20TV1CA	25TV1CA	32TV1CA	40TV1CA	50TV1CA	63TV1CA

**Note:**

V1B : 1 phase, 220-240 V, 50 Hz

V1BA : 1 phase, 220-240 V, 50 Hz

FXDQ-TV1C : Standard Model

FXDQ-TV1CA : With Multi Tenancy Kit Model



## 2. Specifications

Model			FXDQ20TV1C	FXDQ25TV1C	
			FXDQ20TV1CA	FXDQ25TV1CA	
Power supply			1 phase, 220-240 V, 50 Hz	1 phase, 220-240 V, 50 Hz	
★1 ★3 Cooling capacity		kcal/h	1,900	2,400	
		Btu/h	7,500	9,600	
		kW	2.2	2.8	
★2 ★3 Heating capacity		kcal/h	2,200	2,800	
		Btu/h	8,500	10,900	
		kW	2.5	3.2	
Power input	Cooling	TV1C	0.030	0.037	
		TV1CA	0.0305	0.0375	
	Heating	TV1C	0.025	0.032	
		TV1CA	0.0255	0.0325	
Casing			Galvanized steel plate	Galvanized steel plate	
Dimensions: (H×W×D)		mm	200×700×450	200×700×450	
Fan	Type		Sirocco fan	Sirocco fan	
	Motor output × Number of units		W	78×1	78×1
	Airflow rate		m <sup>3</sup> /min	8.1	9.0
			l/s	135	150
			cfm	286	318
	★4 External static pressure		Pa	40-10	40-10
	Drive			Direct drive	Direct drive
	Airflow adjustment			5 step	5 step
★4 External static pressure adjustment			3 step	3 step	
★5 ★6 ★7 Sound pressure level (HH/H/L)		dB(A)	32/30/28	33/30.5/28	
Temperature control			Microprocessor thermostat for cooling and heating	Microprocessor thermostat for cooling and heating	
Air filter			Removable / Washable / Mildew proof	Removable / Washable / Mildew proof	
Drain pump			DC	DC	
Weight		kg	18	18	
Piping connections	Liquid pipes	mm	φ6.4 (Flare connection)	φ6.4 (Flare connection)	
	Gas pipes	mm	φ12.7 (Flare connection)	φ12.7 (Flare connection)	
	Drain pipe	mm	PVC26 (External dia. 26, Internal dia. 20)	PVC26 (External dia. 26, Internal dia. 20)	
Safety devices			Fuse, Thermal protector for fan motor	Fuse, Thermal protector for fan motor	
Refrigerant control			Electronic expansion valve	Electronic expansion valve	
Standard accessories			Operation manual, Installation manual	Operation manual, Installation manual	
Drawing No.	Specification		C: 3D117654	C: 3D117654	
	Sound level		C: 4D115188A	C: 4D115189A	

### Notes:

- ★1. Indoor temp.: 27°CDB, 19°CWB / outdoor temp.: 35°CDB / Equivalent piping length: 5 m, level difference: 0 m.
- ★2. Indoor temp.: 20°CDB / outdoor temp.: 7°CDB, 6°CWB / Equivalent piping length: 5 m, level difference: 0 m.
- ★3. Capacities are net, including a deduction for cooling (an addition for heating) for indoor fan motor heat.
- ★4. External static pressure is changeable to set by the remote controller. This pressure means "High static pressure - Standard static pressure". (Factory setting is 10 Pa.)
- ★5. Anechoic chamber conversion value, measured at a point 1.5 m downward from the unit centre. During actual operation, these values are normally somewhat higher as a result of ambient conditions.
- ★6. Values are based on the external static pressure of 10 Pa.
- ★7. The values of operation sound level represent those for rear-suction operation. Sound level values for bottom-suction operation can be obtained by adding 5 dB(A).

### Conversion formulae

$$\begin{aligned} \text{kcal/h} &= \text{kW} \times 860 \\ \text{Btu/h} &= \text{kW} \times 3412 \\ \text{cfm} &= \text{m}^3/\text{min} \times 35.3 \\ \text{l/s} &= \text{m}^3/\text{min} \times 1000/60 \end{aligned}$$

Model			FXDQ32TV1C		FXDQ40TV1C		
			FXDQ32TV1CA		FXDQ40TV1CA		
Power supply			1 phase, 220-240 V, 50 Hz		1 phase, 220-240 V, 50 Hz		
★1 ★3 Cooling capacity		kcal/h	3,100		3,900		
		Btu/h	12,300		15,400		
		kW	3.6		4.5		
★2 ★3 Heating capacity		kcal/h	3,400		4,300		
		Btu/h	13,600		17,100		
		kW	4.0		5.0		
Power input	Cooling	TV1C	0.037		0.050		
		TV1CA	0.0375		0.0505		
	Heating	TV1C	0.032		0.045		
		TV1CA	0.0325		0.0455		
Casing			Galvanized steel plate		Galvanized steel plate		
Dimensions: (H×W×D)			mm		200×700×450		
Fan	Type		Sirocco fan		Sirocco fan		
	Motor output × Number of units		W	78×1		93×1	
	Airflow rate		m <sup>3</sup> /min	9.0		12.6	
			l/s	150		210	
			cfm	318		445	
	★4 External static pressure		Pa	50-10		60-10	
	Drive		Direct drive		Direct drive		
	Airflow adjustment		5 step		5 step		
★4 External static pressure adjustment		3 step		3 step			
★5 ★6 ★7 Sound pressure level (HH/H/L)		dB(A)	33/30.5/28		34/31.5/29		
Temperature control			Microprocessor thermostat for cooling and heating		Microprocessor thermostat for cooling and heating		
Air filter			Removable / Washable / Mildew proof		Removable / Washable / Mildew proof		
Drain pump			DC		DC		
Weight			kg	18		21	
Piping connections	Liquid pipes	mm	φ6.4 (Flare connection)		φ6.4 (Flare connection)		
	Gas pipes	mm	φ12.7 (Flare connection)		φ12.7 (Flare connection)		
	Drain pipe	mm	PVC26 (External dia. 26, Internal dia. 20)		PVC26 (External dia. 26, Internal dia. 20)		
Safety devices			Fuse, Thermal protector for fan motor		Fuse, Thermal protector for fan motor		
Refrigerant control			Electronic expansion valve		Electronic expansion valve		
Standard accessories			Operation manual, Installation manual		Operation manual, Installation manual		
Drawing No.	Specification	C: 3D117654		C: 3D117654			
	Sound level	C: 4D115190A		C: 4D115191A			

**Notes:**

- ★1. Indoor temp.: 27°CDB, 19°CWB / outdoor temp.: 35°CDB / Equivalent piping length: 5 m, level difference: 0 m.
- ★2. Indoor temp.: 20°CDB / outdoor temp.: 7°CDB, 6°CWB / Equivalent piping length: 5 m, level difference: 0 m.
- ★3. Capacities are net, including a deduction for cooling (an addition for heating) for indoor fan motor heat.
- ★4. External static pressure is changeable to set by the remote controller. This pressure means "High static pressure - Standard static pressure". (Factory setting is 10 Pa.)
- ★5. Anechoic chamber conversion value, measured at a point 1.5 m downward from the unit centre. During actual operation, these values are normally somewhat higher as a result of ambient conditions.
- ★6. Values are based on the external static pressure of 10 Pa.
- ★7. The values of operation sound level represent those for rear-suction operation. Sound level values for bottom-suction operation can be obtained by adding 5 dB(A).

**Conversion formulae**

$$\begin{aligned} \text{kcal/h} &= \text{kW} \times 860 \\ \text{Btu/h} &= \text{kW} \times 3412 \\ \text{cfm} &= \text{m}^3/\text{min} \times 35.3 \\ \text{l/s} &= \text{m}^3/\text{min} \times 1000/60 \end{aligned}$$

Model			FXDQ50TV1C	FXDQ63TV1C	
			FXDQ50TV1CA	FXDQ63TV1CA	
Power supply			1 phase, 220-240 V, 50 Hz	1 phase, 220-240 V, 50 Hz	
★1 ★3 Cooling capacity		kcal/h	4,800	6,100	
		Btu/h	19,100	24,200	
		kW	5.6	7.1	
★2 ★3 Heating capacity		kcal/h	5,400	6,900	
		Btu/h	21,500	27,300	
		kW	6.3	8.0	
Power input	Cooling	TV1C	0.075	0.075	
		TV1CA	0.0755	0.0755	
	Heating	TV1C	0.070	0.070	
		TV1CA	0.0705	0.0705	
Casing			Galvanized steel plate	Galvanized steel plate	
Dimensions: (H×W×D)		mm	200×900×450	200×1,100×450	
Fan	Type		Sirocco fan	Sirocco fan	
	Motor output × Number of units		W	93×1	93×1
	Airflow rate		m <sup>3</sup> /min	15.0	19.5
			l/s	250	325
			cfm	530	688
	★4 External static pressure		Pa	45-10	45-10
	Drive			Direct drive	Direct drive
	Airflow adjustment			5 step	5 step
★4 External static pressure adjustment			3 step	3 step	
★5 ★6 ★7 Sound pressure level (HH/H/L)		dB(A)	35/32.5/30	37/35/33	
Temperature control			Microprocessor thermostat for cooling and heating	Microprocessor thermostat for cooling and heating	
Air filter			Removable / Washable / Mildew proof	Removable / Washable / Mildew proof	
Drain pump			DC	DC	
Weight		kg	21	24	
Piping connections	Liquid pipes	mm	φ6.4 (Flare connection)	φ9.5 (Flare connection)	
	Gas pipes	mm	φ12.7 (Flare connection)	φ15.9 (Flare connection)	
	Drain pipe	mm	PVC26 (External dia. 26, Internal dia. 20)	PVC26 (External dia. 26, Internal dia. 20)	
Safety devices			Fuse, Thermal protector for fan motor	Fuse, Thermal protector for fan motor	
Refrigerant control			Electronic expansion valve	Electronic expansion valve	
Standard accessories			Operation manual, Installation manual	Operation manual, Installation manual	
Drawing No.	Specification		C: 3D117654	C: 3D117654	
	Sound level		C: 4D115192A	C: 4D115193A	

**Notes:**

- ★1. Indoor temp.: 27°CDB, 19°CWB / outdoor temp.: 35°CDB / Equivalent piping length: 5 m, level difference: 0 m.
- ★2. Indoor temp.: 20°CDB / outdoor temp.: 7°CDB, 6°CWB / Equivalent piping length: 5 m, level difference: 0 m.
- ★3. Capacities are net, including a deduction for cooling (an addition for heating) for indoor fan motor heat.
- ★4. External static pressure is changeable to set by the remote controller. This pressure means "High static pressure - Standard static pressure". (Factory setting is 10 Pa.)
- ★5. Anechoic chamber conversion value, measured at a point 1.5 m downward from the unit centre. During actual operation, these values are normally somewhat higher as a result of ambient conditions.
- ★6. Values are based on the external static pressure of 10 Pa.
- ★7. The values of operation sound level represent those for rear-suction operation. Sound level values for bottom-suction operation can be obtained by adding 5 dB(A).

**Conversion formulae**


$$\begin{aligned} \text{kcal/h} &= \text{kW} \times 860 \\ \text{Btu/h} &= \text{kW} \times 3412 \\ \text{cfm} &= \text{m}^3/\text{min} \times 35.3 \\ \text{l/s} &= \text{m}^3/\text{min} \times 1000/60 \end{aligned}$$

### 3. Dimensions





FXDQ20TV1C / FXDQ25TV1C / FXDQ32TV1C  
 FXDQ20TV1CA / FXDQ25TV1CA / FXDQ32TV1CA

Unit: mm

NUMBER	NAME	DESCRIPTION
1	LIQUID PIPE CONNECTION	Ø 6.4 (FLARE CONNECTION)
2	GAS PIPE CONNECTION	Ø 12.7 (FLARE CONNECTION)
3	DRAIN PIPE CONNECTION	PVC26 (O.D. Ø26 / I.D. Ø20)
4	DRAIN HOSE (ACCESSORY)	I.D. Ø 25 (OUTLET)
5	CONTROL BOX	
6	TRANSMISSION WIRING CONNECTION	
7	POWER SUPPLY CONNECTION	
8	SUSPENSION BRACKET	
9	INSPECTION DOOR	
10	SOCKET FOR DRAIN	
11	NAME PLATE	



< SERVICE SPACE >



Notes:  
 1. In case of rear suction, mount cover plate to the bottom of the unit.  
 2. In case of bottom suction, mount cover plate to the back of the unit.  
 3. When installing optional accessories, refer to the installation drawings supplied with the accessories.  
 4. Service space is the minimum recommended distance. In some restricted space installations, it may be necessary to reduce the distance. Please note that this may necessitate additional service work should maintenance or repair be required.

C: 3D117660











FXDQ63TV1C  
FXDQ63TV1CA

Unit: mm

NUMBER	NAME	DESCRIPTION
1	LIQUID PIPE CONNECTION	Ø 9.5 (FLARE CONNECTION)
2	GAS PIPE CONNECTION	Ø 15.9 (FLARE CONNECTION)
3	DRAIN PIPE CONNECTION	PVC26 (O. D. Ø26 / I. D. Ø20)
4	DRAIN HOSE (ACCESSORY)	I. D. Ø 25 (OUTLET)
5	CONTROL BOX	
6	TRANSMISSION WIRING CONNECTION	
7	POWER SUPPLY CONNECTION	
8	SUSPENSION BRACKET	
9	INSPECTION DOOR	
10	SOCKET FOR DRAIN	
11	NAME PLATE	




- Notes:
1. In case of rear suction, mount cover plate to the bottom of the unit.
  2. In case of bottom suction, mount cover plate to the back of the unit.
  3. When installing optional accessories, refer to the installation drawings supplied with the accessories.
  4. Service space is the minimum recommended distance. In some restricted space installations, it may be necessary to reduce the distance. Please note that this may necessitate additional service work should maintenance or repair be required.

3D117678

### 4. Piping Diagrams

**FXDQ20TV1C / FXDQ25TV1C / FXDQ32TV1C / FXDQ40TV1C / FXDQ50TV1C / FXDQ63TV1C  
 FXDQ20TV1CA / FXDQ25TV1CA / FXDQ32TV1CA / FXDQ40TV1CA / FXDQ50TV1CA /  
 FXDQ63TV1CA**



4D132442


■ Refrigerant pipe connection port diameters

Unit: mm

Model	Gas	Liquid
FXDQ20TV1C / FXDQ25TV1C / FXDQ32TV1C / FXDQ40TV1C / FXDQ50TV1C FXDQ20TV1CA / FXDQ25TV1CA / FXDQ32TV1CA / FXDQ40TV1CA / FXDQ50TV1CA	φ12.7	φ6.4
FXDQ63TV1C FXDQ63TV1CA	φ15.9	φ9.5

# 5. Wiring Diagrams

FXDQ20TV1C / FXDQ25TV1C / FXDQ32TV1C / FXDQ40TV1C / FXDQ50TV1C / FXDQ63TV1C



3P496301E



## 6. Electric Characteristics

### FXDQ20TV1C / FXDQ25TV1C / FXDQ32TV1C / FXDQ40TV1C / FXDQ50TV1C / FXDQ63TV1C

MODEL	POWER SUPPLY					IFM		INPUT(W)	
	Hz	Volts	Voltage range	MCA	MFA	kW	FLA	COOLING	HEATING
FXDQ20TV1C	50	220-240V	MAX. 264V MIN. 198V	0.6	15	0.078	0.5	30	25
FXDQ25TV1C				0.8	15	0.078	0.6	37	32
FXDQ32TV1C				0.9	15	0.078	0.7	37	32
FXDQ40TV1C				1.9	15	0.093	1.5	50	45
FXDQ50TV1C				2.1	15	0.093	1.7	75	70
FXDQ63TV1C				1.8	15	0.093	1.4	75	70

#### Symbols:

MCA : Min. Circuit Amps. (A)  
MFA : Max. Fuse Amps (See note 4). (A)  
IFM : Indoor Fan Motor.  
FLA : Full Load Amps. (A)  
kW : Fan Motor Rated Output. (kW)

#### Note:

- Voltage range:  
Units are suitable for use on electrical systems where voltage supplied to unit terminals is not below or above listed range limits.
- Maximum allowable voltage unbalance between phases is 2%.
- MCA/MFA  
 $MCA = 1.25 \times FLA$   
 $MFA \leq 4 \times FLA$   
(Next lower standard fuse rating. Min. 15A).
- Select wire size based on the MCA.
- Instead of fuse, use circuit breaker.

**FXDQ20TV1CA / FXDQ25TV1CA / FXDQ32TV1CA / FXDQ40TV1CA / FXDQ50TV1CA /  
FXDQ63TV1CA**

MODEL	POWER SUPPLY					IFM		INPUT(W)	
	Hz	Volts	Voltage range	MCA	MFA	kW	FLA	COOLING	HEATING
FXDQ20TV1CA	50	220-240V	MAX. 264V MIN. 198V	0.6	15	0.078	0.5	30.5	25.5
FXDQ25TV1CA				0.8	15	0.078	0.6	37.5	32.5
FXDQ32TV1CA				0.9	15	0.078	0.7	37.5	32.5
FXDQ40TV1CA				1.9	15	0.093	1.5	50.5	45.5
FXDQ50TV1CA				2.1	15	0.093	1.7	75.5	70.5
FXDQ63TV1CA				1.8	15	0.093	1.4	75.5	70.5

**Symbols:**

MCA : Min. Circuit Amps. (A)  
MFA : Max. Fuse Amps (See note 4). (A)  
IFM : Indoor Fan Motor.  
FLA : Full Load Amps. (A)  
kW : Fan Motor Rated Output. (kW)

**Note:**

- Voltage range:  
Units are suitable for use on electrical systems where voltage supplied to unit terminals is not below or above listed range limits.
- Maximum allowable voltage unbalance between phases is 2%.
- MCA/MFA  
 $MCA = 1.25 \times FLA$   
 $MFA \leq 4 \times FLA$   
(Next lower standard fuse rating. Min. 15A).
- Select wire size based on the MCA.
- Instead of fuse, use circuit breaker.

## 7. Safety Devices Setting

Model		FXDQ20TV1C	FXDQ25TV1C	FXDQ32TV1C
Printed circuit board fuse	A1P	250 V, 3.15 A	250 V, 3.15 A	250 V, 3.15 A
Fan motor temperature protection	°C	OFF: $100^{+15}_{-10}$ ON : $95^{+15}_{-10}$	OFF: $100^{+15}_{-10}$ ON : $95^{+15}_{-10}$	OFF: $100^{+15}_{-10}$ ON : $95^{+15}_{-10}$

Model		FXDQ40TV1C	FXDQ50TV1C	FXDQ63TV1C
Printed circuit board fuse	A1P	250 V, 3.15 A	250 V, 3.15 A	250 V, 3.15 A
Fan motor temperature protection	°C	OFF: $100^{+15}_{-10}$ ON : $95^{+15}_{-10}$	OFF: $100^{+15}_{-10}$ ON : $95^{+15}_{-10}$	OFF: $100^{+15}_{-10}$ ON : $95^{+15}_{-10}$

C: 4D115160A

Model		FXDQ20TV1CA	FXDQ25TV1CA	FXDQ32TV1CA
Main printed circuit board fuse	A1P	250 V, 3.15 A	250 V, 3.15 A	250 V, 3.15 A
Multitenant printed circuit board fuse	A2P			
Fan motor temperature protection	°C	OFF: $100^{+15}_{-10}$ ON : $95^{+15}_{-10}$	OFF: $100^{+15}_{-10}$ ON : $95^{+15}_{-10}$	OFF: $100^{+15}_{-10}$ ON : $95^{+15}_{-10}$

Model		FXDQ40TV1CA	FXDQ50TV1CA	FXDQ63TV1CA
Main printed circuit board fuse	A1P	250 V, 3.15 A	250 V, 3.15 A	250 V, 3.15 A
Multitenant printed circuit board fuse	A2P			
Fan motor temperature protection	°C	OFF: $100^{+15}_{-10}$ ON : $95^{+15}_{-10}$	OFF: $100^{+15}_{-10}$ ON : $95^{+15}_{-10}$	OFF: $100^{+15}_{-10}$ ON : $95^{+15}_{-10}$

C: 4D117785

## 8. Capacity Tables

### 8.1 Cooling Capacity for Te: Auto

Model	Capacity indication	Indoor air temp.													
		14°CWB		16°CWB		18°CWB		19°CWB		20°CWB		22°CWB		24°CWB	
		20°CDB		23°CDB		26°CDB		27°CDB		28°CDB		30°CDB		32°CDB	
		TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
FXDQ20TV1C FXDQ20TV1CA	20	1.9	1.9	2.1	2.0	2.2	2.0	2.2	1.6	2.2	1.8	2.3	1.7	2.3	1.5
FXDQ25TV1C FXDQ25TV1CA	25	2.5	2.5	2.6	2.5	2.8	2.5	2.8	2.0	2.8	2.2	2.9	2.0	3.0	1.9
FXDQ32TV1C FXDQ32TV1CA	32	3.2	3.1	3.4	3.1	3.5	3.1	3.6	2.6	3.6	2.7	3.7	2.5	3.8	2.3
FXDQ40TV1C FXDQ40TV1CA	40	4.0	3.6	4.2	3.6	4.4	3.7	4.5	3.4	4.6	3.2	4.7	3.0	4.8	2.8
FXDQ50TV1C FXDQ50TV1CA	50	4.9	4.4	5.3	4.5	5.5	4.4	5.6	4.1	5.7	3.9	5.8	3.6	5.9	3.3
FXDQ63TV1C FXDQ63TV1CA	63	6.3	5.6	6.7	5.7	7.0	5.8	7.1	5.1	7.2	5.1	7.3	4.7	7.5	4.3

TC: Total capacity: kW  
SHC: Sensible heat capacity: kW

#### Notes:

- These capacity tables are for use when selecting a VRV indoor unit. The actual capacity of the VRV system depends on factors such as the selected model of outdoor units, outdoor air temperature and piping length. Please confirm that the corrected capacity of the VRV system satisfies the required heat load.
- shows rated condition.

### 8.2 Cooling Capacity for Te: 6°C

Model	Capacity indication	Indoor air temp.													
		14°CWB		16°CWB		18°CWB		19°CWB		20°CWB		22°CWB		24°CWB	
		20°CDB		23°CDB		26°CDB		27°CDB		28°CDB		30°CDB		32°CDB	
		TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
FXDQ20TV1C FXDQ20TV1CA	20	1.5	1.5	1.8	1.7	2.1	1.9	2.2	1.9	2.2	1.8	2.3	1.7	2.3	1.5
FXDQ25TV1C FXDQ25TV1CA	25	1.9	1.9	2.3	2.1	2.6	2.3	2.8	2.3	2.8	2.2	2.9	2.0	3.0	1.9
FXDQ32TV1C FXDQ32TV1CA	32	2.4	2.3	2.9	2.6	3.4	2.8	3.6	2.8	3.6	2.7	3.7	2.5	3.8	2.3
FXDQ40TV1C FXDQ40TV1CA	40	3.0	2.7	3.6	3.0	4.2	3.4	4.5	3.3	4.6	3.2	4.7	3.0	4.8	2.8
FXDQ50TV1C FXDQ50TV1CA	50	3.8	3.3	4.5	3.7	5.2	4.0	5.6	4.1	5.7	3.9	5.8	3.6	5.9	3.3
FXDQ63TV1C FXDQ63TV1CA	63	4.8	4.2	5.7	4.7	6.6	5.2	7.1	5.3	7.2	5.1	7.4	4.7	7.5	4.3

TC: Total capacity: kW  
SHC: Sensible heat capacity: kW

#### Notes:

- These capacity tables are for use when selecting a VRV indoor unit. The actual capacity of the VRV system depends on factors such as the selected model of outdoor units, outdoor air temperature and piping length. Please confirm that the corrected capacity of the VRV system satisfies the required heat load.
- shows rated condition.



### 8.3 Cooling Capacity for Te: 9°C

For VRV indoor units only at Te: 9°C / mixed combination of VRV and residential indoor units

Model	Capacity indication	Indoor air temp.													
		14°CWB		16°CWB		18°CWB		19°CWB		20°CWB		22°CWB		24°CWB	
		20°CDB		23°CDB		26°CDB		27°CDB		28°CDB		30°CDB		32°CDB	
		TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
FXDQ20TV1C FXDQ20TV1CA	20	1.0	1.0	1.3	1.3	1.6	1.6	1.7	1.6	1.8	1.6	1.9	1.5	2.0	1.3
FXDQ25TV1C FXDQ25TV1CA	25	1.3	1.3	1.6	1.6	2.0	1.9	2.2	2.0	2.2	1.9	2.4	1.8	2.6	1.7
FXDQ32TV1C FXDQ32TV1CA	32	1.6	1.6	2.0	2.0	2.6	2.4	2.8	2.4	2.9	2.3	3.1	2.2	3.3	2.1
FXDQ40TV1C FXDQ40TV1CA	40	2.0	2.0	2.6	2.5	3.3	2.9	3.6	2.8	3.7	2.8	4.0	2.7	4.2	2.5
FXDQ50TV1C FXDQ50TV1CA	50	2.5	2.5	3.2	3.1	4.1	3.4	4.5	3.6	4.7	3.4	4.9	3.2	5.1	3.0
FXDQ63TV1C FXDQ63TV1CA	63	3.2	3.2	4.2	3.9	5.2	4.5	5.7	4.6	5.9	4.5	6.3	4.2	6.6	3.9

TC: Total capacity: kW  
SHC: Sensible heat capacity: kW

#### Notes:

- These capacity tables are for use when selecting a VRV indoor unit. The actual capacity of the VRV system depends on factors such as the selected model of outdoor units, outdoor air temperature and piping length. Please confirm that the corrected capacity of the VRV system satisfies the required heat load.
- shows rated condition.

### 8.4 Heating Capacity



Model	Capacity indication	Indoor air temp.					
		16°CDB	18°CDB	20°CDB	21°CDB	22°CDB	24°CDB
		kW	kW	kW	kW	kW	kW
FXDQ20TV1C FXDQ20TV1CA	20	2.6	2.6	2.5	2.4	2.3	2.2
FXDQ25TV1C FXDQ25TV1CA	25	3.4	3.4	3.2	3.1	3.0	2.8
FXDQ32TV1C FXDQ32TV1CA	32	4.2	4.2	4.0	3.9	3.7	3.5
FXDQ40TV1C FXDQ40TV1CA	40	5.2	5.2	5.0	4.8	4.7	4.4
FXDQ50TV1C FXDQ50TV1CA	50	6.6	6.6	6.3	6.1	5.9	5.5
FXDQ63TV1C FXDQ63TV1CA	63	8.4	8.4	8.0	7.7	7.5	7.0

#### Notes:

- These capacity tables are for use when selecting a VRV indoor unit. The actual capacity of the VRV system depends on factors such as the selected model of outdoor units, outdoor air temperature and piping length. Please confirm that the corrected capacity of the VRV system satisfies the required heat load.
- shows rated condition.

# 9. Fan Performances

FXDQ20TV1C  
FXDQ20TV1CA





**NOTES**

1. The remote controller can be used to switch 3 steps between High, High and Low. The 3 steps are High, High and Low.
2. The air flow is set to "standard" before leaving the factory. It is possible to switch between "Standard ESP" and "High ESP" with the remote controller.
3. The fan curves are tested with air suction from rear side.

C: 3D115154A

FXDQ25TV1C  
FXDQ25TV1CA





NOTES

1. The remote controller can be used to switch 3 steps between HighHigh and Low. The 3 steps are HighHigh, High and Low
2. The air flow is set to "standard" before leaving the factory. It is possible to switch between "Standard ESP" and "High ESP" with the remote controller.
3. The fan curves are tested with air suction from rear side.

C: 3D115155A

FXDQ32TV1C  
FXDQ32TV1CA





**NOTES**

1. The remote controller can be used to switch 3 steps between HighHigh and Low. The 3 steps are HighHigh, High and Low
2. The air flow is set to "standard" before leaving the factory. It is possible to switch between "Standard ESP" and "High ESP" with the remote controller.
3. The fan curves are tested with air suction from rear side.

C: 3D115156A

FXDQ40TV1C  
FXDQ40TV1CA





**NOTES**

1. The remote controller can be used to switch 3 steps between HighHigh and Low. The 3 steps are HighHigh, High and Low
2. The air flow is set to "standard" before leaving the factory. It is possible to switch between "Standard ESP" and "High ESP" with the remote controller.
3. The fan curves are tested with air suction from rear side.

C: 3D115157A



FXDQ50TV1C  
FXDQ50TV1CA





NOTES

1. The remote controller can be used to switch 3 steps between High, High and Low. The 3 steps are High, High and Low.
2. The air flow is set to 'standard' before leaving the factory. It is possible to switch between 'Standard ESP' and 'High ESP' with the remote controller.
3. The fan curves are tested with air suction from rear side.

C: 3D115158A

FXDQ63TV1C  
FXDQ63TV1CA




NOTES

1. The remote controller can be used to switch 3 steps between High, High and Low. The 3 steps are High, High and Low.
2. The air flow is set to "standard" before leaving the factory. It is possible to switch between "Standard ESP" and "High ESP" with the remote controller.
3. The fan curves are tested with air suction from rear side.

C: 3D115159A

# 10. Sound Levels

## FXDQ20TV1C FXDQ20TV1CA



**OPERATING CONDITIONS**

POWER SOURCE : 230V 50Hz  
 RETURN AIR TEMPERATURE : 27 °C DB, 19 °C WB  
 COOLING OUTDOOR TEMPERATURE : 35 °C DB, 24 °C WB  
 RETURN AIR TEMPERATURE : 20 °C DB, 15 °C WB  
 HEATING OUTDOOR TEMPERATURE : 7 °C DB, 6 °C WB  
 EXTERNAL STATIC PRESSURE : 10Pa

**OVERALL (dB)**


SCALE	HH	H	L
A	32	30	28

(B. G. N. IS ALREADY RECTIFIED)

**MEASURING PLACE**


**ANECHOIC CHAMBER**

NOTE: Operation noise differs with operation and ambient conditions.



4D115188A

## FXDQ25TV1C FXDQ25TV1CA



**OPERATING CONDITIONS**

POWER SOURCE : 230V 50Hz  
 RETURN AIR TEMPERATURE : 27 °C DB, 19 °C WB  
 COOLING OUTDOOR TEMPERATURE : 35 °C DB, 24 °C WB  
 RETURN AIR TEMPERATURE : 20 °C DB, 15 °C WB  
 HEATING OUTDOOR TEMPERATURE : 7 °C DB, 6 °C WB  
 EXTERNAL STATIC PRESSURE : 10Pa

**OVERALL (dB)**


SCALE	HH	H	L
A	33	30.5	28

(B. G. N. IS ALREADY RECTIFIED)

**MEASURING PLACE**

**ANECHOIC CHAMBER**


NOTE: Operation noise differs with operation and ambient conditions.



4D115189A



**FXDQ32TV1C**  
**FXDQ32TV1CA**




**OPERATING CONDITIONS**  
 POWER SOURCE : 230V 50Hz  
 RETURN AIR TEMPERATURE : 27 °C DB, 19 °C WB  
 COOLING OUTDOOR TEMPERATURE : 35 °C DB, 24 °C WB  
 RETURN AIR TEMPERATURE : 20 °C DB, 15 °C WB  
 HEATING OUTDOOR TEMPERATURE : 7 °C DB, 6 °C WB  
 EXTERNAL STATIC PRESSURE : 10Pa

**OVERALL (dB)**

SCALE	HH	H	L
A	33	30.5	28

(B. G. N. IS ALREADY RECTIFIED)


**MEASURING PLACE**  
ANECHOIC CHAMBER



NOTE: Operation noise differs with operation and ambient conditions.

4D115190A

**FXDQ40TV1C**  
**FXDQ40TV1CA**




**OPERATING CONDITIONS**  
 POWER SOURCE : 230V 50Hz  
 RETURN AIR TEMPERATURE : 27 °C DB, 19 °C WB  
 COOLING OUTDOOR TEMPERATURE : 35 °C DB, 24 °C WB  
 RETURN AIR TEMPERATURE : 20 °C DB, 15 °C WB  
 HEATING OUTDOOR TEMPERATURE : 7 °C DB, 6 °C WB  
 EXTERNAL STATIC PRESSURE : 10Pa

**OVERALL (dB)**

SCALE	HH	H	L
A	34	31.5	29

(B. G. N. IS ALREADY RECTIFIED)


**MEASURING PLACE**  
ANECHOIC CHAMBER




NOTE: Operation noise differs with operation and ambient conditions.

4D115191A

**FXDQ50TV1C  
FXDQ50TV1CA**



**OPERATING CONDITIONS**  
 POWER SOURCE : 230V 50Hz  
 RETURN AIR TEMPERATURE : 27 °C DB, 19 °C WB  
 COOLING OUTDOOR TEMPERATURE : 35 °C DB, 24 °C WB  
 RETURN AIR TEMPERATURE : 20 °C DB, 15 °C WB  
 HEATING OUTDOOR TEMPERATURE : 7 °C DB, 6 °C WB  
 EXTERNAL STATIC PRESSURE : 10Pa



**OVERALL (dB)**

SCALE	HH	H	L
A	35	32.5	30


(B. G. N. IS ALREADY RECTIFIED)

**MEASURING PLACE**  
ANECHOIC CHAMBER


NOTE: Operation noise differs with operation and ambient conditions.

4D115192A

**FXDQ63TV1C  
FXDQ63TV1CA**



**OPERATING CONDITIONS**  
 POWER SOURCE : 230V 50Hz  
 RETURN AIR TEMPERATURE : 27 °C DB, 19 °C WB  
 COOLING OUTDOOR TEMPERATURE : 35 °C DB, 24 °C WB  
 RETURN AIR TEMPERATURE : 20 °C DB, 15 °C WB  
 HEATING OUTDOOR TEMPERATURE : 7 °C DB, 6 °C WB  
 EXTERNAL STATIC PRESSURE : 10Pa



**OVERALL (dB)**

SCALE	HH	H	L
A	37	35	33

(B. G. N. IS ALREADY RECTIFIED)

**MEASURING PLACE**  
ANECHOIC CHAMBER


NOTE: Operation noise differs with operation and ambient conditions.

4D115193A

# 11. Centre of Gravity

FXDQ20TV1C / FXDQ25TV1C / FXDQ32TV1C  
FXDQ20TV1CA / FXDQ25TV1CA / FXDQ32TV1CA


Unit: mm



4D117681

FXDQ40TV1C / FXDQ50TV1C  
FXDQ40TV1CA / FXDQ50TV1CA


Unit: mm



4D117682

FXDQ63TV1C  
FXDQ63TV1CA

Unit: mm



4D117683

## 12. Accessories

### 12.1 Optional Accessories (for Controls)

Item	Model					
	FXDQ20TV1C	FXDQ25TV1C	FXDQ32TV1C	FXDQ40TV1C	FXDQ50TV1C	FXDQ63TV1C
	FXDQ20TV1CA	FXDQ25TV1CA	FXDQ32TV1CA	FXDQ40TV1CA	FXDQ50TV1CA	FXDQ63TV1CA
3D Auto swing discharge grille	BDG20A09			BDG20A15		BDG20A20
Auto clean air filter unit	BAE20A62			BAE20A82		BAE20A102
Wired remote controller	BRC1E63 (Note 4)					
Wireless remote controller	Cooling Only	BRC4C66 (Note 4)				
	Heat Pump	BRC4C65 (Note 4)				
Simplified remote controller	BRC2C51					
Remote controller for hotel use	BRC3A61					
Adaptor for wiring	KRP1C64 ★1					
Wiring adaptor for electrical appendices (1)	KRP2A61 ★1					
Wiring adaptor for electrical appendices (2)	KRP4AA51 ★1					
Remote sensor	KRCS01-4B					
Installation box for adaptor printed circuit board	BRP9A90					
Adaptor for multi tenant	DTA114A61 ★1 (Note 5)					
Multi Tenancy Kit	KRP114A3 (Note 5)					

C: 4D117695A

#### Notes:

1. Installation box is necessary for each adaptor marked ★1.
2. Only one adaptor can be fixed for installation box.
3. Only one installation box can be installed for each indoor unit.
4. Wireless remote controller does not have AUTO fan mode.  
Use wired remote controller to select AUTO fan mode.
5. Only applicable to FXDQ-TV1C.

---

## Air Conditioner

---

### MODELS

Ceiling-mounted duct type  
low static pressure unit

FXDQ20TV1C(A)

FXDQ25TV1C(A)

FXDQ32TV1C(A)

FXDQ40TV1C(A)

FXDQ50TV1C(A)

FXDQ63TV1C(A)

---

Before installation, please read this installation manual carefully, and after reading,  
please keep it well for future reference.

---





## CONTENTS

1. SAFETY PRECAUTIONS.....	1
2. BEFORE INSTALLATION.....	2
3. SELECTING INSTALLATION SITE.....	3
4. PREPARATIONS BEFORE INSTALLATION.....	3
5. INDOOR UNIT INSTALLATION.....	4
6. REFRIGERANT PIPING WORK.....	5
7. DRAIN PIPING WORK.....	6
8. INSTALLING THE DUCT.....	8
9. ELECTRIC WIRING WORK.....	8
10. WIRING EXAMPLE.....	10

### 1. SAFETY PRECAUTIONS

The air conditioner is a Level A product. When it is used in house, there is possibility of causing radio interference, and in case of such phenomena, the user shall take the corresponding countermeasures. Before installing the air conditioner, please carefully read the "SAFETY PRECAUTIONS" to ensure correct installation. **This air conditioner comes under the term "appliances not accessible to general public".** The precautions indicated below are divided into two types. The two types of precautions are related to safety and very important, so please carefully read the precautions.

-  **WARNING**.....Situations as death or severe injury can occur in case of noncompliance.
-  **CAUTION**.....Situations as injury or damage to the machine can occur in case of noncompliance. Depending on different situations, situations as severe injury can occur.

After installation, please carry out test run to confirm whether the machine operates normally. And please give instructions on the use and maintenance of the air conditioner to the user. Ask the user to keep the installation manual and the operation manual well for future references.

#### **WARNING**

- The installation work shall be carried out by the dealer or professional personnel. Do not operate by yourself without authorization. Incorrect installation may lead to water leakage, electrical shock and fire.
- Please follow the steps in the instruction manual to install. Incorrect installation may lead to water leakage, electrical shock and fire.
- When it is installed in a small room, the corresponding measures shall be taken to prevent the concentration of the refrigerant in the room from exceeding the limit in case of any leakage of the refrigerant. Please consult the dealer for the corresponding countermeasures. When the concentration of the refrigerant in a confined space is too high, insufficient oxygen can occur.
- Always use the specified parts to install. In case that the installation is not carried out with the specified parts, such issues as air conditioner falling, water leakage, electrical shock, fire or incorrect operation can occur.
- Please install the air conditioner in a firm place which is sufficient to withstand its weight. In case that the base is not firm, the air conditioner may fall down and damages can occur.
- Take full considerations on influences from strong wind, typhoon and earthquake, and reinforce the installation. Incorrect installation can lead to falling off of the air conditioner and result in accidents.

- Always use separate circuits to supply the power. Any electrical work shall comply with the local laws and regulations, and at the same time follow the installation instruction manual to ask a qualified professional electrician to carry out the work. Insufficient capacity or incorrect electrical work can lead to electrical shock or fire.
- Use cables with the specified specifications, and all the cables shall be reliably connected, and the wiring terminals and the cables are not tensioned by any external force. Poor wiring and incorrect installation can lead to fire.
- When connecting the power cable, remote control cable or transmission cable, they shall be routed orderly and placed even, so that the electrical box cover can be covered tightly. In case that the cover cannot be covered evenly, problems as electrical shock, fire or overheating of the electrical box can occur.
- During installation, in case that any refrigerant gas leaks out, please open the door and window immediately to exchange the air. When the refrigerant gas is in contact with fire, poisonous gas can be generated.
- After complete installation, please check whether there is any refrigerant gas leakage. In case that any refrigerant gas is leaked out in the room and is in contact with any fire source, such as heater, oven and furnace, poisonous gas can be generated.
- Before touching any electrical part, please switch off the power supply.
- Never touch any switch with any wet hand. Touching any switch with any wet hand can lead to electrical shock.
- The air conditioner must be grounded. Never connect the grounding cable to any gas pipe, running water pipe, lighting rod and telephone line. Poor grounding can lead to electrical shock.
- In case that the connected outdoor unit is of 24 kW or below, the remote control cable and the connection cable shall be grounded noiselessly.
- An electricity leakage circuit breaker shall be installed. If no electricity leakage circuit breaker is not installed, electrical shock or fire can occur.
- The indoor unit shall be installed in a place with a height which cannot be reached by children - at least 2.3m above the floor.

#### **CAUTION**

- Please follow the installation manual to set the water drainage pipe to ensure smooth water drainage, and heat insulate the pipe to prevent condensate from building up. Poor piping can lead to water leakage and soaking articles in house.
- The indoor unit, outdoor unit, power cable and connection cable shall be separated from the TV set and radio for at least 1 m, so as to prevent any electromagnetic interference and noise. (For radios with some bands, even they are separated for over 1 m, noise cannot be fully prevented.)
- In houses with fluorescent light (variable frequency or fast start type) installed, possibly the signal transmission distance of the remote control (wireless) cannot reach the expected value. The farther the indoor unit is installed from the fluorescent light, the better the performance is.
- The air conditioner is not suitable to be installed in the following places:
  - (a) Places in which there is mineral oil mist or spray or vapor, such as in the kitchen. The plastic parts can be deteriorated and damaged and lead to water leakage.



- (b) Places in which corrosive gas can be generated, such as sulfur dioxide.  
The copper pipes or welded parts can be corroded and lead to refrigerant leakage.
  - (c) Places near any machine which generates electromagnetic wave.  
Electromagnetic wave can have influence on the control system, so the air conditioner cannot work properly.
  - (d) Places in which any combustible gas is leaked out, any carbon fiber or combustible powder floats, or volatile combustible gas such as gasoline or thinner is stored.  
In case that the air conditioner is used in such places, fire can occur.
- Please never touch any fin of the heat exchanger. Improper touching can cause damages.
  - Please pay special attention to the transport of the product. PP packing straps are used for some products. Please never lift and pull the PP packing straps to transport. It is dangerous.
  - For the sake of safety, please discard the packing materials. Packing materials such as nails and timbers can lead to stabbings or other harms. Please tear off and discard the plastic bags, so as to prevent children from playing with plastic bags and leading to suffocation.
  - Please do not switch off the power supply when the operation is just stopped. Please wait for at least 5 minutes before switching off the power supply. Otherwise water leakage and other problems can occur.
  - Depending on different setting environment, electromagnetic interference can occur for different products. In this case, keep proper distance from the product.

Please follow the State standards to carry out the installation work.

## 2. BEFORE INSTALLATION

**Before the installation work is completed, please never discard any accessory which may be required during installation. Never discard!**

1. Determine the route for moving in the air conditioner in advance.
2. Before moving the air conditioner to the place of installation, never unpack it. In cases that the air conditioner has to be unpacked, soft ropes shall be used when hoisted up or a protection plate shall be placed in the point of the hoisting cable, so as to prevent the air conditioner from damage or scratching.

**When moving the air conditioner whether when it is being unpacked or after it is unpacked, please hold the hoisting bracket base. Never apply force on the refrigerant pipe, water drainage pipe or plastic parts.**




Before installing the air conditioner, please confirm whether the refrigerant used is R410A refrigerant. For the installation of the outdoor unit, please make references to the installation manual for the outdoor unit.





### 2-1 Notes

- Please tell the correct operating methods of the various functions as well as the temperature adjustment methods of the air conditioner to the user, and ask the user to read the operation manual and carry out operations at the same time.
- The air conditioner is not suitable to be installed in places in which high content of salt is contained in the air, such as coast; and is not suitable in places in which the fluctuation of voltage is high, such as factory. The air conditioner is also not suitable to be used in vehicles or ships.

### 2-2 Accessories

Please check whether the following articles are supplied with the air conditioner.

Name	Metal clip	Water drainage hose	Hanger metal
Quantity	1 piece	1 piece	4 pieces
Shape			

Name	Bolt for hangers	Insulation piece for connector	Banding tie	(Other)
Quantity	1 set	1 piece each	1 set	
Shape	 8 pieces	 For liquid pipe  For air pipe	 8 pieces	<ul style="list-style-type: none"> <li>• Operation manual</li> <li>• Installation manual</li> <li>• Conforming certificate of product</li> </ul>

### 2-3 Optional parts

- The indoor unit needs one remote control for operations as listed in the following table.

Remote control			Applicable model
Wired R/C		BRC1E62 (3 ranges) BRC1E63 (5 ranges)	FXDQ ~ TV1C(A)
Wireless R/C	H/P	BRC4C65 (3 ranges)	
	C/O	BRC4C66 (3 ranges)	

**During installation work and during inspection after completion of installation, pay special attention to the following points.**

#### a. Key points to be inspected after completion of installation.



Items of Inspection	Results possibly occurring in case of any error	Inspected and signature
Are the indoor unit and outdoor unit installed firmly?	The air conditioner falls off, vibrates and sends out noise.	
Has air leakage inspection been carried out?	There is no sufficient cool air or hot air.	
Is the heat insulation good? (Refrigerant pipe, water drainage pipe and air pipe)	Condensate drips off.	
Is water smoothly drained off?	Water leaks out.	
Is the power voltage consistent with the one specified on the nameplate of the machine?	The machine cannot work normally or parts are burnt off.	
Is the connection of the cable and the pipe correct?	The machine cannot work normally or parts are burnt off.	
Is the air conditioner safely grounded?	Once there is electricity leakage, it is very dangerous.	
Are cables with the specified specifications used?	The machine cannot work normally or parts are burnt off.	
Are the suction inlet and air blow outlet of the indoor unit and the outdoor unit blocked by anything?	There is no sufficient cool air or hot air.	
Have the length of the refrigerant pipe and the filled amount of refrigerant been recorded?	The amount of the refrigerant of the air conditioning system is unknown.	

At the same time, please make references to Section "SAFETY PRECAUTIONS".

## b. Key points during inspection when handing over

Items of inspection	Inspected and signature
Was the user explained on the operating methods in accordance with the operation manual?	
Was the operation manual handed over to the user?	
Was the user instructed on the operating methods and cleaning methods of the parts supplied on site (air filter element and grille (suction inlet and air blow outlet), etc.)?	
In case that there is operation manual for any part supplied on site, is the operation manual handed over to the user?	

## c. Key points on explanation of the operating methods

The sections with a  Warning and a  Caution symbol in the operation manual emphasize such issues as possible personal injury and damage to properties arising from failure to comply with the normal methods to use the air conditioner. The contents on the precautions shall be completely and clearly explained to the user, and the user shall be asked to read the operating section in this operation manual.


## 3. SELECTING INSTALLATION SITE

### CAUTION

- When moving the air conditioner when it is being unpacked or after it is unpacked, the hoisting bracket base shall be held, but no force shall be applied on any other parts, especially to the refrigerant pipe, water drainage pipe and the flange parts.
- In case that the temperature and humidity in the lamination in the ceiling are over 30°C and RH 80%, please apply insulation material on the body of the unit. Please use glass wool or foamed polyethylene as the insulation material, and the thickness shall be over 10 mm, and it shall be able to be accommodated in the opening in the ceiling.

### (1) Select a place complying with all of the following conditions and meeting the requirements of the user to install the air conditioner.

- Ensure that the ventilation is good.
- The airflow is not blocked by any barrier.
- The condensate can be smoothly drained off.
- The strength of the ceiling can withstand the weight of the indoor unit.
- The ceiling is not obviously tilted.
- There is no hazard of possible leakage of combustible gas.
- There is enough space for service and maintenance. **(Please refer to Fig. 1)**
- The length of the pipe between the indoor unit and the outdoor unit is within the allowable range. **(Please refer to the installation manual for the outdoor unit.)**



- The size of \*H in the above figure stands for the minimum height of the air conditioner.
- When selecting \*H, the downward slope of at least 1/100 for the water drainage pipe shall be ensured, as shown in Section "7. DRAIN PIPING WORK".

### [Notes]


- To prevent image interference or noise, when installing the indoor unit, outdoor unit, power cable and transmission cable, they shall be at least 1 m from the TV set or radio. (As the radio wave is different, sometimes it cannot be ensured that interference can be prevented even if the distance is 1 m.)
- In case that the wireless remote control assembly is installed in houses with fluorescent light (variable frequency or fast start type), possibly the signal transmission distance of the remote control can become shorter. The indoor unit shall be installed far from the fluorescent light as possible.

- (2) Use hanging bolt to install. Please check whether the ceiling is firm enough to withstand the weight of the indoor unit. In case that there is possibility that the ceiling is not firm, please reinforce it in advance. (Please refer to the installation interval marked on the packing carton to check whether reinforcement is required.)

## 4. PREPARATIONS BEFORE INSTALLATION

### (1) Please confirm the position relationship between the unit and the hanging bolt. (Please refer to Fig. 2)

- Set the inspection opening on the side of the electrical box to facilitate the maintenance and inspection of the electrical box and the water drainage pump.



**Note** 

(Unit: mm)

Model	A	B
FXDQ20 ~ 32	752	700
FXDQ40 ~ 50	952	900
FXDQ63	1152	1100

**(2) Please confirm whether the static pressure outside the air conditioner exceeds the allowable range.**


(For the setting range of the static pressure outside the air conditioner, please refer to the technical documents.)

**(3) Make the opening for installation. (Where ceiling has been built up)**

- When the opening for installation is made in the ceiling in the installation position, put the refrigerant pipe, water drainage pipe, transmission cable, and remote control cable (in case of wireless remote control, there is no cable) through the opening to the pipe and cable connection interface of the unit. Please refer to Section “6. REFRIGERANT PIPING WORK”, “7. DRAIN PIPING WORK” and “10. WIRING EXAMPLES”.
- When the opening is made in the ceiling, to keep the level of the ceiling and prevent vibration, please reinforce such sections of the ceiling as the beam bracket as required. For details, please consult the professional construction decoration personnel.

**(4) Install the hanging bolt.**



(Please use W3/8 or M10 hanging bolt.)  
To reinforce the withstanding strength of the ceiling for the weight of the air conditioner, anchor bolts can be installed into the existing ceiling, and pile anchor screws and pile anchor bolts can be built in the new ceiling, and other items purchased in the market can be used. **(Please refer to Fig. 3)**



Note: All of the above items are supplied on site. **Fig. 3**


**(5) In case the air is supplied from the bottom, follow the sequences in Fig. 4 to retrofit the box cover.**

- (1) Remove the box cover.
- (2) Please follow the direction in Fig. 4 to reinstall box cover removed.



**Fig. 4**

- Positioning of the screws of the E-box based on the installation.




**5. INDOOR UNIT INSTALLATION**

**(During the installation work, always use the accessories supplied with the machine and parts complying with the specified specifications.)**

**(1) Temporarily installing the indoor unit.**

- Hang the hoisting bracket base on the hanging bolt. Always use the nut and washer to fix the upper and lower side of the hoisting bracket base.




**[Note]** As resin water drainage pan is used for the air conditioner, during the installation work, please prevent any welding spark and any other foreign object from entering into the air blow outlet.

**(2) Adjust the height of the unit.**

**(3) Correct the level of the air conditioner.**

**— CAUTION —**

- Use a water level or water filled polyethylene pipe to confirm whether the air conditioner is installed horizontally. When a PE pipe is used to replace a water level, please align the upper surface of the unit with the horizontal level of both sides of the PE pipe, to adjust the level of the unit. **(Pay special attention that the tilting direction shall not be reversed against the water drainage direction as this will result in water leakage)**



**Fig. 5**

**(4) Tighten the nut on the upper side.**

## 6. REFRIGERANT PIPING WORK

(For the installation of the refrigerant pipe for the outdoor unit, please refer to the installation manual for the outdoor unit.)

(Heat insulation shall be carried out for the pipes on the gas supply side and the liquid side. Otherwise water may leak out. Please use insulation material which can withstand a high temperature of over 120°C.

Please base on the installation environment to reinforce the heat insulation for the refrigerant pipe.

Otherwise, condensate may occur on the surface of the heat insulation material.)

(Before installing the refrigerant pipe, please always confirm that the refrigerant is R410A. In case that any other refrigerant is used, the air conditioner cannot work normally.)

### ⚠ CAUTION

The product is a special machine using new type refrigerant (R410A). Please always comply with the following items to carry out the installation work.


- Use special pipe cutting machine and flare tools for R410A.
- When connecting the flare, please apply freezing oil (ester oil or ether oil) only on the inside of the flare.
- Always use the flare nut supplied with the air conditioner. (Never use flare nut of any other type, such as Type 1 flare nut, otherwise the refrigerant may leak out.)
- To prevent dirt, dust or moisture from entering into the inside of the pipe, please correct the pipe in the squeezed or sealed manner.

### ⚠ CAUTION

- Please ensure to use refrigerant of the specified type in the refrigeration cycle, and never let the air contaminate the refrigerant.
- In case that during installation any refrigerant is leaked out, the house should be ventilated for air exchange.

### (1) Connect the pipe.

- Refrigerant has been filled in the outdoor unit.
- Align the connecting section of the refrigerant pipe to the center of the flare section, and firstly turn 3 – 4 operations manually, and then tighten the pipe with the specified torque.
  - To prevent the flare section from being broken or leaking air, please tighten with a torque wrench. (Please refer to Fig. 6)
- To prevent gas leakage, please apply freezing oil (ester oil or ether oil) on the inside of the flare. (Please refer to Fig. 7)
- Please fix the flare nut to the main unit. (To prevent the flare nut from aging and cracking)
- For the dimensions of the flare and the tightening torque, please refer to Table 1.



Note : Please always align the center of the connection section of the refrigerant pipe with the center of the flare section and the flare nut. Otherwise pipe breaking or refrigerant leakage can occur.

Table 1

Pipe diameter	Tightening torque	Flare dimension A (mm)	Flare
∅ 6.4 (1/4")	14.2 - 17.2N · m (144 - 176 kgf · cm)	8.7 - 9.1	
∅ 9.5 (3/8")	32.7 - 39.9N · m (333 - 407 kgf · cm)	12.8 - 13.2	
∅ 12.7 (1/2")	49.5 - 60.3N · m (504 - 616 kgf · cm)	16.2 - 16.6	
∅ 15.9 (5/8")	61.8 - 75.4N · m (630 - 770 kgf · cm)	19.3 - 19.7	

### ⚠ CAUTION

**Over-tightening can damage the flare and result in refrigerant leakage. Please note not to let oil stick to any part outside the flare. In case that any oil sticks to parts as resin, damage can occur.**

- In case that a torque wrench is not available, please refer to Table 2.  
When an ordinary wrench is used to tighten the flare nut, the nut will suddenly become tightened in some point. From such point, further tighten the nut to the angle as shown in Table 2.

**It is not recommended to use this method, and it can be used only in emergency cases.**

You must use a torque wrench, but if you do not have a torque wrench and have to install the unit, you can follow the following method to install.

**When you complete the work, always check whether any refrigerant is leaked out.**

When you use a wrench to tighten the flare nut, the tightening torque can suddenly increase in some point. From such point, further tighten the flare nut to the angle as shown below :



Table 2

Pipe dimension	Angle to be further tightened	Recommended length of the tool arm
Ø 6.4 (1/4")	60 to 90 degrees	About 150 mm
Ø 9.5 (3/8")	60 to 90 degrees	About 200 mm
Ø 12.7 (1/2")	30 to 60 degrees	About 250 mm
Ø 15.9 (5/8")	30 to 60 degrees	About 300 mm

(2) When the pipe work is completed, please confirm whether any refrigerant is leaked out.

(3) When it is checked that no refrigerant is leaked out, please refer to Fig. 8 to properly insulate the pipe connections with heat insulation material.

- When carrying out heat insulation work, please use the supplied heat insulation piece for the pipe of the liquid side and the gas supply side. In addition, the connecting seams of the heat insulation piece and for the connector shall face upward. (Please use cable tie to clamp both ends.)
- Please use the middle seal for the connector on the pipe of the gas supply side. (The flare nut section)






Fig. 8

**CAUTION**

The pipe supplied on site must be heat insulated to the connecting section of the pipe. In case that the pipe is exposed, condensate can occur, and injury from burning can also happen if touched.

- Before welding the refrigerant pipe, please firstly carry out nitrogen exchange, or when welding (Caution 2), fill in nitrogen (Caution 1) in the refrigerant pipe, and finally use the flare to connect to the indoor unit. (Refer to Fig. 9)

**CAUTION**

1. In case that nitrogen is filled into the pipe when welding, a relief valve shall be used to control the pressure to 0.02 MPa (0.2 kgf/cm<sup>2</sup>) (as if breeze flows along your cheek).
2. When welding the connection section of the refrigerant pipe, never use any welding flux. Please use phosphorus and bronze brazing material (BCuP-2: JIS Z 3264/BCu93P-710/795: ISO 3677) which does not need welding flux. (In case that any welding flux containing chlorine is used, the pipe can be corroded; and in case that any welding flux containing fluorin is used, the ester oil or ether oil can be deteriorated, and the refrigerant pipe system can be further influenced.)





Fig. 9

**7. DRAIN PIPING WORK**

**CAUTION**

- The connecting interface of the water drainage pipe varies depending on different types, so please confirm the name of the type, and use the installation method suitable for the type.

(1) Install the water drainage pipe.



- When installing the water drainage pipe, ensure that the water drainage is smooth.
- The diameter of the water drainage pipe shall be larger than or equal to that of the connection pipe (polyethylene pipe; pipe dimensions: 20 mm; outer diameter: 26 mm). (Not including the riser pipe)

- The water drainage pipe shall be short as possible and tilt downward, and the slope shall be at least 1/100, so as to prevent the forming of any air trap. (Refer to Fig. 10)




Fig. 10

Integrated water drainage pipe  
(with a download slope of at least 1/100)

### CAUTION

In case that there is any accumulated water in the water drainage pipe, blockage can occur.

- To prevent the pipe from sagging, a hanging cable shall be used to hang it up every 1 ~ 1.5 m.
- Please use the water drainage hose and metal clip in the accessories. The water drainage hose shall be inserted to the bottom of the water drainage insertion opening, and the metal clip shall be used for firm fixing on the marking band in the front of the hose. Tighten the metal clip, until the protruding height of the bolt head is less than 4 mm. (Please refer to Fig. 11 and 12)
- The following two points shall be heat insulated, so as to prevent any condensate dripping.
  - The indoor water drainage hose
  - The water drainage insertion opening
 Please refer to the following figure to use a large seal to carry out heat insulation for the metal clip and the water drainage hose. (Please refer to Fig. 12)




Fig. 11




Fig. 12

### (Precautions on installing the water drainage riser pipe)

- Please confirm that the height of the water drainage riser pipe is within 600 mm.

- Please keep the water drainage riser pipe vertical, and ensure that the distance from the air conditioner is within 300 mm. (Refer to Fig. 13)




Fig. 13

### (Notes)

#### Water drainage pipe connection

- Never directly connect the water drainage pipe to any sewage with an ammonia smell. The ammonia in the sewage can enter into the indoor unit along the water drainage pipe and corrode the heat exchanger.
- Never twist or bend the water drainage hose, and never apply too high force on it. (Otherwise water leakage can occur.)
- In case that an integrated water drainage pipe is used, please connect it as shown in Fig. 10.
- Please select the integrated water drainage pipe with proper dimensions in accordance with the capacity of the air conditioner to be connected.

(2) When the pipe work is completed, please check whether the water drainage is smooth.

**CAUTION**

- The electrical wiring work shall be carried out by qualified professional electricians.
- When the professional electrician is not on site, please follow Step 3 ~ 7 after the system test run is completed to carry out drainage to confirm that it works.

1. Remove the electrical box cover, and then connect the remote control cable and the power cable (Power supply: Single phase, 50 Hz, 220-240 V) to their corresponding terminal block. Also connect the grounding cable. (Refer to the below figure)

**CAUTION**

To prevent the wiring connection from being pulled by extra tension, please follow the methods as shown in Fig. 14 to fix firmly with cable clamp.

2. Before switching on the power supply, please confirm whether the electrical box cover has been completely covered.
3. Please remove the repair cover.
4. Slowly fill about 1000 cc water into the water drainage pan from the repair opening, so as to check the water drainage situations.

**CAUTION**



Please never apply any external force to the floating valve switch. (Otherwise error can occur.)

5. Please install the repair cover.
6. Please carry out the test operations from the remote control so as to check the water drainage situations. Please refer to the manuals supplied with BRC1E remote controller for detailed procedures.

**ALSO REFER TO INSTALLATION MANUAL SUPPLIED WITH OUTDOOR UNIT.**

**CAUTION**

Please note that the fan is also running at this time. Please never touch the water drainage pump to prevent any electrical shock.




7. Please always use the remote control to switch off to stop water drainage and confirm that it works.

## 8. INSTALLING THE DUCT

Please connect the air duct supplied on site.

### Air inlet side

- Air filter is supplied as standard on the unit. If duct is required, remove the filter before connecting duct.
- Please install the flange (supplied on site) on the air supply side.
- Please use bolts (supplied on site) to connect the flange and the main body of the air conditioner.
- Use sealing materials such as aluminum adhesive tape to seal the connection section between the flange and the air pipe on the air inlet side, so as to prevent air leakage.



### Air outlet side

- Connect the air pipe to the inside of the flange in the air supply side.
- Use sealing materials such as aluminum adhesive tape to seal the connection section between the flange and the air pipe on the air outlet side, so as to prevent air leakage.

**CAUTION**

- Always use heat insulation material to prevent condensate on the air duct. (Material: Glass wool or foamed polyethylene, thickness: 25 mm).
- In case that the metal air duct passes any metal wire, metal wire net or metal plate of any wood structure, ensure that the air duct and the wall are (electrically) insulated.
- Please instruct the operating methods and cleaning methods of the parts supplied on site to the user (auto clear air filter, grille (suction inlet and blow outlet), etc.).
- Please follow BRC1E installation manual to set unit ESP within allowable range, failure to do so may result in higher power input.

## 9. ELECTRIC WIRING WORK

### 9-1 General

- Before carrying out any electrical work, always switch off the power supply.
- Any part and material locally purchased as well as any electrical work shall comply with the local regulations.
- Always use copper cables.
- When carrying out electrical wiring work, please also refer to the "Wiring Diagram" attached to the electrical box cover.
- For details on the wiring of the remote control, please refer to the "Installation instruction manual for remote control" supplied with the remote control.
- Any wiring work shall be carried out by qualified professional electricians.
- If the system consists of many indoor units. Please name the individual indoor units as Unit A, Unit B, ..., and confirm whether the cables connecting from the terminal board to the outdoor unit and the BS device match accordingly. In case that any connection of the cables or pipes between the outdoor unit and the indoor unit is incorrect, the air conditioning system will not work normally. To prevent any error, please refer to [Wiring Examples] for wiring.
- Wire circuit breaker or electricity leakage circuit breaker must be installed in the power supply point.
- The grounding resistance must be below 4 Ω.

- Never connect the grounding cable to any gas pipe, running water pipe, lighting rod or telephone line.
- Gas pipe : Once any gas is leaked out, explosion and fire can happen.
- Running water pipe: In case that hard plastic pipe is used, there will be no grounding function.
- Telephone grounding line and lighting rod : When struck by lightning, the grounding potential will become exceptionally high.
- To prevent short circuiting of the power cable, insulated sleeve terminals must be used.
- Before all the electrical work is completed, no power supply shall be switched on (wire circuit breaker or electricity leakage circuit breaker).

## 9-2 Specifications of standard wiring parts

### Power cable, etc.

Power cable (including grounding cable)			
Number of units	Site fuse	Cable	Dimensions
1	16A	H05VV-U3G	Comply with the local regulations.


Transmission cable and remote control cable			
Cable (Note 5)			Dimensions (mm <sup>2</sup> )
• Cases that the connected outdoor unit is 24 kW or below	• Cases that the connected outdoor unit is above 24 kW		
Shielded cable RVVP	Polyethylene sleeve flexible cable or power cable		0.75 - 1.25


### Notes

1. Over-current circuit breaker can be used to replace the fuse.
  2. The above Type H05VV cable is minimum specification for installation. Local standard must be conformed for alternative cables(AS/NZS 3000).
  3. In case that the cable is within a place easily in contact with people, please install an electricity leakage circuit breaker to prevent electrical shock.
  4. When an electricity leakage circuit breaker is used, please use a device compatible with grounding over-current protection and short circuit protection. When one special grounding protection device is used in the electricity leakage circuit breaker, always use a wire circuit breaker at the same time.
  5. When the connected outdoor unit is 24 kW or below, the transmission cable and remote control cable shall be shielded.
- The length of the transmission cable and remote control cable is limited as below.

### Length of the transmission cable and remote control cable

Type of outdoor unit connected	• Horizontal blow type outdoor unit connected	• Upward blow type outdoor unit connected
Outdoor unit – indoor unit	Max. length 300 m (Total cable length : 600 m)	Max. length 1000 m (Total cable length : 2000 m)
Indoor unit – remote control	Max. length 300 m	Max. length 500 m

- The shielded sections shall be wrapped with materials as insulated adhesive tape to prevent contact with any other terminal.
  - The end of the shielded sections shall be closely connected to the noiseless grounding point marked with .
  - Shield wire materials may be used for transmission wiring, and must comply with EMI (AS/NZS 3548) or (CISPR 14).
6. The specifications of the fuse on the circuit board(s) is: 250V, 3.15A (F1U)

 **WARNING** : When the fuse is blown out, please have it replaced by a repair agency, but never replace it by yourself. Otherwise accidents as electrical shock can happen.

7. As the unit is equipped with a frequency converter, to prevent misoperation of the electricity leakage circuit breaker itself, please use a product which can resist against high harmonic wave.

## 9-3 Electrical features

Model	Power supply					Fan motor	
	Hz	Volts	Voltage range	MCA	MFA	kW	FLA
FXDQ20	50	220 - 240V	Max 264V Min 198V	0.6	15	0.078	0.5
FXDQ25				0.8		0.078	0.6
FXDQ32				0.9		0.078	0.7
FXDQ40				1.9		0.093	1.5
FXDQ50				2.1		0.093	1.7
FXDQ63				1.8		0.093	1.4

**MCA** : Minimum circuit current (A)

**MFA** : Maximum fuse current (A)

**kW** : Rated output power of the fan motor (kW)

**FLA** : Full load current (A)



## 10. WIRING EXAMPLE

### 10-1 Connection of the power cables

- As shown in the Fig. 14, please open the electrical box cover and then connect the cables.  
(Please refer to Fig. 14)




Fig. 14

### CAUTION

- When fixing the cables, note to follow the method in Fig. 14 to clamp with the cable clamp, so that the connection section will not be tensioned.
- Please use the fixing part to connect the power cable and the grounding cable to the electrical box.
- When connecting the cables, the cables shall be routed orderly and placed even, and the electrical box cover shall not be supported up, and the electrical box cover shall be covered firmly. When covering the electrical box cover, be careful not to clamp any cable.
- Outside the air conditioner, the weak current cables (the remote control cable and the transmission cable) shall not be routed with the strong current cables (the grounding cable and the power cable), but shall be separated for a distance of over 50 mm. Otherwise misoperation and fault can happen due to electrical interference (foreign noise).

### [Notes]

- For the installation and wiring of the remote control, please refer to the "Installation manual for the remote control" supplied with the remote control.
- When connecting the power supply for the air conditioner, please refer to the "Wiring Diagram" on the nameplate at the same time.
- In any circumstances, the power cable shall not be connected to the terminal block of the remote control cable or the transmission cable. Otherwise the whole air conditioning system will be damaged.
- Please connect the remote control cable and the transmission cable to the corresponding terminal block.
- Functional earth is only used for functional purposes only.

### [Connection of the power cable, remote control cable and transmission cable] (Please refer to Fig. 15)





Fig. 15

### Dimensions of the shielded cable processed (indoor connection cable)



- Power cable and grounding cable**  
Open the electrical box cover. Then, route the cables through the cable routing section into the air conditioner, and connect them to the terminal board (3P). In addition, the sleeve of the cables shall be always put into the electrical box. (For FXDQ~TV1CA model only) Route 24VAC power cable into the control box then connect them to the terminal board (2P).
- Remote control cable and transmission cable**  
Route the cables through the cable routing section into the air conditioner, and connect them to the terminal board (6P). In addition, the sleeve of the cables shall be always put into the electrical box.

[Wiring Examples]

**CAUTION**

In case that the connected outdoor unit is 24 kW or below, please comply with the following items.

- For the remote control cable and transmission cable, always use shielded cable, and carry out noiseless grounding. (☆ and \* section)
- In case that wired remote control is used, always use an embedded remote control box (made of metal) on the remote control, and connect the noiseless grounding cable to the embedded remote control box. Then, ground the embedded remote control box additionally.
- In case that wireless remote control is used, always use an embedded remote control box (made of metal) on the remote control signal receiving assembly, and connect the noiseless grounding cable to the embedded remote control box. Then, ground the embedded remote control box additionally.

**System 1 Use 1 remote control to control 1 indoor unit**




Fig. 16

**System 2 Control by group or double control for one unit**




Fig. 17

Use 2 remote controls to control 1 unit

**System 3 Case with BS device installed**





Fig. 18

**(Notes when connecting the power cable)**

- Never connect two cables with different cable diameters to the same power terminal. (Overheating can occur due to causes as loosened cables.)
- When connected to the terminal board, please use round wiring terminal with insulated sleeve. In case that round wiring terminal with insulated sleeve cannot be used, connect the cable of the same cable diameter to both sides of the terminal, as shown in the figure.



**Risks of overheating can happen due to causes such as loosened cables, so please always comply with the following items.**

- Please use power cable of the specified specifications, and firmly connect the power cable, and then confirm whether the power cable is pulled by any external force in the point of the terminal board.
- When tightening the terminal screw, please use a suitable screw driver. In case that the screw driver head is too narrow, the screw head can be damaged, and the screw may not be tightened.
- In case that the terminal screw is over-tightened, it can be damaged.
- For the tightening torque of the terminal screw, please refer to the following table.

Terminal	Tightening torque (N · m)
Terminal board for the remote control / transmission cable (6P)	0.79 - 0.97
Terminal board for the power supply (3P)	1.18 - 1.44
Terminal for noiseless grounding (M4)	1.44 - 1.94

## 10-2 Double controls for one unit (One indoor unit controlled by two remote controls)

- When two remote controls are used, one must be set to "Master", and the other must be set to "Sub". Please refer to the installation instruction manual for the BRC1E remote control.)

### Master / Sub Controller switching


(1) Following is displayed after turn on the power:

**"Checking the connection. Please stand by. "**

During above display, backlight does not light by button operation.

**When 1 indoor unit is controlled by 2 remote controllers:**

Be sure to set sub remote controller during above display. Press and hold for 4 seconds or longer the Mode Selector button of the remote controller to be set. When the display is changed from main remote controller to sub remote controller, the setting is completed.




(2) Basic screen is displayed.

**Cable connecting method (Please refer to Section "Electrical Wiring Work".)**


(3) Remove the electrical box cover.

(4) Connect remote control 2 (Sub) to the terminal board of the remote control cable in the electrical box (P<sub>1</sub> and P<sub>2</sub>). (No polarity.)




### [Notes]

- In case that control by group and double remote controls are used at the same time, it is required to connect a jump cable.
- Please connect remote control 2 (Sub) to the indoor unit at the end of the jump cable (P<sub>1</sub> and P<sub>2</sub>).



## 10-3 Remote operated control (Forced off and on / off operation)

- Connect the input cable from external to Terminal T1 and T2 on the terminal board of the remote control (6P) to carry out remote operated control.
- For the details on the operations, please refer to the instruction manual for remote controller. **"FIELD SETTING AND TEST OPERATION"**.



Cable specifications	Polyethylene sleeve flexible wire or cable (2 cores)
Section area	0.75 - 1.25mm <sup>2</sup>
Length	Max. length 100 m
Specifications of external contactor	Minimum applicable load of the contactor 15V DC, 1 mA.

## 10-4 Cases of integrated control

- In case that integrated control is used, it is required to set the group number. For details, please refer to the instruction manual for integrated control.



**Warning**



- Ask a qualified installer or contractor to install this product. Do not try to install the product yourself. Improper installation can result in water or refrigerant leakage, electrical shock, fire or explosion.
- Use only those parts and accessories supplied or specified by Daikin. Ask a qualified installer or contractor to install those parts and accessories. Use of unauthorised parts and accessories or improper installation of parts and accessories can result in water or refrigerant leakage, electrical shock, fire or explosion.
- Read the user's manual carefully before using this product. The user's manual provides important safety instructions and warnings. Be sure to follow these instructions and warnings.

If you have any enquiries, please contact your local importer, distributor and/or retailer.

### **Cautions on product corrosion**

1. Air conditioners should not be installed in areas where corrosive gases, such as acid gas or alkaline gas, are produced.
2. If the outdoor unit is to be installed close to the sea shore, direct exposure to the sea breeze should be avoided. If you need to install the outdoor unit close to the sea shore, contact your local distributor.

**VRV** is a trade mark of Daikin Industries, Ltd.

**VRV** Air Conditioning System is the world's first individual air conditioning system with variable refrigerant flow control and was commercialised by Daikin in 1982.

**VRV** is the trade mark of Daikin Industries, Ltd., which is derived from the technology we call "variable refrigerant volume."

# **RAPID** RESPONSE

## Header Box Exhaust Fan



**Powerful Performance**  
**Quiet Operation**



The stylish **Rapid Response** header box exhaust fan is the quietest and most powerful in its class. Its aerodynamic and fully optimised design minimises resistance and produces strong, efficient air flow performance.



**FANTECH**  
Intelligent Ventilation



# The quietest and most powerful in its class

The Rapid Response ceiling mounted header box fan features a fully optimised inlet cone and centrifugal impeller that maximises air pressure and ensures rooms are quickly cleared of steam and unpleasant odours. Its clever design includes a unique swing clip and removable spigot that makes it very easy to install.



IPX4



Low noise



Powerful air flow



Easy to install



*Rapid Response fan body available in 8 inch and 10 inch models.*



# Rapid Response Standard Grilles

The stylish and modern Rapid Response grille is available in round and square designs with white or black finish (black finish only available with 10" model).

- Innovative design allows grilles to be easily removed for cleaning
- Available in 2 sizes to suit 8" and 10" Rapid Response header box fan
- Quick and easy to install to fan body
- Can be retrofitted to a previously installed Rapid Response fan




*Round grille with black finish*



*Square grille with black finish*



*Round grille with white finish*



*Square grille with white finish*


# Rapid Response Grilles with LED

The Rapid Response grille with LED light will brighten up any bathroom, ensuite or toilet. They are quick and easy to install, and feature a stylish, modern design to suit any setting. For added convenience the LED light can be controlled separately to the fan.

- Available in round and square designs with white finish
- Available in 2 sizes to suit 8" and 10" Rapid Response fan
- 8" LED model is ideal for toilets and powder rooms, as it combines both a fan and light in-one
- Can be retrofitted to a previously installed Rapid Response fan
- Innovative design allows grilles to be easily removed for cleaning
- Complies to: AS/NZS 60598.2.2:2001 and AS/NZS 60598.1:2013 Certificate No.: SAA152082



*Round grille with LED light*



*Square grille with LED light*






# Rapid Response Selection Guide

## Step 1

### Select fan body size

Calculate room volume in m<sup>3</sup>  
(Length X Width X Height)



Select suitable fan body by matching it with your application and room volume (m<sup>3</sup>) in the table below

Application	8" fan body (RESPF8/T)	10" fan body (RESPF150/T)
Toilets Powder rooms Walk in wardrobes Laundries	Up to 30m <sup>3</sup>	Up to 40m <sup>3</sup>
Bathrooms Ensuites	Up to 10m <sup>3</sup>	Up to 30m <sup>3</sup>

## Step 2

### Select grille type

To suit 8" fan body (RESPF8/T)

To suit 10" fan body (RESPF150/T)

To suit 8" fan body (RESPF8/T)		To suit 10" fan body (RESPF150/T)	
	Square grille white finish (RESPG8-SQWH)		Square grille white finish (RESPG150SQWH)
	Square grille white finish with LED light (RESPG8-SQWH-LED)		Square grille white finish with LED light (RESPG150SQWH-LED)
	Round grille white finish (RESPG8-RNWH)		Square grille black finish (RESPG150SQBK)
	Round grille white finish with LED light (RESPG8-RNWH-LED)		Round grille white finish (RESPG150RNWH)
			Round grille white finish with LED light (RESPG150RNWH-LED)
			Round grille black finish (RESPG150RNBK)

### Easy to install



Long clip-in spigot makes installation and duct connection easier.



Rotate swing clips to hold fan body in place.



Tighten screws so clips clamp onto ceiling board.

**RAPID  
RESPONSE**  
Header Box Exhaust Fan

## Suitable for residential and light commercial applications


The modern and stylish Rapid Response header box fan is suitable for residential and light commercial buildings in applications such as toilets, bathrooms, laundries and ensuites. Its low profile, compact design and side exhaust outlet makes it suitable for mounting between floors and applications with limited ceiling space such as those with cathedral ceilings.

The Rapid Response housing is made from quality injected moulded, fire retardant, ABS plastic giving it a robust construction and reliable operation.

There are two sizes available; an 8 inch model and a 10 inch model, that are available with a 3 to 15 minute run-on timer. Both sizes are also available with modern looking round and square grilles that can include a high quality LED light (white finish models only).

## Features and benefits

- The ultra quiet 8" model is ideal for odour and dampness removal from areas such as powder rooms, toilets, ensuites and walk in wardrobes
- 10" model provides stronger air flow performance to ensure steam is cleared from rooms such as bathrooms and ensuites
- Advanced impeller and housing design provides powerful air flow and minimises noise
- Can be retrofitted into an existing standard 8" and 10" round fan cutout
- Low resistance non-return backdraft damper maximises air flow performance
- Includes sealed for life ball bearings
- High strength swing clips make installation easy
- Available with stylish and modern square and round grilles
- Square grille can be easily rotated to align with walls




*Optimised inlet cone and impeller blade design maximises air pressure.*



# Fan Body

## Dimensional Data

Model Number	Dimensions, mm				App Weight (kg)
	Cut Out AØ	B	C*	D*	
RESPF8	250	195	94 (100mm spigot)	105 (100mm spigot)	2
RESPF8-T			170 (150mm spigot)	120 (150mm spigot)	
RESPF150	290	197	170	120	3
RESPF150T					



\*RESPF8 comes with spigot to suit both 100mm and 150mm duct.

RESPF150 comes with spigot to suit 150mm duct only.

## Technical Data



Model Number	Run-on timer	Air flow <sup>#</sup>		Fan Speed rev/sec	Average Sound Level dB(A) @ 3m	Watts	Volts
		m <sup>3</sup> /hr	L/sec				
RESPF8	No	216	60	18	29	30	240
RESPF8-T	Yes						
RESPF150	No	349	97	18	37	60	240
RESPF150T	Yes						

<sup>#</sup> Air flow without duct and fittings

# Grilles

## Dimensional Data

	Model Number	Description	Dimensions, mm			
			A□	B	CØ	D
8" Grille	RESPG8-SQWH	8" Square Grille White Finish	300	28	-	-
	RESPG8-SQWH-LED	8" Square Grille White Finish with LED Light	300	28	-	-
	RESPG8-RNWH	8" Round Grille White Finish	-	-	294	19
	RESPG8-RNWH-LED	8" Round Grille White Finish with LED Light	-	-	294	19
10" Grille	RESPG150SQWH	10" Square Grille White Finish	353	30	-	-
	RESPG150SQBK	10" Square Grille Black Finish	353	30	-	-
	RESPG150SQWH-LED	10" Square Grille White Finish with LED Light	353	30	-	-
	RESPG150RNWH	10" Round Grille White Finish	-	-	332	24
	RESPG150RNBK	10" Round Grille Black Finish	-	-	332	24
	RESPG150RNWH-LED	10" Round Grille White Finish with LED Light	-	-	332	24



## LED Grilles Specifications

Model Number	Lumens (LM)	Input power (W)	Colour Temp (K)	Beam Angle (°C)
RESPG8-SQWH-LED	1000	12	4200	180
RESPG8-RNWH-LED	800	9	4200	180
RESPG150SQWH-LED	1000	12	4200	180
RESPG150RNWH-LED	800	9	4200	180



Scan the QR Code for more information



### Fantech Pty. Ltd.

Victoria: (+61 3) 9554 7845  
 New South Wales: (02) 8811 0400  
 South Australia: (08) 8294 0530  
 Northern Territory: (08) 8947 0447  
 Queensland: (07) 3299 9888  
 Western Australia: (08) 9209 4999  
 A.C.T.: (02) 6280 5511  
 New Zealand: (09) 444 6266

[www.fantech.com.au](http://www.fantech.com.au) |

For sales enquiries contact:

Specifications and design subject to change without notice.



A



## DESCRIPTION

The Fantech Velocity ceiling mounted header box fan features quiet operation and powerful air flow performance. It includes a fully optimised inlet cone and centrifugal impeller that maximises air pressure and ensures rooms are quickly cleared of steam and unpleasant odours. It includes a unique swing clip and removable spigot that makes it very easy to install into a standard 10" round fan cut out.

### Typical Applications

Exhausts from residential or light commercial applications such as toilets, bathrooms, laundries, kitchens and ensuites. Its low profile compact design and side exhaust outlet makes it suitable for mounting between floors and applications with low ceiling heights such as cathedral ceilings.

### Features

- Advanced impeller and housing design provides powerful air flow and minimises noise
- High strength swing clips make installation easy
- Low resistance non-return backdraft damper maximises air flow performance
- Easy to remove diffuser makes cleaning simple
- Can be retrofitted into a standard 10" round fan cut out
- Fitted plug and lead simplifies installation
- Available with a 3 to 15 minute adjustable run-on timer

### Construction

Housing and diffuser are made from injected moulded polypropylene. Fans are forward-curved centrifugal, driven by a squirrel cage motor.

### Motor

Type - squirrel cage induction motor.  
Electricity supply - 230V, single-phase, 50Hz.  
Bearings - sealed for life, ball.  
See pages O-2/3 for details on these motors.

### Internal Thermal Protection

Automatic reset thermal protection is fitted as standard

### Testing


Air flow to ISO5801: 2007  
Noise to ISO3744: 2010

### Special Note

Timer model ECL29-150RDWT includes a plug and lead to suit HPM 4 pin socket.

## SPECIAL FEATURES

### Easy duct connection



*Long clip-in spigot makes installation and duct connection easier.*

### Installation is made easy



*Rotate swing clips to hold fan body in place.*



*Tighten screws so clips clamp onto ceiling board.*


## SUGGESTED SPECIFICATION

The ceiling fans shall be of the Fantech Velocity Header Box Series as designed by Fantech Pty Ltd. and be of the model number shown on the schedule/drawing.


Impellers shall be forward-curved centrifugal and driven by a squirrel cage motor with integral thermal protection. They shall be fitted with high strength swing clips, removable spigot, low resistance non-return backdraft damper and removable diffuser. They shall include a plug and lead, and its housing and diffuser be made of injected moulded polypropylene.

They shall be tested to ISO5801: 2007 for air flow and ISO3744: 2010 for noise.

## PERFORMANCE CURVE



## DIMENSIONS




Model Number	Description	Cut out Ø	Dimensions, mm				
		A	B	C	D	E	
ECL29-150RDW..	Round diffuser	290	332	25	192	170	120


## TECHNICAL DATA

Model Number	Fan Speed rev/sec	Avg. dB(A) @ 3m	Watts	Amps	App. Wt. kg
ECL29-150RDW..	16	38	40	0.17	3

## HOW TO ORDER



## ANCILLARY EQUIPMENT



\* Not suitable for models with run-on timers





## Section 5

### Warranties

Please find Daikin & Fantech Warranty information on the following pages

**Office:** 2/30 Access Crescent, Coolum Beach, QLD 4573

**Postal:** PO Box 6017, Maroochydore, Qld 4558

**Email:** [admin@portcityairconditioning.com.au](mailto:admin@portcityairconditioning.com.au)

**Phone:** 1300 PORT CITY / 07 4972 3355 **Fax:** 07 4972 1791

**After Hours Emergency Phone:** 0439 665 398

**Website:** <http://www.portcitygroup.com.au/>

ABN: 99 717 077 615 / QBCC: 1184073 / ARCTICK: AU12994 / ELEC: 73329

## WARRANTY CLAIMS

Please complete the details below and store this card along with the purchase docket in a safe place. To claim under this Warranty, both this card and the purchase docket must be presented to or sent to Daikin Australia at the address below, or your Daikin Dealer/Installer.

WHERE THE OWNER IS A CONSUMER WITHIN THE MEANING OF THE ACL AND THERE IS A VALID CLAIM UNDER THE WARRANTY, DAIKIN AUSTRALIA WILL BEAR THE COST OF ARRANGING FOR THE REPAIR OR REPLACEMENT OF THE EQUIPMENT, INCLUDING ANY NECESSARY ATTENDANCE BY TECHNICIANS OR INSTALLERS. WHERE THE OWNER IS NOT A CONSUMER WITHIN THE MEANING OF THE ACL, DAIKIN AUSTRALIA WILL BEAR THE COST OF THE REPLACEMENT PARTS ONLY.

**OUTDOOR UNIT** Model No. \_\_\_\_\_ Serial No. \_\_\_\_\_

**INDOOR UNIT(S)** Model No. \_\_\_\_\_ Serial No. \_\_\_\_\_

Model No. \_\_\_\_\_ Serial No. \_\_\_\_\_

Model No. \_\_\_\_\_ Serial No. \_\_\_\_\_

Model No. \_\_\_\_\_ Serial No. \_\_\_\_\_

**CONTROLLER(S)** Model No. \_\_\_\_\_

**SUPPLIED BY** \_\_\_\_\_ Phone No. \_\_\_\_\_

**INSTALLED BY** \_\_\_\_\_ Date \_\_\_\_\_

**OWNER'S NAME** \_\_\_\_\_

**ADDRESS** \_\_\_\_\_

## IMPORTANT NOTE

For repair or replacement of equipment under this Warranty it is recommended that the Owner contact their Daikin Dealer / Installer. If the owner requests Daikin Australia to perform or arrange the service call, the Owner will be liable for all associated costs if the problem is not covered by the provisions of this Warranty or the Owner's Statutory Rights.

**Daikin Australia Pty Ltd** ABN 62 000 172 967

62-66 Governor Macquarie Drive  
Chipping Norton, NSW 2170  
Phone 1300 362 438

Part No. 3PA004113  
Rev. No. 1709

[daikin.com.au](http://daikin.com.au)

# DAIKIN

# DAIKIN VRV WARRANTY

## THIS WARRANTY APPLIES TO DAIKIN VRV EQUIPMENT SUPPLIED IN AUSTRALIA.

The Daikin equipment listed on the back of this card is warranted by Daikin Australia Pty Limited (ABN 62 000 172 967) ("Daikin Australia") against defects in design, materials and workmanship as set out in this Warranty.

### THIS WARRANTY DOES NOT COVER

- a) Damage, problems or unsatisfactory performance caused by:
  - i) faulty or incorrect external electrical wiring, incorrect power supply, voltage fluctuations, over voltage transients or electromagnetic interference not originating within the equipment;
  - ii) incorrect or poor installation;
  - iii) the use of an accessory, component or equipment not supplied by Daikin Australia;
  - iv) storm, fire, flood, vandalism, abuse, misuse, negligence, Acts of God, earthquake, war, vermin, foreign matter entering the equipment (e.g. dirt and moisture) or any other outside agency;
  - v) operation of the equipment in an environment where the climatic comfort of humans is not the primary function of the equipment;
  - vi) operation of the equipment outside the operating conditions specified by Daikin for the equipment; or
  - vii) misapplication or modification of the equipment;

- b) Damage or deterioration to the external surfaces or refrigeration coils caused by normal weathering or corrosive atmospheric conditions;
- c) Any costs or additional labour associated with gaining acceptable service access to equipment installed in restricted or unsafe (e.g. high) locations;
- d) Freight charges (including insurance) or travelling costs for repairs performed outside the area normally serviced by Daikin Australia or a repair agent authorised by Daikin Australia;
- e) Equipment which has been installed or reinstalled in a transportable or mobile unit (e.g. caravan or boat);
- f) Equipment which has been re-installed at a location other than the original location;
- g) Any consumable item (e.g. batteries, filters, belts) supplied with the equipment unless the item is shown to be defective at the time of purchase; or
- h) Liability for any direct, indirect or consequential loss or damage, which is expressly excluded.

### OWNER'S RESPONSIBILITY

The Owner is responsible for the correct operation and regular maintenance of the equipment, including:

- a) Operation and maintenance of the equipment in accordance with the operating instructions.
- b) Regular cleaning of the air filter(s) and replacement where necessary.
- c) Ensuring that the air inlet and outlet on the outdoor unit is kept clear of any obstructions (e.g. dirt, leaves, plants).
- d) Ensuring that the condensate drain is kept clean.
- e) Replacement of exhausted batteries.
- f) The application of additional corrosion protection if the product is installed in a corrosive environment (e.g. Industrial pollution, sea air).

The correction of any non-equipment fault or problem is not covered by this Warranty.

### OWNER'S STATUTORY RIGHTS

If this equipment is supplied to an owner (the Owner) who is a consumer (within the meaning of the Australian Consumer Law or ACL):

- a) The Owner has the benefit of a number of statutory guarantees, rights and remedies that are in addition to this Warranty; and
- b) Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

The Owner's Australian Consumer Law guarantees, and similar statutory rights and remedies, are called the "Owner's Statutory Rights" in this Warranty.

If the Owner is not a consumer, the Owner's rights are limited to this Warranty.

THE RIGHTS GIVEN BY THE DAIKIN AUSTRALIA 5 YEAR WARRANTY ARE IN ADDITION TO THE OWNER'S STATUTORY RIGHTS.

### 5 YEAR WARRANTY

The equipment listed on the back of this card is warranted by Daikin Australia Pty Ltd (ABN 62 000 172 967) ("Daikin Australia") against defects in design, materials and workmanship for a period of 5 years from the date the equipment is purchased by the original owner.

Subject to the Owner's Statutory Rights, equipment defects covered by this Warranty will be repaired or replaced (with the same equipment, if available or substitute equipment of a comparable value) at the discretion of Daikin Australia without cost to the Owner for parts or direct repair labour, or replacement parts or equipment. The repair or replacement shall be performed during normal business hours by Daikin Australia or a repair agent authorised by Daikin Australia.

Any Daikin parts or Daikin equipment replaced under this Warranty will be warranted in accordance with the provisions of this Warranty for the remainder of the original warranty period or 12 months from the completion of the repair, whichever is the greater.

### 12 MONTH (EQUIPMENT)/36 MONTH (COMPRESSOR) WARRANTY

This Warranty applies to equipment supplied to the Owner who is not a consumer (within the meaning of the ACL).

The Daikin equipment listed on the back of this card is warranted by Daikin Australia against defects in design, materials and workmanship for a period of 12 months and all compressors contained in that equipment are so warranted against defects in design, materials and workmanship for a period of 36 months, in each case from the date the equipment is purchased by the original owner.

Equipment defects covered by this Warranty will be repaired or replaced at the discretion of Daikin Australia without cost to the Owner for replacement parts or equipment. The repair or replacement shall be performed during normal business hours by Daikin Australia or a repair agent authorised by Daikin Australia.

Any Daikin parts or Daikin equipment replaced under this Warranty will be warranted in accordance with the provisions of this Warranty for the remainder of the original warranty period or 12 months from the completion of the repair, whichever is the greater.

In respect of any equipment supplied to the Owner who is not a consumer, within the meaning of the Australian Consumer Law, all liability of Daikin Australia for any loss or damage, direct and consequential, not covered under this Warranty is expressly excluded.

In respect of any equipment that is not of a kind ordinarily acquired for personal, domestic or household use or consumption, the liability of Daikin Australia for any defect of design, materials or workmanship will be limited to any of the following as determined by Daikin Australia:-

- a) replacing the equipment or supplying equivalent equipment;
- b) repairing the equipment;
- c) paying the cost of replacing the equipment or acquiring equivalent equipment; or
- d) paying the cost of having the equipment repaired, unless the Owner establishes that this limitation of liability is unfair or unreasonable.



Please complete the details below and store this card along with the purchase docket in a safe place. To receive repair under Warranty both this card and the purchase docket must be presented.

#### OUTDOOR UNIT

Model No. \_\_\_\_\_ Serial No. \_\_\_\_\_

#### INDOOR UNIT(S)

Model No. \_\_\_\_\_ Serial No. \_\_\_\_\_

Model No. \_\_\_\_\_ Serial No. \_\_\_\_\_

Model No. \_\_\_\_\_ Serial No. \_\_\_\_\_

Model No. \_\_\_\_\_ Serial No. \_\_\_\_\_

#### CONTROLLER(S)

Model No. \_\_\_\_\_

#### SUPPLIED BY

#### PHONE NO.

#### INSTALLED BY

#### DATE

#### OWNER'S NAME

#### ADDRESS

#### IMPORTANT NOTE

For repair of equipment under this Warranty it is recommended that the owner contact their Daikin Dealer / Installer. If the owner requests Daikin Australia to perform or arrange the service call, the owner will be liable for all associated costs if the problem is not covered by the provisions of this Warranty or the Owner's Statutory Rights.

**Daikin Australia Pty Ltd** ABN 62 000 172 967

62-66 Governor Macquarie Drive

Chipping Norton, NSW 2170

Phone 1300 362 438

Part No. DADW0203

Rev. No. 1709

[daikin.com.au](http://daikin.com.au)

# DAIKIN

# 5 YEAR WARRANTY

**THIS WARRANTY APPLIES TO DOMESTIC AND "SKY AIR"  
PRODUCTS PURCHASED AND INSTALLED IN AUSTRALIA.**

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. Your Australian Consumer Law guarantees, and similar statutory rights, are called the "Owner's Statutory Rights" in this Warranty.

**THE RIGHTS GIVEN BY THE DAIKIN AUSTRALIA 5 YEAR WARRANTY  
ARE IN ADDITION TO THE OWNER'S STATUTORY RIGHTS.**

The Daikin equipment listed on the back of this card is warranted by Daikin Australia Pty Limited (ABN 62 000 172 967) ("Daikin Australia") against defects in design, materials and workmanship for a period of 5 years from the date the equipment is purchased by the original owner.

Equipment defects covered by this Warranty will be repaired or replaced at the discretion of Daikin Australia (subject to the Owner's rights under the Australian Consumer Law with respect to major failures) without cost to the owner for parts or direct repair labour. The repair or replacement shall be performed during normal business hours by Daikin Australia or a repair agent authorised by Daikin Australia.

Any Daikin parts or Daikin equipment replaced under this Warranty will be warranted in accordance with the provisions of this Warranty for the remainder of the original warranty period or 12 months from the completion of the repair, whichever is the greater.

Except where inconsistent with the Owner's Statutory Rights and the rights given by this Warranty, all other warranties and all liability of Daikin Australia for any loss or damage direct and consequential is expressly excluded.

### THIS WARRANTY DOES NOT COVER

- a) Damage or problems or unsatisfactory performance caused to the equipment by faulty or incorrect external electrical wiring, incorrect power supply, voltage fluctuations, over voltage transients or electromagnetic interference not originating within the equipment.
- b) Damage or problems resulting from incorrect or poor installation.
- c) Damage or problems caused by the use of an accessory, component or equipment not supplied by Daikin Australia.
- d) Damage or problems caused by storm, fire, flood, vandalism, misuse, negligence, Acts of God, earthquake, war, vermin, foreign matter entering the equipment (e.g. dirt and moisture) or any other outside agency.
- e) Damage or deterioration to the external surfaces or refrigeration coils caused by normal weathering or corrosive atmospheric conditions.
- f) Any costs or additional labour associated with gaining acceptable service access to equipment installed in restricted or unsafe (e.g. high) locations.
- g) Freight charges (including insurance) or travelling cost for repairs performed outside the area normally serviced by Daikin Australia or a repair agent authorised by Daikin Australia.
- h) Equipment which has been installed in a transportable or mobile application (e.g. caravan or boat).
- i) Equipment which has been re-installed in a transportable or mobile application (e.g. caravan or boat).
- j) Equipment which has been re-installed at a location other than the original location.
- k) Any consumable item (e.g. batteries, filters, belts) supplied with the equipment unless the item is shown to be defective at the time of purchase.

- l) Damage or problems or unsatisfactory performance resulting from operation in an environment where the climatic comfort of humans is not the primary function of the equipment.
- m) Damage or problems or unsatisfactory performance resulting from operations at conditions outside the operating conditions specified in the Daikin technical or sales literature applicable to the equipment.
- n) Damage, problems or unsatisfactory performance resulting from misapplication of the equipment.

Where this Warranty does not apply, the Owner's rights are limited to the Owner's non-excludable Statutory Rights.

### OWNER'S RESPONSIBILITY

The owner is responsible for the correct operation and regular maintenance of the equipment as listed below. The correction of any non product fault or problem is not covered by this Warranty.

- a) Operation and maintenance of the equipment in accordance with the operating instructions.
- b) Regular cleaning of the air filter(s) and replacement where necessary.
- c) Ensuring that the air inlet and outlet on the outdoor unit is kept clear of any obstructions (e.g. dirt, leaves, plants)
- d) Ensuring that the condensate drain is kept clean.
- e) Replacement of exhausted batteries.
- f) The application of additional corrosion protection if the product is installed in a corrosive environment (e.g. Industrial pollution, sea air).

### LIMITATION OF OWNER'S STATUTORY RIGHTS

In respect of any goods supplied under the contract which are not of a kind ordinarily acquired for personal domestic or household use or consumption, unless the owner establishes the following limitation of liability would not be fair and reasonable, the liability of Daikin Australia for any defect of design, materials or workmanship will be limited to any of the following as determined by Daikin Australia:

- a) Replacing the equipment or supplying equivalent equipment;
- b) Repairing the equipment;
- c) Paying the cost of replacing the equipment or acquiring equivalent equipment;
- d) Paying the cost of having the equipment repaired.

# GOODS AND WARRANTY

- When supplying goods to a consumer, the following mandated statement applies:  
*“Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.”*
- The benefits of this warranty are in addition to any rights and remedies imposed by Australian State and Federal legislation that cannot be excluded. Nothing in this warranty is to be interpreted as excluding, restricting or modifying any State or Federal legislation applicable to the supply of goods and services which cannot be excluded, restricted or modified.
- Subject to the conditions and limitation below, the Company warrants products of its manufacture to be free of defects in workmanship and/or materials at the time of delivery to the Buyer.
- Any part, assembly or portion thereof found to be defective within one year from the date of commissioning or eighteen (18) months from date of shipment from our factory, whichever is the sooner, unless expressly stated otherwise in the Company’s Publications or Literature, will be repaired or exchanged F.O.B factory.
- The Company reserves the right to replace defective parts of the goods with parts and components of similar quality, grade and composition where an identical component is not available.
- Goods presented for repair may be replaced by refurbished goods of the same type rather than being repaired. Refurbished parts may be used to repair the goods.
- Goods or parts that have been returned for repair (except where the repair is as a result of the Company’s failure to comply with the statutory guarantees in the ACL) or warranty assessment are deemed to have been abandoned by the Buyer if not collected within 30 days after the Company has notified the Buyer in writing of the warranty assessment outcome or the completed repair.
- The Company reserves the right to dispose or otherwise deal with an abandoned product or part at its discretion.
- This warranty does not apply if:
  - the goods have not been paid for by the Buyer as per the credit terms provided; or
  - the goods have not been installed in accordance with AS NZS 3000/2000 Australian/New Zealand Wiring rules; or
  - the goods have been misused or neglected.
- The Company assumes no responsibility under this warranty for the labour costs involved in the removal of defective parts, installation of new parts or service charges related thereto.
- If a fault covered by this warranty occurs, the Buyer must first contact the Company at the contact address listed below.
- Any warranty claim must be accompanied by:
  - proof of purchase;
  - written details of the alleged defect; and
  - appropriate documentation (such as installation and maintenance records etc).
- The Company shall have the option of requiring the return of the defective part (transportation prepaid by the Buyer) to establish the claim.
- The Company makes no warranties or representations other than set out in this clause 7.
- The repair or exchange of the goods or part of the goods, is the absolute limit of the Company’s liability under this express warranty.



## Fantech Contacts

### Head Office

#### Victoria - Melbourne

A.B.N. 11 005 434 024

Ph: +61 (3) 9554 7845

Fax: +61 (3) 9554 7833

Email: info@fantech.com.au

### Australia

Adelaide (08) 8294 0530

Brisbane (07) 3299 9888

Darwin (08) 8947 0447

**Melbourne H.O. (03) 9554 7845**

Perth (08) 9209 4999

Sydney (02) 8811 0400

### New Zealand

Auckland H.O. (09) 444 6266

Christchurch (03) 379 8622

Wellington (04) 566 0532

### Asia

For agents in the Asian region

call (603) 7846 0340

or visit [www.elfantechasia.com](http://www.elfantechasia.com)

**[www.fantech.com.au](http://www.fantech.com.au)**



## Section 6

### CERTIFICATION

Please find included the following documents.

Mechanical form 15 & 12

Seismic form 15 & 12

Passive fire form 12

Fire Penetration register

**Office:** 2/30 Access Crescent, Coolum Beach, QLD 4573

**Postal:** PO Box 6017, Maroochydore, Qld 4558

**Email:** [admin@portcityairconditioning.com.au](mailto:admin@portcityairconditioning.com.au)

**Phone:** 1300 PORT CITY / 07 4972 3355 **Fax:** 07 4972 1791

**After Hours Emergency Phone:** 0439 665 398

**Website:** <http://www.portcitygroup.com.au/>

# Form 15—Compliance Certificate for building Design or Specification

NOTE	<p>This is to be used for the purposes of section 10 of the <i>Building Act 1975</i> and/or section 46 of the <i>Building Regulation 2006</i>.</p> <p><b>RESTRICTION:</b> A building certifier (class B) can only give a compliance certificate about whether building work complies with the BCA or a provision of the QDC. A building certifier (Class B) can not give a certificate regarding QDC boundary clearance and site cover provisions.</p>																																						
<p><b>1. Property description</b>  This section need only be completed if details of street address and property description are applicable.  <b>EG. In the case of (standard/generic) pool design/shell manufacture and/or patio and carport systems this section may not be applicable.</b> The description must identify all land the subject of the application. The lot &amp; plan details (eg. SP / RP) are shown on title documents or a rates notice. If the plan is not registered by title, provide previous lot and plan details.</p>	<p>Street address <i>(include no., street, suburb / locality &amp; postcode)</i></p> <p><b>3-15 Archer St</b></p> <hr/> <p><b>Toowong</b> Postcode <b>4066</b></p> <p>Lot &amp; plan details <i>(attach list if necessary)</i></p> <p><b>Lots 3 RP 70716</b></p> <p>In which local government area is the land situated?</p> <p><b>Brisbane City Council</b></p>																																						
<p><b>2. Description of component/s certified</b>  Clearly describe the extent of work covered by this certificate, e.g. all structural aspects of the steel roof beams.</p>	<p><b>1) Ventilation to basement and mezzanine carpark levels including podium levels enclosed ramps.</b></p> <p><b>2) General ventilation to ground floor pump/garbage/MSB rooms.</b></p> <p><b>3) Apartment ventilation to bathrooms, ensuites, laundries and kitchen ranges.</b></p> <hr/> <p><b>Excludes: all air conditioning and stairwell pressurisation systems (Fire engineered out)</b></p>																																						
<p><b>3. Basis of certification</b>  Detail the basis for giving the certificate and the extent to which tests, specifications, rules, standards, codes of practice and other publications, were relied upon.</p>	<p><b>NCC2019, Section J5 for podium, ground, mezzanine, and basement 1 &amp; 2.</b></p> <p><b>BCA2009 section J5 for apartment levels,</b></p> <p><b>NCC2019 Sections F6.3, F4.5, J3.5</b></p> <hr/> <p><b>AS 1668.2, AS1668.1</b></p> <hr/> <p><b>OMNI FER 5766102 (Rev C dated 24 May 2021)</b></p>																																						
<p><b>4. Reference documentation</b>  Clearly identify any relevant documentation, e.g. numbered structural engineering plans.</p>	<p>Drawings as follows:</p> <table border="1"> <thead> <tr> <th>Drawing Reference:</th> <th>Revision</th> </tr> </thead> <tbody> <tr><td>#05788 PORTCITY 211224 The Patterson-M000</td><td>2</td></tr> <tr><td>#05788 PORTCITY 211224 The Patterson-M001</td><td>2</td></tr> <tr><td>#05788 PORTCITY 211224 The Patterson-M100</td><td>6</td></tr> <tr><td>#05788 PORTCITY 211224 The Patterson-M101</td><td>6</td></tr> <tr><td>#05788 PORTCITY 211224 The Patterson-M102</td><td>6</td></tr> <tr><td>#05788 PORTCITY 211224 The Patterson-M103</td><td>7</td></tr> <tr><td>#05788 PORTCITY 211224 The Patterson-M104</td><td>6</td></tr> <tr><td>#05788 PORTCITY 211224 The Patterson-M105</td><td>6</td></tr> <tr><td>#05788 PORTCITY 211224 The Patterson-M106</td><td>5</td></tr> <tr><td>#05788 PORTCITY 211224 The Patterson-M107</td><td>5</td></tr> <tr><td>#05788 PORTCITY 211224 The Patterson-M108</td><td>5</td></tr> <tr><td>#05788 PORTCITY 211224 The Patterson-M109</td><td>5</td></tr> <tr><td>#05788 PORTCITY 211224 The Patterson-M110</td><td>5</td></tr> <tr><td>#05788 PORTCITY 211224 The Patterson-M111</td><td>5</td></tr> <tr><td>#05788 PORTCITY 211224 The Patterson-M112</td><td>5</td></tr> <tr><td>#05788 PORTCITY 211224 The Patterson-M113</td><td>5</td></tr> <tr><td>#05788 PORTCITY 211224 The Patterson-M114</td><td>5</td></tr> <tr><td>#05788 PORTCITY 211224 The Patterson-MS1</td><td>4</td></tr> </tbody> </table> <hr/> <p><b>21-05-21_HVAC Alliance SID report</b></p>	Drawing Reference:	Revision	#05788 PORTCITY 211224 The Patterson-M000	2	#05788 PORTCITY 211224 The Patterson-M001	2	#05788 PORTCITY 211224 The Patterson-M100	6	#05788 PORTCITY 211224 The Patterson-M101	6	#05788 PORTCITY 211224 The Patterson-M102	6	#05788 PORTCITY 211224 The Patterson-M103	7	#05788 PORTCITY 211224 The Patterson-M104	6	#05788 PORTCITY 211224 The Patterson-M105	6	#05788 PORTCITY 211224 The Patterson-M106	5	#05788 PORTCITY 211224 The Patterson-M107	5	#05788 PORTCITY 211224 The Patterson-M108	5	#05788 PORTCITY 211224 The Patterson-M109	5	#05788 PORTCITY 211224 The Patterson-M110	5	#05788 PORTCITY 211224 The Patterson-M111	5	#05788 PORTCITY 211224 The Patterson-M112	5	#05788 PORTCITY 211224 The Patterson-M113	5	#05788 PORTCITY 211224 The Patterson-M114	5	#05788 PORTCITY 211224 The Patterson-MS1	4
Drawing Reference:	Revision																																						
#05788 PORTCITY 211224 The Patterson-M000	2																																						
#05788 PORTCITY 211224 The Patterson-M001	2																																						
#05788 PORTCITY 211224 The Patterson-M100	6																																						
#05788 PORTCITY 211224 The Patterson-M101	6																																						
#05788 PORTCITY 211224 The Patterson-M102	6																																						
#05788 PORTCITY 211224 The Patterson-M103	7																																						
#05788 PORTCITY 211224 The Patterson-M104	6																																						
#05788 PORTCITY 211224 The Patterson-M105	6																																						
#05788 PORTCITY 211224 The Patterson-M106	5																																						
#05788 PORTCITY 211224 The Patterson-M107	5																																						
#05788 PORTCITY 211224 The Patterson-M108	5																																						
#05788 PORTCITY 211224 The Patterson-M109	5																																						
#05788 PORTCITY 211224 The Patterson-M110	5																																						
#05788 PORTCITY 211224 The Patterson-M111	5																																						
#05788 PORTCITY 211224 The Patterson-M112	5																																						
#05788 PORTCITY 211224 The Patterson-M113	5																																						
#05788 PORTCITY 211224 The Patterson-M114	5																																						
#05788 PORTCITY 211224 The Patterson-MS1	4																																						

<b>5. Building certifier reference number</b>	Building certifier reference number <input type="text" value="-"/>
<b>6. Competent person details</b> A competent person for building work, means a person who is assessed by the building certifier for the work as competent to practise in an aspect of the building and specification design, of the building work because of the individual's skill, experience and qualifications in the aspect. The competent person must also be registered or licensed under a law applying in the State to practice the aspect. If no relevant law requires the individual to be licensed or registered to be able to give the help, the certifier must assess the individual as having appropriate experience, qualifications or skills to be able to give the help. If the chief executive issues any guidelines for assessing a competent person, the building certifier must use the guidelines when assessing the person.	Name (in full) <input type="text" value="Peter Logovik for an on behalf of Port City Air Conditioning"/> Company name (if applicable)    Contact person <input type="text" value="HVAC Alliance Pty Ltd"/> <input type="text" value="Peter Logovik"/> Phone no. business hours    Mobile no.    Fax no. <input type="text" value="Nil"/> <input type="text" value="Nil"/> <input type="text" value="0433160350"/> Email address <input type="text" value="peterl@hvacalliance.solutions"/> Postal address <input type="text" value="1 Prince St"/> <input type="text" value="Virginia"/> <input type="text" value="Postcode 4014"/> Licence or registration number (if applicable) <input type="text" value="RPEQ 21430"/>
<b>7. Signature of competent person</b> This certificate must be signed by the individual assessed by the building certifier as competent.	Signature    Date <input type="text" value="Peter Logovik"/> <input type="text" value="25 / 06 / 2021"/>

LOCAL GOVERNMENT USE ONLY

Date received		Reference Number/s	
---------------	--	--------------------	--



This form is to be used for the purposes of sections 74 and 77 of the Building Regulation 2021 (appointed competent person statement that an aspect of work has been completed and complies with the building development approval).

Information about how to complete this form is in the Appendix at the end of the form.

### 1. Indicate the aspect of the building work

Examples of aspects of the stage of building work (and not limited to the examples provided below):

waterproofing, tiling, glazing, energy efficiency, emergency lights, exit signs, smoke detection, air-conditioning.

Aspect of building work (indicate the aspect)

Mechanical Air Conditioning and Ventilation

### 2. Property description

The description must identify all land the subject of the application.

The lot and plan details (e.g. SP/RP) are shown on title documents or a rates notice.

If the plan is not registered by title, provide previous lot and plan details.

Street address	3 – 15 Archer Street		
	Suburb/locality	Toowong	
State	QLD	Postcode	4066
Lot and plan details ( <i>attach list if necessary</i> )			
L2 & L3 on RP.70716			
Local government area the land is situated in			
Brisbane City Council			

### 3. Building/structure description

Building/structure description

Apartment and Basement Car Park

---

Class of building/structure

---

Class 2 & 7a

---

#### 4. Description of the extent of aspect/s certified

Clearly describe the extent of work covered by this certificate, i.e. all structural aspects of the steel roof beams and location i.e. what floors the work was on, the parts of a room.

---

Mechanical ( Air Conditioning, Smoke exhaust, Carpark exhaust, Dampers, Zones, Ventilation, Toilet exhaust)

---

#### 5. Basis of certification

Detail the basis for giving the certificate and the extent to which tests, specifications, rules, standards, codes of practice and other publications were relied upon.

---

Mechanical Ventilation for exhaust air systems compliant with part F4 of the BCA  
Mechanical Ventilation and/or AC Systems compliant with part F4.5 of the BCA, AS1668.2-1991 and AS/NZS-as applicable  
Energy efficiency requirement compliant with Part J5 Air Conditioning and Ventilation systems of the BCA  
B1.2, B1.4  
AS1668 1 & 2  
AS/NZS 3666.1  
NCC Clause F6.2  
AS1170.4  
Tested system under C3.15 (Passive fire form 12)  
NCC Specification C2.5 (Passive fire form 12)

---

#### 6. Reference documentation

Clearly identify any relevant documentation, e.g. numbered structural engineering plans.



M100, M101, M102, M103, M104, M105, M106, M107, M108, M109, M110, M111, M112, M113, M114.

## 7. Building certifier reference number and building development approval number

Building certifier's name <i>(in full)</i>			
Building certifier reference number		Development approval number	A005708978

## 8. Details of appointed competent person

Name <i>(in full)</i>	Daine Ross Smith		
Company name <i>(if applicable)</i>	Port City Air Conditioning Pty Ltd		
Contact person	Daine Ross Smith		
Business phone number	07 5443 4095	Mobile	0439 665 398
Email address	<a href="mailto:daine@portcityair.com.au">daine@portcityair.com.au</a>		
Postal address	PO Box 6017		
		Suburb/locality	Maroochydore
State	QLD	Postcode	4558
Licence class or registration type <i>(if applicable)</i>	Refrigeration, Air conditioning & Mechanical Services incl Limited Design		
Licence class or registration number <i>(if applicable)</i>	1184073		
Date request to inspect received from building certifier	9/03/2023		

## 9. Signature of appointed competent person

Signature		Date	9/03/2023
-----------	---	------	-----------

## LOCAL GOVERNMENT USE ONLY

Date received	Click or tap to enter a date.	Reference number/s	
---------------	-------------------------------	--------------------	--

## Appendix – explanatory information

**IMPORTANT NOTE:** a competent person who knowingly or reasonably suspects the information they are giving to the building certifier is false or misleading, including the information contained in this certificate (Form 12), commits an offence and is liable to a maximum penalty of 100 penalty units.

**When is this certificate needed?** (sections 10 of the *Building Act 1975* (Building Act) and 75 of Building Regulation 2021 (BR 2021))

When performing a building certification function, a building certifier may accept and rely on **an aspect inspection certificate** from an appointed competent person to satisfy themselves that an aspect of work has been completed and complies with the building development approval.

For a single detached class 1a building a building certifier can only accept this form for an aspect of work that is for

- boundary clearance if the appointed competent person is a cadastral surveyor, and,
- the reinforcement of footing systems if the appointed competent person is the appropriate registered professional engineer.

For further information about inspections for detached class 1a and 10 buildings or structures, refer to **Guideline for inspections of class 1 and 10 buildings and structures**.

**Who can sign this certificate (Form 12)?** (Part 9, Division 2, Section 74 of the BR 2021)

A person assessed and appointed as a competent person (inspections) must complete the approved form (Form 12) and give it to the building certifier after they (1) inspect the aspect of work; and (2) are satisfied the aspect of work has been completed and complies with the building development approval.

**Competent person** (section 10 Part 6 of the BR 2021)

A building certifier must assess and decide to appoint an individual as a competent person before they can, as a competent person, give inspection help or design-specification help. The building certifier is required to keep detailed records about what was considered when appointing a competent person.

A competent person cannot give inspection help to a building certifier until they have been appointed by the building certifier. For further information about assessment of someone as a competent person refer to the **Guideline for the assessment of competent persons**.

**Inspection help** (section 34 of the BR 2021)

A building certifier must be satisfied that an individual is competent to give the type of inspection help having regard to the individual's experience, qualifications and skills and if required by law to hold a licence or registration, that the individual is appropriately registered or licensed.

For further information about conducting inspections for class 2 to 9 buildings, refer to the **Guideline for inspection of class 2 to 9 buildings**.

**How to complete this form**

### **Section 1 – Aspect of building work**

An aspect of building work means a component of a stage of the building work, for example water proofing. A stage of assessable building work (requires a building development approval) is a stage of the work, prescribed by regulation, that may be inspected, or stated in a building development approval by the relevant building certifier.

### **Section 2 – Property description**

The property description must identify all the land the subject of the application. The lot and plan details (e.g. SP/RP) can be found on title documents or a rates notice. If the plan is not registered by title, provide previous lot and plan details.

### **Section 3 – Building / structure description**

Describe the type of building or structures and provide the classification determined under the National Construction Code (NCC). The NCC can be accessed at the Australian Building Codes Board's website.

### **Section 4 – Describe the extent or location of the aspect work inspected.**

Clearly describe the extent of work covered by this certificate, i.e. all structural aspects of the steel roof beams and location i.e. what floors the work was on, the parts of a room.

### **Sections 5 – Basis for the certification and section 6 Reference documentation** (section 77 of BR 2021)

The appointed competent person (inspections) must state the basis for giving the certificate (Form 12) including the extent to which the competent person has relied on tests, specifications, rules, standards, codes of practice or other publications to make their decision that the aspect of work has been completed and complies with the building development approval.

Under the regulation (section 76) the appointed competent person (inspections) may accept and rely on a certificate (Form 12) from another appointed competent person (inspections) without inspecting the work. Although this can only be done if the inspection was carried out in accordance with best industry practice.

#### **Other relevant inspection / aspect forms**

**Aspect work – assessable building work: Form 43 – Aspect certificate (completed by a QBCC licensee)** for aspect work for a single detached class 1a building and class 10 buildings and structures.

**Aspect work not subject to a building development approval - accepted development (self-assessable): Form 30 – (completed by a QBCC licensee)** given to either the builder or building owner of the building, stating the subject aspect work complies with the relevant provisions, standards and codes.

**Stages of work: Form 16 – Inspection certificate (completed by a building certifier or competent person)** for a stage of work.

**Building design – specification: Form 15 – Compliance certificate for building design or specification (completed by the appointed competent person (design – specification))** - for an aspect of stating a building design – specification will, if installed or carried out to the detail under this Form will comply with the building assessment provisions.

For all other building forms and guidelines visit the [Business Queensland website](#).

#### **PRIVACY NOTICE**

The Department of Energy and Public Works is collecting personal information as required under the *Building Act 1975*. This information may be stored by the Department, and will be used for administration, compliance, statistical research and evaluation of building laws. Your personal information will be disclosed to other government agencies, local government authorities and third parties for purposes relating to administering and monitoring compliance with the *Building Act 1975*. Personal information will otherwise only be disclosed to third parties with your consent or unless authorised or required by law.

This form is to be used for the purposes of sections 74 and 77 of the Building Regulation 2021 (appointed competent person statement that an aspect of work has been completed and complies with the building development approval).

Information about how to complete this form is in the Appendix at the end of the form.

<p><b>1. Indicate the aspect of the building work</b></p> <p>Examples of aspects of the stage of building work (and not limited to the examples provided below):</p> <p>waterproofing, tiling, glazing, energy efficiency, emergency lights, exit signs, smoke detection, air-conditioning.</p>	<p>Aspect of building work (indicate the aspect)</p> <p>The inspection for Port City Air Conditioning of the installation of air conditioning services penetrating fire rated elements in the construction of this building.</p>						
<p><b>2. Property description</b></p> <p>The description must identify all land the subject of the application.</p> <p>The lot and plan details (e.g. SP/RP) are shown on title documents or a rates notice.</p> <p>If the plan is not registered by title, provide previous lot and plan details.</p>	<p>Street address (include number, street, suburb/locality and postcode)</p> <p><b>3 - 15 Archer Street,</b> ..... <b>Toowong.</b> State <b>QLD</b> Postcode <b>4066</b> .....</p> <p>Lot and plan details (attach list if necessary)</p> <p><b>Lot 2 &amp; 3 on RP 70716</b> .....</p> <p>Local government area the land is situated in</p> <p><b>Brisbane City Council</b> .....</p>						
<p><b>3. Building/structure description</b></p>	<table border="1"> <thead> <tr> <th>Building/structure description</th> <th>Class of building/structure</th> </tr> </thead> <tbody> <tr> <td>New multi-storey residential apartment building</td> <td>2</td> </tr> <tr> <td>New Ancillary car parking</td> <td>7a</td> </tr> </tbody> </table>	Building/structure description	Class of building/structure	New multi-storey residential apartment building	2	New Ancillary car parking	7a
Building/structure description	Class of building/structure						
New multi-storey residential apartment building	2						
New Ancillary car parking	7a						
<p><b>4. Description of the extent of aspect/s certified</b></p> <p>Clearly describe the extent of work covered by this certificate, i.e. all structural aspects of the steel roof beams and location i.e. what floors the work was on, the parts of a room.</p>	<p>The inspection of the installation of mechanical air conditioning pipe work penetrating fire rated concrete slabs and fire walls in accordance with the requirements of the BCA.</p>						







## Appendix – explanatory information

**IMPORTANT NOTE:** a competent person who knowingly or reasonably suspects the information they are giving to the building certifier is false or misleading, including the information contained in this certificate (Form 12), commits an offence and is liable to a maximum penalty of 100 penalty units.

**When is this certificate needed?** (sections 10 of the *Building Act 1975* (Building Act) and 75 of Building Regulation 2021 (BR 2021))  
When performing a building certification function, a building certifier may accept and rely on **an aspect inspection certificate** from an appointed competent person to satisfy themselves that an aspect of work has been completed and complies with the building development approval.

For a single detached class 1a building a building certifier can only accept this form for an aspect of work that is for

- boundary clearance if the appointed competent person is a cadastral surveyor, and,
- the reinforcement of footing systems if the appointed competent person is the appropriate registered professional engineer.

For further information about inspections for detached class 1a and 10 buildings or structures, refer to **Guideline for inspections of class 1 and 10 buildings and structures**.

**Who can sign this certificate (Form 12)?** (part 9, division 2, section 74 of the BR 2021)

A person assessed and appointed as a competent person (inspections) must complete the approved form (Form 12) and give it to the building certifier after they (1) inspect the aspect of work; and (2) are satisfied the aspect of work has been completed and complies with the building development approval.

**Competent person** (section 10, Part 6 of the BR 2021)

A building certifier must assess and decide to appoint an individual as a competent person before they can, as a competent person, give inspection help or design-specification help. The building certifier is required to keep detailed records about what was considered when appointing a competent person.

A competent person cannot give inspection help to a building certifier until they have been appointed by the building certifier. For further information about assessment of someone as a competent person refer to the **Guideline for the assessment of competent persons**.

**Inspection help** (section 34 of the BR 2021)

A building certifier must be satisfied that an individual is competent to give the type of inspection help having regard to the individual's experience, qualifications and skills and if required by law to hold a licence or registration, that the individual is appropriately registered or licensed.

For further information about conducting inspections for class 2 to 9 buildings, refer to the **Guideline for inspection of class 2 to 9 buildings**.

### How to complete this form

#### Section 1 – Aspect of building work

An aspect of building work means a component of a stage of the building work, for example water proofing. A stage of assessable building work (requires a building development approval) is a stage of the work, prescribed by regulation, that may be inspected, or stated in a building development approval by the relevant building certifier.

#### Section 2 – Property description

The property description must identify all the land the subject of the application. The lot and plan details (e.g. SP/RP) can be found on title documents or a rates notice. If the plan is not registered by title, provide previous lot and plan details.

#### Section 3 – Building / structure description

Describe the type of building or structures and provide the classification determined under the National Construction Code (NCC). The NCC can be accessed at the Australian Building Codes Board's website.

#### Section 4 – Describe the extent or location of the aspect work inspected.

Clearly describe the extent of work covered by this certificate, i.e. all structural aspects of the steel roof beams and location i.e. what floors the work was on, the parts of a room.

#### Sections 5 – Basis for the certification and section 6 Reference documentation (section 77 of BR 2021)

The appointed competent person (inspections) must state the basis for giving the certificate (Form 12) including the extent to which the competent person has relied on tests, specifications, rules, standards, codes of practice or other publications to make their decision that the aspect of work has been completed and complies with the building development approval.

Under the regulation (section 76) the appointed competent person (inspections) may accept and rely on a certificate (Form 12) from another appointed competent person (inspections) without inspecting the work. Although this can only be done if the inspection was carried out in accordance with best industry practice.

### Other relevant inspection / aspect forms

**Aspect work – assessable building work: Form 43 – Aspect certificate (completed by a QBCC licensee)** - for aspect work for a single detached class 1a building and class 10 buildings and structures .

**Aspect work not subject to a building development approval - accepted development (self-assessable): Form 30 – (completed by a QBCC licensee)** - given to either the builder or the owner of the building, stating the subject aspect work complies with the relevant provisions, standards and codes.

**Stages of work: Form 16 – Inspection certificate (completed by a building certifier or competent person)** for a stage of work.

**Building design – specification: Form 15 – Compliance certificate for building design or specification (completed by a competent person (design – specification))** for an aspect of stating a building design – specification will, if installed or carried out to the detail under this Form will comply with the building assessment provisions.

For all other building forms and guidelines visit the [Business Queensland website](#).

**PRIVACY NOTICE**

The Department of Energy and Public Works is collecting personal information as required under the *Building Act 1975*. This information may be stored by the Department, and will be used for administration, compliance, statistical research and evaluation of building laws. Your personal information will be disclosed to other government agencies, local government authorities and third parties for purposes relating to administering and monitoring compliance with the *Building Act 1975*. Personal information will otherwise only be disclosed to third parties with your consent or unless authorised or required by law.

<u>Penetration #</u>	<u>Location</u>	<u>FRL</u>	<u>Description / Material</u>	<u>Size</u>	<u>Manufacturer / Test Report #</u>	<u>Drawing #</u>
1 FD	Level 1 Switch Room	120 / 120	Fire Damper / Core Filled wall	400 x 400 x 200	Holyoake / EWFA 2358000.5	M103
2 FD	Level 1 Switch Room	120 / 120	Fire Damper / Core Filled wall	350 x 350 x 200	Holyoake / EWFA 2358000.5	M103
3 FD	Level 1 Ramp	120 / 120	Fire Damper / Formed concrete	500 x 500 x 200	Holyoake / EWFA 2358000.5	M103
4 FD	Level 1 Fire Escape	120 / 120	Fire Damper / Fire Wall	1200 x 1800 x 90	Holyoake / EWFA 2358000.5	M103
1A	Level 1 Fire Stair	120 / 120	FyrePEX / Core Filled wall	110Ø	Trafalgar / FAR4849	M103
1B	Level 1 Fire Stair	120 / 120	FyrePEX / Formed concrete	110Ø	Trafalgar / FAR4849	M103
1C	Level 1 Fire Stair	120 / 120	FyrePEX / Formed concrete	110Ø	Trafalgar / FAR4849	M103

<u>Penetration #</u>	<u>Location</u>	<u>FRL</u>	<u>Description / Material</u>	<u>Size</u>	<u>Manufacturer / Test Report #</u>	<u>Drawing #</u>
5 FD	Level 3 Ramp	120 / 120	Fire Damper / Formed concrete	1250 x 1700 x 200	Holyoake / EWFA 2358000.5	M105

<u>Penetration #</u>	<u>Location</u>	<u>FRL</u>	<u>Description / Material</u>	<u>Size</u>	<u>Manufacturer / Test Report #</u>	<u>Drawing #</u>
400 A	Level 4 Riser	120 / 120	FyreBox cast in / Concrete Slab	350 x 125	Trafalgar / FC10266-001	M106
400 B	Level 4 Riser	120 / 120	FyreBox cast in / Concrete Slab	650 x 125	Trafalgar / FC10266-001	M106
401 A & 401 B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M106
402 A & 402 B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M106
403 A & 403 B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M106
404 A & 404 B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M106
405 A & 405 B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M106
406 A & 406 B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M106

<u>Penetration #</u>	<u>Location</u>	<u>FRL</u>	<u>Description / Material</u>	<u>Size</u>	<u>Manufacturer / Test Report #</u>	<u>Drawing #</u>
501, 601, 701, 801, 901 A & B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M107
502, 602, 702, 802, 902 A & B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M107
503, 603, 703, 803, 903 A & B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M107
504, 604, 704, 804, 904 A & B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M107
505, 605, 705, 805, 905 A & B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M107
506, 606, 706, 806, 906 A & B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M107
500 A1	Level 5 Riser	120 / 120	FyreBox cast in / Concrete Slab	350 x 125	Trafalgar / FC10266-001	M107
500 A2	Level 5 Riser	120 / 120	FyreBox cast in / Concrete Slab	650 x 125	Trafalgar / FC10266-001	M107
500 B, BB	Level 6 Riser	120 / 120	FyrePEX / In Slab	110Ø	Trafalgar / FAR4849	M107
500 C, CC	Level 6 Riser	120 / 120	FyrePEX / In Slab	110Ø	Trafalgar / FAR4849	M107
600	Level 6 Riser	120 / 120	FyreBox cast in / Concrete Slab	350 x 125	Trafalgar / FC10266-001	M107
600 A, B, C	Level 6 Riser	120 / 120	FyrePEX / In Slab	110Ø	Trafalgar / FAR4849	M107
600 AA, BB, CC	Level 7 Riser	120 / 120	FyrePEX / In Slab	110Ø	Trafalgar / FAR4849	M107
800 A, B, C	Level 8 Riser	120 / 120	FyrePEX / In Slab	110Ø	Trafalgar / FAR4849	M107
800 AA, BB, CC	Level 9 Riser	120 / 120	FyrePEX / In Slab	110Ø	Trafalgar / FAR4849	M107

<u>Penetration #</u>	<u>Location</u>	<u>FRL</u>	<u>Description / Material</u>	<u>Size</u>	<u>Manufacturer / Test Report #</u>	<u>Drawing #</u>
1001 A & B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M108
1003 A & B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M108
1004 A & B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M108
1005 A & B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M108
1006 A & B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M108
1000	Level 10 riser	120 / 120	FyreBox cast in / Concrete Slab	350 x 125	Trafalgar / FC10266-001	M108

<u>Penetration #</u>	<u>Location</u>	<u>FRL</u>	<u>Description / Material</u>	<u>Size</u>	<u>Manufacturer / Test Report #</u>	<u>Drawing #</u>
1101 A & B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M109
1102 A & B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M109
1103 A & B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M109
1104 A & B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M109
1105 A & B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M109
1106 A & B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M109
1100	Level 11 riser	120 / 120	FyreBox cast in / Concrete Slab	350 x 125	Trafalgar / FC10266-001	M109



<u>Penetration #</u>	<u>Location</u>	<u>FRL</u>	<u>Description / Material</u>	<u>Size</u>	<u>Manufacturer / Test Report #</u>	<u>Drawing #</u>
1201 A & B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M110
1202 A & B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M110
1203 A & B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M110
1204 A & B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M110
1206 A & B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M110
1200	Level 12 riser	120 / 120	FyreBox cast in / Concrete Slab	650 x 125	Trafalgar / FC10266-001	M110

<u>Penetration #</u>	<u>Location</u>	<u>FRL</u>	<u>Description / Material</u>	<u>Size</u>	<u>Manufacturer / Test Report #</u>	<u>Drawing #</u>
1301 A & B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M111
1303 A & B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M111
1304 A & B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M111
1306 A & B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M111
1300	Level 13 riser	120 / 120	FyreBox cast in / Concrete Slab	950 x 125	Trafalgar / FC10266-001	M111

<u>Penetration #</u>	<u>Location</u>	<u>FRL</u>	<u>Description / Material</u>	<u>Size</u>	<u>Manufacturer / Test Report #</u>	<u>Drawing #</u>
1401 A & B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M112
1402 A & B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M112
1403 A & B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M112
1400	Level 14 riser	120 / 120	FyreBox cast in / Concrete Slab	950 x 125	Trafalgar / FC10266-001	M111


<u>Penetration #</u>	<u>Location</u>	<u>FRL</u>	<u>Description / Material</u>	<u>Size</u>	<u>Manufacturer / Test Report #</u>	<u>Drawing #</u>
1501 A & B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M113
1502 A & B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M113
1503 A & B	Above Apartment Door	-/60 /60	FyrePEX / Fire Board	110Ø	Trafalgar / FAR4849	M113












<b>PORT CITY AIR CONDITIONING PTY LTD</b> 3-15 Acton St, Toowoomba Brisbane	
<b>MECHANICAL SERVICES</b> LEVEL 59 TYPICAL FLOOR PLAN	
PROJECT NO: M107 SHEET NO: 15	FOR APPROVAL



**NOTES**

1. ALL WORK SHALL BE IN ACCORDANCE WITH THE CONTRACT DOCUMENTS AND THE NATIONAL BUILDING REGULATIONS.
2. THE CONTRACTOR SHALL BE RESPONSIBLE FOR OBTAINING ALL NECESSARY PERMITS AND APPROVALS FROM THE RELEVANT AUTHORITIES.
3. THE CONTRACTOR SHALL BE RESPONSIBLE FOR PROTECTING ALL EXISTING SERVICES AND STRUCTURES.
4. ALL WORK SHALL BE COMPLETED WITHIN THE SPECIFIED TIME FRAME.
5. THE CONTRACTOR SHALL BE RESPONSIBLE FOR THE PROTECTION OF ALL ADJACENT AREAS.
6. ALL MATERIALS AND WORKMANSHIP SHALL BE SUBJECT TO INSPECTION AND APPROVAL BY THE RELEVANT AUTHORITIES.
7. THE CONTRACTOR SHALL BE RESPONSIBLE FOR THE DISPOSAL OF ALL WASTE MATERIALS.
8. ALL WORK SHALL BE COMPLETED IN ACCORDANCE WITH THE RELEVANT STANDARDS AND SPECIFICATIONS.
9. THE CONTRACTOR SHALL BE RESPONSIBLE FOR THE PROTECTION OF ALL EXISTING SERVICES AND STRUCTURES.
10. ALL WORK SHALL BE COMPLETED WITHIN THE SPECIFIED TIME FRAME.
11. THE CONTRACTOR SHALL BE RESPONSIBLE FOR THE PROTECTION OF ALL ADJACENT AREAS.

**FOR APPROVAL**

DATE: 15/08/2024

BY: [Signature]

PROJECT: 3-15 Acker St, Looming Brisbane

MECHANICAL SERVICES LEVEL 10 FLOOR PLAN

MECHANICAL SERVICES

3-15 Acker St, Looming Brisbane

The Patterson by Mosaic

PORT CITY AIR CONDITIONING PTY LTD


4/200 BROADWAY, BRISBANE QLD 4000

P: 07 3250 1234 F: 07 3250 1235

E: info@portcityair.com.au W: www.portcityair.com.au

MECHANICAL SERVICES

NO.	DESCRIPTION	DATE	BY
1	ISSUED FOR APPROVAL	15/08/2024	[Signature]
2	REVISION		
3	REVISION		
4	REVISION		
5	REVISION		
6	REVISION		
7	REVISION		
8	REVISION		
9	REVISION		
10	REVISION		
11	REVISION		



SEE DWG. BELOW OF PAGE FOR CONTINUATION


SEE DWG. ABOVE OF PAGE FOR CONTINUATION

**NOTES**

- 1) ALL WORK SHALL BE IN ACCORDANCE WITH THE CONDITIONS OF THE CONTRACT AND THE NATIONAL FIRE PROTECTION ASSOCIATION (NFPA) 96A, 97A, 99A, 101A, 102A, 103A, 104A, 105A, 106A, 107A, 108A, 109A, 110A, 111A, 112A, 113A, 114A, 115A, 116A, 117A, 118A, 119A, 120A, 121A, 122A, 123A, 124A, 125A, 126A, 127A, 128A, 129A, 130A, 131A, 132A, 133A, 134A, 135A, 136A, 137A, 138A, 139A, 140A, 141A, 142A, 143A, 144A, 145A, 146A, 147A, 148A, 149A, 150A, 151A, 152A, 153A, 154A, 155A, 156A, 157A, 158A, 159A, 160A, 161A, 162A, 163A, 164A, 165A, 166A, 167A, 168A, 169A, 170A, 171A, 172A, 173A, 174A, 175A, 176A, 177A, 178A, 179A, 180A, 181A, 182A, 183A, 184A, 185A, 186A, 187A, 188A, 189A, 190A, 191A, 192A, 193A, 194A, 195A, 196A, 197A, 198A, 199A, 200A, 201A, 202A, 203A, 204A, 205A, 206A, 207A, 208A, 209A, 210A, 211A, 212A, 213A, 214A, 215A, 216A, 217A, 218A, 219A, 220A, 221A, 222A, 223A, 224A, 225A, 226A, 227A, 228A, 229A, 230A, 231A, 232A, 233A, 234A, 235A, 236A, 237A, 238A, 239A, 240A, 241A, 242A, 243A, 244A, 245A, 246A, 247A, 248A, 249A, 250A, 251A, 252A, 253A, 254A, 255A, 256A, 257A, 258A, 259A, 260A, 261A, 262A, 263A, 264A, 265A, 266A, 267A, 268A, 269A, 270A, 271A, 272A, 273A, 274A, 275A, 276A, 277A, 278A, 279A, 280A, 281A, 282A, 283A, 284A, 285A, 286A, 287A, 288A, 289A, 290A, 291A, 292A, 293A, 294A, 295A, 296A, 297A, 298A, 299A, 300A, 301A, 302A, 303A, 304A, 305A, 306A, 307A, 308A, 309A, 310A, 311A, 312A, 313A, 314A, 315A, 316A, 317A, 318A, 319A, 320A, 321A, 322A, 323A, 324A, 325A, 326A, 327A, 328A, 329A, 330A, 331A, 332A, 333A, 334A, 335A, 336A, 337A, 338A, 339A, 340A, 341A, 342A, 343A, 344A, 345A, 346A, 347A, 348A, 349A, 350A, 351A, 352A, 353A, 354A, 355A, 356A, 357A, 358A, 359A, 360A, 361A, 362A, 363A, 364A, 365A, 366A, 367A, 368A, 369A, 370A, 371A, 372A, 373A, 374A, 375A, 376A, 377A, 378A, 379A, 380A, 381A, 382A, 383A, 384A, 385A, 386A, 387A, 388A, 389A, 390A, 391A, 392A, 393A, 394A, 395A, 396A, 397A, 398A, 399A, 400A, 401A, 402A, 403A, 404A, 405A, 406A, 407A, 408A, 409A, 410A, 411A, 412A, 413A, 414A, 415A, 416A, 417A, 418A, 419A, 420A, 421A, 422A, 423A, 424A, 425A, 426A, 427A, 428A, 429A, 430A, 431A, 432A, 433A, 434A, 435A, 436A, 437A, 438A, 439A, 440A, 441A, 442A, 443A, 444A, 445A, 446A, 447A, 448A, 449A, 450A, 451A, 452A, 453A, 454A, 455A, 456A, 457A, 458A, 459A, 460A, 461A, 462A, 463A, 464A, 465A, 466A, 467A, 468A, 469A, 470A, 471A, 472A, 473A, 474A, 475A, 476A, 477A, 478A, 479A, 480A, 481A, 482A, 483A, 484A, 485A, 486A, 487A, 488A, 489A, 490A, 491A, 492A, 493A, 494A, 495A, 496A, 497A, 498A, 499A, 500A, 501A, 502A, 503A, 504A, 505A, 506A, 507A, 508A, 509A, 510A, 511A, 512A, 513A, 514A, 515A, 516A, 517A, 518A, 519A, 520A, 521A, 522A, 523A, 524A, 525A, 526A, 527A, 528A, 529A, 530A, 531A, 532A, 533A, 534A, 535A, 536A, 537A, 538A, 539A, 540A, 541A, 542A, 543A, 544A, 545A, 546A, 547A, 548A, 549A, 550A, 551A, 552A, 553A, 554A, 555A, 556A, 557A, 558A, 559A, 560A, 561A, 562A, 563A, 564A, 565A, 566A, 567A, 568A, 569A, 570A, 571A, 572A, 573A, 574A, 575A, 576A, 577A, 578A, 579A, 580A, 581A, 582A, 583A, 584A, 585A, 586A, 587A, 588A, 589A, 590A, 591A, 592A, 593A, 594A, 595A, 596A, 597A, 598A, 599A, 600A, 601A, 602A, 603A, 604A, 605A, 606A, 607A, 608A, 609A, 610A, 611A, 612A, 613A, 614A, 615A, 616A, 617A, 618A, 619A, 620A, 621A, 622A, 623A, 624A, 625A, 626A, 627A, 628A, 629A, 630A, 631A, 632A, 633A, 634A, 635A, 636A, 637A, 638A, 639A, 640A, 641A, 642A, 643A, 644A, 645A, 646A, 647A, 648A, 649A, 650A, 651A, 652A, 653A, 654A, 655A, 656A, 657A, 658A, 659A, 660A, 661A, 662A, 663A, 664A, 665A, 666A, 667A, 668A, 669A, 670A, 671A, 672A, 673A, 674A, 675A, 676A, 677A, 678A, 679A, 680A, 681A, 682A, 683A, 684A, 685A, 686A, 687A, 688A, 689A, 690A, 691A, 692A, 693A, 694A, 695A, 696A, 697A, 698A, 699A, 700A, 701A, 702A, 703A, 704A, 705A, 706A, 707A, 708A, 709A, 710A, 711A, 712A, 713A, 714A, 715A, 716A, 717A, 718A, 719A, 720A, 721A, 722A, 723A, 724A, 725A, 726A, 727A, 728A, 729A, 730A, 731A, 732A, 733A, 734A, 735A, 736A, 737A, 738A, 739A, 740A, 741A, 742A, 743A, 744A, 745A, 746A, 747A, 748A, 749A, 750A, 751A, 752A, 753A, 754A, 755A, 756A, 757A, 758A, 759A, 760A, 761A, 762A, 763A, 764A, 765A, 766A, 767A, 768A, 769A, 770A, 771A, 772A, 773A, 774A, 775A, 776A, 777A, 778A, 779A, 780A, 781A, 782A, 783A, 784A, 785A, 786A, 787A, 788A, 789A, 790A, 791A, 792A, 793A, 794A, 795A, 796A, 797A, 798A, 799A, 800A, 801A, 802A, 803A, 804A, 805A, 806A, 807A, 808A, 809A, 810A, 811A, 812A, 813A, 814A, 815A, 816A, 817A, 818A, 819A, 820A, 821A, 822A, 823A, 824A, 825A, 826A, 827A, 828A, 829A, 830A, 831A, 832A, 833A, 834A, 835A, 836A, 837A, 838A, 839A, 840A, 841A, 842A, 843A, 844A, 845A, 846A, 847A, 848A, 849A, 850A, 851A, 852A, 853A, 854A, 855A, 856A, 857A, 858A, 859A, 860A, 861A, 862A, 863A, 864A, 865A, 866A, 867A, 868A, 869A, 870A, 871A, 872A, 873A, 874A, 875A, 876A, 877A, 878A, 879A, 880A, 881A, 882A, 883A, 884A, 885A, 886A, 887A, 888A, 889A, 890A, 891A, 892A, 893A, 894A, 895A, 896A, 897A, 898A, 899A, 900A, 901A, 902A, 903A, 904A, 905A, 906A, 907A, 908A, 909A, 910A, 911A, 912A, 913A, 914A, 915A, 916A, 917A, 918A, 919A, 920A, 921A, 922A, 923A, 924A, 925A, 926A, 927A, 928A, 929A, 930A, 931A, 932A, 933A, 934A, 935A, 936A, 937A, 938A, 939A, 940A, 941A, 942A, 943A, 944A, 945A, 946A, 947A, 948A, 949A, 950A, 951A, 952A, 953A, 954A, 955A, 956A, 957A, 958A, 959A, 960A, 961A, 962A, 963A, 964A, 965A, 966A, 967A, 968A, 969A, 970A, 971A, 972A, 973A, 974A, 975A, 976A, 977A, 978A, 979A, 980A, 981A, 982A, 983A, 984A, 985A, 986A, 987A, 988A, 989A, 990A, 991A, 992A, 993A, 994A, 995A, 996A, 997A, 998A, 999A, 1000A.

<b>MECHANICAL SERVICES</b> <b>LEVEL 11 FLOOR PLAN</b>	
The Patterson by Mosaic 3-115 Acter St, Looming Brisbane	
<b>PORT CITY AIR CONDITIONING PTY LTD</b> 1/100 SOUTH BRISBANE ROAD BRISBANE QLD 4000 P: 07 3250 1000 F: 07 3250 1001 E: info@portcityair.com.au W: www.portcityair.com.au	
DRAWN BY: M109 CHECKED BY: M109 DATE: 14	FOR APPROVAL





SEE DWG ABOVE OF PAGE FOR CONTINUATION


SEE DWG BELOW OF PAGE FOR CONTINUATION

**NOTES**

1. ALL WORK TO BE IN ACCORDANCE WITH THE CONTRACT DOCUMENTS AND THE SPECIFICATIONS.
2. THE CONTRACTOR SHALL BE RESPONSIBLE FOR OBTAINING ALL NECESSARY PERMITS AND APPROVALS FROM THE LOCAL AUTHORITIES.
3. THE CONTRACTOR SHALL BE RESPONSIBLE FOR PROTECTING ALL EXISTING SERVICES AND STRUCTURES.
4. ALL WORK SHALL BE COMPLETED WITHIN THE SPECIFIED TIME FRAME.
5. THE CONTRACTOR SHALL BE RESPONSIBLE FOR THE DISPOSAL OF ALL WASTE MATERIALS.
6. ALL WORK SHALL BE COMPLETED TO THE SATISFACTION OF THE ARCHITECT.
7. THE CONTRACTOR SHALL BE RESPONSIBLE FOR THE PROTECTION OF ALL ADJACENT AREAS.
8. ALL WORK SHALL BE COMPLETED IN ACCORDANCE WITH THE LOCAL REGULATIONS.
9. THE CONTRACTOR SHALL BE RESPONSIBLE FOR THE PROTECTION OF ALL EXISTING SERVICES.
10. ALL WORK SHALL BE COMPLETED WITHIN THE SPECIFIED TIME FRAME.
11. THE CONTRACTOR SHALL BE RESPONSIBLE FOR THE DISPOSAL OF ALL WASTE MATERIALS.

<b>PORT CITY AIR CONDITIONING PTY LTD</b> 4/200 North Road, North Sydney, NSW 1585 P: 02 9439 1000 F: 02 9439 1001 www.portcityairconditioning.com.au	
The Patterson by Mosaic 3-15 Actar St, Looming Brisbane	
<b>MECHANICAL SERVICES</b> <b>LEVEL 12 FLOOR PLAN</b>	
DRAWN BY: M110 CHECKED BY: M110 DATE: 15/11/2023	FOR APPROVAL DATE: 15/11/2023





SEE DWG BELOW OF PAGE FOR CONTINUATION

SEE DWG ABOVE OF PAGE FOR CONTINUATION

**NOTES**

- 1) ALL WORK TO BE COMPLETED IN ACCORDANCE WITH THE CONTRACT DOCUMENTS AND THE SPECIFICATIONS.
- 2) THE CONTRACTOR SHALL BE RESPONSIBLE FOR OBTAINING ALL NECESSARY PERMITS AND APPROVALS FROM THE LOCAL AUTHORITIES.
- 3) THE CONTRACTOR SHALL BE RESPONSIBLE FOR PROTECTING ALL EXISTING UTILITIES AND STRUCTURES.
- 4) THE CONTRACTOR SHALL BE RESPONSIBLE FOR THE PROTECTION OF ALL ADJACENT AREAS.
- 5) THE CONTRACTOR SHALL BE RESPONSIBLE FOR THE PROTECTION OF ALL EXISTING WORK.
- 6) THE CONTRACTOR SHALL BE RESPONSIBLE FOR THE PROTECTION OF ALL EXISTING WORK.
- 7) THE CONTRACTOR SHALL BE RESPONSIBLE FOR THE PROTECTION OF ALL EXISTING WORK.
- 8) THE CONTRACTOR SHALL BE RESPONSIBLE FOR THE PROTECTION OF ALL EXISTING WORK.
- 9) THE CONTRACTOR SHALL BE RESPONSIBLE FOR THE PROTECTION OF ALL EXISTING WORK.
- 10) THE CONTRACTOR SHALL BE RESPONSIBLE FOR THE PROTECTION OF ALL EXISTING WORK.
- 11) THE CONTRACTOR SHALL BE RESPONSIBLE FOR THE PROTECTION OF ALL EXISTING WORK.

**FOR APPROVAL**


DATE: 11/11/2024

BY: [Signature]

PROJECT: **PORT CITY AIR CONDITIONING PTY LTD**  
 3-15 Acton St, Toowoomba Brisbane

MECHANICAL SERVICES  
 LEVEL 13 FLOOR PLAN


NO.	DESCRIPTION	DATE	BY
1	ISSUED FOR TENDER	11/11/2024	[Signature]
2	FOR APPROVAL	11/11/2024	[Signature]
3	FOR APPROVAL	11/11/2024	[Signature]
4	FOR APPROVAL	11/11/2024	[Signature]
5	FOR APPROVAL	11/11/2024	[Signature]
6	FOR APPROVAL	11/11/2024	[Signature]
7	FOR APPROVAL	11/11/2024	[Signature]
8	FOR APPROVAL	11/11/2024	[Signature]
9	FOR APPROVAL	11/11/2024	[Signature]
10	FOR APPROVAL	11/11/2024	[Signature]
11	FOR APPROVAL	11/11/2024	[Signature]



**NOTES**

1. ALL WORK SHALL BE IN ACCORDANCE WITH THE CONDITIONS OF THE CONTRACT AND THE SPECIFICATIONS.
2. THE CONTRACTOR SHALL BE RESPONSIBLE FOR OBTAINING ALL NECESSARY PERMITS AND APPROVALS FROM THE LOCAL AUTHORITIES.
3. THE CONTRACTOR SHALL BE RESPONSIBLE FOR PROTECTING ALL EXISTING SERVICES AND STRUCTURES.
4. THE CONTRACTOR SHALL BE RESPONSIBLE FOR THE PROTECTION OF ALL ADJACENT AREAS AND PROPERTIES.
5. THE CONTRACTOR SHALL BE RESPONSIBLE FOR THE PROTECTION OF ALL EXISTING UTILITIES AND SERVICES.
6. THE CONTRACTOR SHALL BE RESPONSIBLE FOR THE PROTECTION OF ALL EXISTING STRUCTURES AND SERVICES.
7. THE CONTRACTOR SHALL BE RESPONSIBLE FOR THE PROTECTION OF ALL EXISTING UTILITIES AND SERVICES.
8. THE CONTRACTOR SHALL BE RESPONSIBLE FOR THE PROTECTION OF ALL EXISTING STRUCTURES AND SERVICES.
9. THE CONTRACTOR SHALL BE RESPONSIBLE FOR THE PROTECTION OF ALL EXISTING UTILITIES AND SERVICES.
10. THE CONTRACTOR SHALL BE RESPONSIBLE FOR THE PROTECTION OF ALL EXISTING STRUCTURES AND SERVICES.
11. THE CONTRACTOR SHALL BE RESPONSIBLE FOR THE PROTECTION OF ALL EXISTING UTILITIES AND SERVICES.

<b>PORT CITY AIR CONDITIONING PTY LTD</b> 1/150 North Street, Sydney NSW 1585 P: 02 9439 1000 F: 02 9439 1001 www.portcityairconditioning.com.au	
<b>The Patterson by Mosaic</b> 3-15 Archer St, Loomville Brisbane	
<b>MECHANICAL SERVICES</b> LEVEL 4 FLOOR PLAN	
DRAWN BY: [Name] CHECKED BY: [Name] DATE: [Date]	FOR APPROVAL DATE: [Date]



SEE DWG ABOVE OF PAGE FOR CONTINUATION

SEE DWG BELOW OF PAGE FOR CONTINUATION

**NOTES**

1. ALL WORK TO BE COMPLETED IN ACCORDANCE WITH THE CONTRACT DOCUMENTS AND THE SPECIFICATIONS.
2. THE CONTRACTOR SHALL BE RESPONSIBLE FOR OBTAINING ALL NECESSARY PERMITS AND APPROVALS FROM THE LOCAL AUTHORITIES.
3. THE CONTRACTOR SHALL MAINTAIN ACCESS TO ALL EXISTING SERVICES AND UTILITIES AT ALL TIMES.
4. THE CONTRACTOR SHALL PROTECT ALL EXISTING STRUCTURAL ELEMENTS AND SERVICES.
5. THE CONTRACTOR SHALL BE RESPONSIBLE FOR THE PROTECTION AND REPAIR OF ALL EXISTING FINISHES.
6. THE CONTRACTOR SHALL MAINTAIN CLEAR ACCESS TO ALL EXISTING EXITS AND EGRESS ROUTES.
7. THE CONTRACTOR SHALL BE RESPONSIBLE FOR THE PROTECTION AND REPAIR OF ALL EXISTING MECHANICAL AND ELECTRICAL SERVICES.
8. THE CONTRACTOR SHALL MAINTAIN CLEAR ACCESS TO ALL EXISTING EXITS AND EGRESS ROUTES.
9. THE CONTRACTOR SHALL BE RESPONSIBLE FOR THE PROTECTION AND REPAIR OF ALL EXISTING MECHANICAL AND ELECTRICAL SERVICES.
10. THE CONTRACTOR SHALL MAINTAIN CLEAR ACCESS TO ALL EXISTING EXITS AND EGRESS ROUTES.
11. THE CONTRACTOR SHALL BE RESPONSIBLE FOR THE PROTECTION AND REPAIR OF ALL EXISTING MECHANICAL AND ELECTRICAL SERVICES.

<b>PORT CITY AIR CONDITIONING PTY LTD</b> 3-15 Archer St, Toowoomba, Brisbane	
<b>Mechanical Services</b> Level 5 Floor Plan	
PROJECT NO: M113 DATE: 15/08/2024	FOR APPROVAL SIGNATURE: _____ TITLE: _____

This form is to be used for the purposes of sections 74 and 77 of the Building Regulation 2021 (appointed competent person statement that an aspect of work has been completed and complies with the building development approval).

Information about how to complete this form is in the Appendix at the end of the form.

### 1. Indicate the aspect of the building work

Examples of aspects of the stage of building work (and not limited to the examples provided below):

waterproofing, tiling, glazing, energy efficiency, emergency lights, exit signs, smoke detection, air-conditioning.

Aspect of building work (indicate the aspect)

Mechanical Air Conditioning and Ventilation

### 2. Property description

The description must identify all land the subject of the application.

The lot and plan details (e.g. SP/RP) are shown on title documents or a rates notice.

If the plan is not registered by title, provide previous lot and plan details.

Street address	3 – 15 Archer Street		
	Suburb/locality	Toowong	
State	QLD	Postcode	4066

Lot and plan details (*attach list if necessary*)

L2 & L3 on RP.70716

Local government area the land is situated in

Brisbane City Council

### 3. Building/structure description

Building/structure description

Seismic restraint of suspended mechanical services, floor mounted equipment, refrigerant pipework



---

Class of building/structure

Class 2 & 7a

---

#### 4. Description of the extent of aspect/s certified

Clearly describe the extent of work covered by this certificate, i.e. all structural aspects of the steel roof beams and location i.e. what floors the work was on, the parts of a room.

Mechanical ( Air Conditioning, Smoke exhaust, Carpark exhaust, Dampers, Zones, Ventilation, Toilet exhaust)

---

#### 5. Basis of certification

Detail the basis for giving the certificate and the extent to which tests, specifications, rules, standards, codes of practice and other publications were relied upon.

AS/NZA1170.0 – 2002 General Principles  
AS/NZS 1170.4 – 2007 Earthquake Actions in Australia  
AS4100 – 1998 Steel Structures  
AS4600 – 2018 Cold Form Steel Structures  
FER 5766102 Rev. D

---

#### 6. Reference documentation

Clearly identify any relevant documentation, e.g. numbered structural engineering plans.

Gripple Drawings: H1119-SR-1 to SR-14  
SRD-1C, SRD-2B, SRD-5, SRD-5.2  
Gripple Calcs: H1119-CW-1-1 to H1119-CW-1-18

## 7. Building certifier reference number and building development approval number

Building certifier's name <i>(in full)</i>			
Building certifier reference number	Development approval number	A005708978	

## 8. Details of appointed competent person

Name <i>(in full)</i>	Daine Ross Smith		
Company name <i>(if applicable)</i>	Port City Air Conditioning Pty Ltd		
Contact person	Daine Ross Smith		
Business phone number	07 5443 4095	Mobile	0439 665 398
Email address	<a href="mailto:daine@portcityair.com.au">daine@portcityair.com.au</a>		
Postal address	PO Box 6017		
	Suburb/locality	Maroochydore	
State	QLD	Postcode	4558
Licence class or registration type <i>(if applicable)</i>	Refrigeration, Air conditioning & Mechanical Services incl Limited Design		
Licence class or registration number <i>(if applicable)</i>	11804073		
Date request to inspect received from building certifier	9/03/2023		

## 9. Signature of appointed competent person

Signature	Date	9/03/2023
-----------	------	-----------

## LOCAL GOVERNMENT USE ONLY

Date received	Click or tap to enter a date.	Reference number/s	
---------------	-------------------------------	--------------------	--

## Appendix – explanatory information

**IMPORTANT NOTE:** a competent person who knowingly or reasonably suspects the information they are giving to the building certifier is false or misleading, including the information contained in this certificate (Form 12), commits an offence and is liable to a maximum penalty of 100 penalty units.

**When is this certificate needed?** (sections 10 of the *Building Act 1975* (Building Act) and 75 of Building Regulation 2021 (BR 2021))

When performing a building certification function, a building certifier may accept and rely on **an aspect inspection certificate** from an appointed competent person to satisfy themselves that an aspect of work has been completed and complies with the building development approval.

For a single detached class 1a building a building certifier can only accept this form for an aspect of work that is for

- boundary clearance if the appointed competent person is a cadastral surveyor, and,
- the reinforcement of footing systems if the appointed competent person is the appropriate registered professional engineer.

For further information about inspections for detached class 1a and 10 buildings or structures, refer to **Guideline for inspections of class 1 and 10 buildings and structures**.

**Who can sign this certificate (Form 12)?** (Part 9, Division 2, Section 74 of the BR 2021)

A person assessed and appointed as a competent person (inspections) must complete the approved form (Form 12) and give it to the building certifier after they (1) inspect the aspect of work; and (2) are satisfied the aspect of work has been completed and complies with the building development approval.

**Competent person** (section 10 Part 6 of the BR 2021)

A building certifier must assess and decide to appoint an individual as a competent person before they can, as a competent person, give inspection help or design-specification help. The building certifier is required to keep detailed records about what was considered when appointing a competent person.

A competent person cannot give inspection help to a building certifier until they have been appointed by the building certifier. For further information about assessment of someone as a competent person refer to the **Guideline for the assessment of competent persons**.

**Inspection help** (section 34 of the BR 2021)

A building certifier must be satisfied that an individual is competent to give the type of inspection help having regard to the individual's experience, qualifications and skills and if required by law to hold a licence or registration, that the individual is appropriately registered or licensed.

For further information about conducting inspections for class 2 to 9 buildings, refer to the **Guideline for inspection of class 2 to 9 buildings**.

## How to complete this form

### Section 1 – Aspect of building work

An aspect of building work means a component of a stage of the building work, for example water proofing. A stage of assessable building work (requires a building development approval) is a stage of the work, prescribed by regulation, that may be inspected, or stated in a building development approval by the relevant building certifier.

### Section 2 – Property description

The property description must identify all the land the subject of the application. The lot and plan details (e.g. SP/RP) can be found on title documents or a rates notice. If the plan is not registered by title, provide previous lot and plan details.

### Section 3 – Building / structure description

Describe the type of building or structures and provide the classification determined under the National Construction Code (NCC). The NCC can be accessed at the Australian Building Codes Board's website.

### Section 4 – Describe the extent or location of the aspect work inspected.

Clearly describe the extent of work covered by this certificate, i.e. all structural aspects of the steel roof beams and location i.e. what floors the work was on, the parts of a room.

### Sections 5 – Basis for the certification and section 6 Reference documentation (section 77 of BR 2021)

The appointed competent person (inspections) must state the basis for giving the certificate (Form 12) including the extent to which the competent person has relied on tests, specifications, rules, standards, codes of practice or other publications to make their decision that the aspect of work has been completed and complies with the building development approval.

Under the regulation (section 76) the appointed competent person (inspections) may accept and rely on a certificate (Form 12) from another appointed competent person (inspections) without inspecting the work. Although this can only be done if the inspection was carried out in accordance with best industry practice.

#### **Other relevant inspection / aspect forms**

**Aspect work – assessable building work: Form 43 – Aspect certificate (completed by a QBCC licensee)** for aspect work for a single detached class 1a building and class 10 buildings and structures.

**Aspect work not subject to a building development approval - accepted development (self-assessable): Form 30 – (completed by a QBCC licensee)** given to either the builder or building owner of the building, stating the subject aspect work complies with the relevant provisions, standards and codes.

**Stages of work: Form 16 – Inspection certificate (completed by a building certifier or competent person)** for a stage of work.

**Building design – specification: Form 15 – Compliance certificate for building design or specification (completed by the appointed competent person (design – specification))** - for an aspect of stating a building design – specification will, if installed or carried out to the detail under this Form will comply with the building assessment provisions.

For all other building forms and guidelines visit the [Business Queensland website](#).

#### **PRIVACY NOTICE**

The Department of Energy and Public Works is collecting personal information as required under the *Building Act 1975*. This information may be stored by the Department, and will be used for administration, compliance, statistical research and evaluation of building laws. Your personal information will be disclosed to other government agencies, local government authorities and third parties for purposes relating to administering and monitoring compliance with the *Building Act 1975*. Personal information will otherwise only be disclosed to third parties with your consent or unless authorised or required by law.



Department of Housing and Public Works  
**Form 15—Compliance certificate  
 for building design or  
 specification**

Version 4 – July 2017

**NOTE:** This is to be used for the purposes of section 10 of the *Building Act 1975* and/or section 46 of the *Building Regulation 2006*.

**RESTRICTION:** A building certifier (class B) can only give a compliance certificate about whether building work complies with the BCA or a provision of the Queensland Development Code (QDC). A building certifier (Class B) can not give a certificate regarding QDC boundary clearance and site cover provisions.

**1. Property description**

This section need only be completed if details of street address and property description are applicable.

E.g. in the case of (standard/generic) pool design/shell manufacture and/or patio and carport systems this section may not be applicable.

The description must identify all land the subject of the application.

The lot and plan details (e.g. SP/RP) are shown on title documents or a rates notice.

If the plan is not registered by title, provide previous lot and plan details.

**Street address** (include no., street, suburb/locality and postcode)

3-15 ARCHER ST, TOOWONG, BRISBANE

**Lot and plan details** (attach list if necessary)

**In which local government area is the land situated?**

Brisbane City Council

**2. Description of component/s certified**

Clearly describe the extent of work covered by this certificate, e.g. all structural aspects of the steel roof beams.

Seismic restraint of suspended mechanical services, floor mounted equipment, refrigerant pipework

**3. Basis of certification**

Detail the basis for giving the certificate and the extent to which tests, specifications, rules, standards, codes of practice and other publications, were relied upon.

AS/NZS1170.0 - 2002 General Principles

AS/NZS1170.4 - 2007 Earthquake Actions in Australia

AS4100 - 1998 Steel Structures

AS4600 - 2018 Cold Form Steel Structures

**4. Reference documentation**

Clearly identify any relevant documentation, e.g. numbered structural engineering plans.

Gripple Drawings: H1119-SR-1 to SR-14 (ALL REV A)

Gripple Drawings: SRD-1C, SRD-2B, SRD-5(REV A), SRD-5.2 (Rev A)

Gripple Calcs: H1119-CW-1-1 to H1119-CW-1-18 (All REV A)

**LOCAL GOVERNMENT USE ONLY**

Date received

Reference Number/s

<b>5. Building certifier reference number</b>	<b>Building certifier reference number</b> <input type="text"/>
<b>6. Competent person details</b> A competent person for building work, means a person who is assessed by the building certifier for the work as competent to practice in an aspect of the building and specification design, of the building work because of the individual's skill, experience and qualifications in the aspect. The competent person must also be registered or licensed under a law applying in the State to practice the aspect.  If no relevant law requires the individual to be licensed or registered to be able to give the help, the certifier must assess the individual as having appropriate experience, qualifications or skills to be able to give the help.  If the chief executive issues any guidelines for assessing a competent person, the building certifier must use the guidelines when assessing the person.	<b>Name (in full)</b> <input type="text" value="Lachlan Rhodes"/> <b>Company name (if applicable)</b> <input type="text" value="Polyplas Intl."/> <b>Contact person</b> <input type="text"/> <b>Phone no. (business hours)</b> <input type="text" value="03 9754 0333"/> <b>Mobile no.</b> <input type="text" value="0400610942"/> <b>Fax no.</b> <input type="text"/> <b>Email address</b> <input type="text" value="lachlan@griipple.net.au"/> <b>Postal address</b> <input type="text" value="3 Corporate Ave"/> <input type="text" value="Rowville, VIC"/> <b>Postcode</b> <input type="text" value="3178"/> <b>Licence or registration number (if applicable)</b> <input type="text" value="RPEQ - 24401"/>
<b>7. Signature of competent person</b> This certificate must be signed by the individual assessed by the building certifier as competent.	<b>Signature</b> <input type="text" value="L Rhodes"/> <b>Date</b> <input type="text" value="29/9/21"/>

The *Building Act 1975* is administered by the Department of Housing and Public Works



## Section 7

### AS BUILT DRAWINGS

**Office:** 2/30 Access Crescent, Coolum Beach, QLD 4573  
**Postal:** PO Box 6017, Maroochydore, Qld 4558  
**Email:** [admin@portcityairconditioning.com.au](mailto:admin@portcityairconditioning.com.au)  
**Phone:** 1300 PORT CITY / 07 4972 3355 **Fax:** 07 4972 1791

**After Hours Emergency Phone:** 0439 665 398  
**Website:** <http://www.portcitygroup.com.au/>

ABN: 99 717 077 615 / QBCC: 1184073 / ARCTICK: AU12994 / ELEC: 73329



# The Patterson by Mosaic

## 3-15 Archer St, Toowong, Brisbane

### MECHANICAL SERVICES

#### GENERAL NOTE

Scope of Works  
Provide & install a fully operational car park ventilation systems complete with control system, detectors, dampers and FPI interface as indicated.  
Provide & install general ground floor ventilation systems to all base building areas such as switch rooms, garbage rooms, pump rooms and the like including controls interlocking and sensors.  
Provide general ventilation systems to apartment levels in compliance with NCC2019 (which refers back to EC A2016).  
Ensure correct maintenance records are kept for the the whole system in a hard copy manual in the controls cabinet referring documents to site traffic/ke labelling.

#### Builders Work

Concrete slabs for condensing units (Galvanised channel angle surrounds to be provided and installed by mechanical contractor, filled in by builder).  
Access panels to and clear space in ceiling space for servicing of plant and equipment.  
Installation only of door grilles, supplied by Mechanical Services and undercutting doors as shown on drawings.  
Under flashing of wall and roof penetrations.  
Drain points for condensate as indicated on drawings.  
Formed and trimmed openings through walls and ceilings for mechanical and electrical components.  
Provision of core holes through floors and walls.  
Co-ordination of the Mechanical Services installation to fit in with the construction programme.  
Temporary light and power during construction.

#### Electrical Services

Single phase power supplies to isolators adjacent to all mechanical services plant as indicated on drawings (for final connection by Mechanical Services).  
Three phase power supplies to isolator adjacent to the mechanical services plant as indicated on drawings (for final connection by mechanical contractor)

#### Codes & Standards

The whole of the work specified shall be in accordance with the current issue of the following -  
National Construction Code (NCC) 2019 for B1 B2, Mezzanine, ground floor, level 2 & level 3.  
Building Code of Australia 2016 applies to only apartment levels, in particular with respect to ventilation.  
NCC 2019 section B3.5, F6.3 apply to all apartment levels.  
All ductwork to comply with AS 4254 parts 1 & 2 (flexible duct and rigid respectively).  
Fire and smoke damper selection shall be installed in compliance with AS1851  
QDC MR4.1 - Queensland Development Mandatory Code Part 4.1 Sustainable Buildings.  
AS 1470 Health and Safety at Work - Principle and Practices  
AS 1668 - Part 1 (2015) Fire and Smoke Control Systems.  
AS 1668 - Part 2: Mechanical ventilation for acceptable indoor air quality).  
AS 5149 2016 - (2012) Refrigeration systems.  
AS 3000 - Wiring Rules.  
AS/NZS 3823 - Performance of electrical appliances - air conditioners and heat pumps.  
AS 3696 - Air Handling and Water Systems of Buildings  
AS/NZS 3823.2 (MDS)  
AS/NZS 4755.3.1 (DRM1, 2 and 3)  
AS1170 4-2007 - Seismic Restraint  
All other relevant Acts and Regulations, Local Authority Requirements, Australian Standards and Codes having jurisdiction.

#### Roof Space Mounted Exhaust Fans

Fans mounted in the roof space shall be directly driven by external rotors. Provide directional arrows for rotation and air flow.  
The fan shall be suspended from the roof structure by spring mounted supports complete with neoprene pads and grommets to prevent vibration transmission to the building structure.

#### Filters

Filters for ducted fan coil units shall be a 100mm disposed dry media (F5 rating to AS1342).

#### Air Distribution System

Rectangular ductwork construction  
Ductwork shall be fabricated from first quality patent-laminated galvanized sheet steel.  
Ductwork construction shall be based upon SWACNA Standards and AS4254.

#### Control dampers

Opposed blade control dampers shall be fitted in main duct branches, generally where shown on the drawing and as necessary for system balancing and in return air, exhaust air and outside air inlet ducts or openings where balancing is required. Individual flexible duct take off spigots shall be fitted with Quad Lock dampers where further balancing is required.

#### Flexible Connections

Approved flexible connectors shall be provided between the inlets and outlets of all fans to adjacent ductwork ensuring they are truly aligned ensuring smooth air flow.  
Flexible connectors shall be readily accessible for maintenance, removal, and shall be positively airtight under full fan pressure.

#### Circular flexible ductwork

All flexible ductwork shall comply with AS 4254 and AS 4588.  
For ventilation and relief air applications the core shall be constructed with an aluminum / polyester film laminate incorporating a coated mechanical spring wire helix and solvent based adhesive as a minimum.  
All bends made in flexible ducting shall be formed to manufacturer's recommendations and shall have a centre-line radius of not less than 1.5 times the diameter of the ducts.  
Bends shall remain at full diameter throughout the length of the bend and all bends deformed or damaged in any way during installation shall be replaced with new bends.  
The inlets, spigots and reducer/expand fittings shall be of galvanneal metal exactly as specified for circular sheet metal ductwork.  
Duct connections shall be taped and smoothed with bands as follows:  
All joints shall be fixed with proprietary line duct bands. These shall be continuous type metal or PVC bands similar to "Bubble" hose clips or approved equivalent may be used.  
Self-tapping metal screws and nuts shall not be used.  
All flexible ducts shall be adequately supported with hanger straps and half saddles of "gutter guard" located at 1500 maximum centres, to prevent undue sagging and strictly in accordance with the requirements of this section of the specification.  
The ductwork shall have the following minimum indices when tested in accordance with AS 1530:  
-stability-0  
-spread of flame-0  
-heat evolved-0  
-Smoke Developed-3

#### Controls & sequencing

Each level of car park ventilation shall operate independently via controls module on mezzanine adjacent to VSD units. Refer to AS1668.2 (2012) 4.1.1 for parameters for ventilation system operation, flow rate setbacks and off periods.  
EF-1.1 & EF-1.2 shall operate together as one on a single VSD interlocked with controls programming to SF-1.1.  
EF-2.1 shall operate via a separate VSD interlocked with controls to SF-2.1  
SF-A&1 shall operate via a stand alone VSD  
SF-G&1 to operate matching air frequency of other 3 supply air fans when any SF-A&1, SF-1.1 or SF-2.1 operate.  
Note the carbon monoxide sensors shall be installed with modular sensor components that allows swap out procedure for detection components ensuring quick and economic ongoing testing for compliance purposes.

NO.	DRAWING TITLE
M000	DRAWING LIST, LEGENDS, NOTES, SYMBOLS
M001	SCHEDULED SHEET
M100	BASEMENT 2 FLOOR PLAN
M101	BASEMENT 1 FLOOR PLAN
M102	BASEMENT MEZZANINE FLOOR PLAN
M103	LEVEL 1 FLOOR PLAN
M104	LEVEL 2 FLOOR PLAN
M105	LEVEL 3 FLOOR PLAN
M106	LEVEL 4 FLOOR PLAN
M107	LEVEL 5 & TYPICAL FLOOR PLAN
M108	LEVEL 10 FLOOR PLAN
M109	LEVEL 11 FLOOR PLAN
M110	LEVEL 12 FLOOR PLAN
M111	LEVEL 13 FLOOR PLAN
M112	LEVEL 14 FLOOR PLAN
M113	LEVEL 15 TYPICAL FLOOR PLAN
M114	ROOF TERRACE FLOOR PLAN
M51	SECTION 1 TO 3
M52	SECTION 4 & 5
M53	SECTION 6L, 6R & 6C
BW100	BASEMENT 2 FLOOR PLAN (BUILDER WORKS)
BW101	BASEMENT 1 FLOOR PLAN (BUILDER WORKS)
BW102	BASEMENT MEZZANINE FLOOR PLAN (BUILDER WORKS)
BW103	LEVEL 1 FLOOR PLAN (BUILDER WORKS)
BW104	LEVEL 2 FLOOR PLAN (BUILDER WORKS)
BW105	LEVEL 3 FLOOR PLAN (BUILDER WORKS)
BW106	LEVEL 4 FLOOR PLAN (BUILDER WORKS)
BW107	LEVEL 5 & TYPICAL FLOOR PLAN (BUILDER WORKS)
BW108	LEVEL 10 FLOOR PLAN (BUILDER WORKS)
BW109	LEVEL 11 FLOOR PLAN (BUILDER WORKS)
BW110	LEVEL 12 FLOOR PLAN (BUILDER WORKS)
BW111	LEVEL 13 FLOOR PLAN (BUILDER WORKS)
BW112	LEVEL 14 FLOOR PLAN (BUILDER WORKS)
BW113	LEVEL 15 FLOOR PLAN (BUILDER WORKS)
BW114	ROOF TERRACE PLAN (BUILDER WORKS)


NO.	GENERAL NOTES
1	ALL DIMENSIONS ARE IN MILLIMETERS (MM) UNLESS OTHERWISE STATED.
2	DO NOT SCALE THIS DRAWING REFER TO WRITTEN DIMENSIONS ONLY
3	ALL DUCTWORK DIMENSIONS ARE EXTERNAL SHEETMETAL SIZES, WITH WIDTH IN CURRENT NEW SHOWING FIRST. BY COORDINATE WITH CURRENT WORK DUCT FLANGES AND HANGERS TO BE CONSIDERED WHEN COORDINATING OTHER SERVICES AND STRUCTURE.
4	ALL OF FLEXIBLE CONNECTION FROM UNIT TO FIRST DUCT HAVE 1 TOP END & 1 RE END J/L/O.
5	ALL DUCTWORK TO BE MADE FROM GALVANIZED SHEETMETAL UNLESS OTHERWISE STATED.
6	ALL DUCT TO BE CONSTRUCTED AND INSTALLED IN ACCORDANCE WITH AUSTRALIAN STANDARD "AS 4254 - DUCTWORK FOR AIRHANDLING SYSTEMS IN BUILDINGS"
7	ALL INTERNAL SURFACES THAT ARE IN CONTACT WITH AIR THROUGH AN AIR DIFFUSER, GRILLE OR LOUVER SHALL BE PAINTED MATT BLACK.
8	VERMIN PROOF MESH TO BE FITTED TO ALL LOUVERS AND REEFY VENTS.
9	RUN ALL CONDENSATE DRAINING TO TUNDRAYS PROVIDED BY BUILDER (MINIMUM 140 FALL)
10	REFRIGERANT RING AND CONDENSATE RING ARE DESIGNED INDICATIVELY AND SHALL BE COORDINATED ON SITE WITH OTHER TRADES AT SITE
11	CO-ORDINATE ACCESS PANEL LOCATIONS ON SITE WITH BUILDER.
12	ALL DUCTWORK EXPOSED TO WEATHER TO BE CROSS-BROKEN ON TOP
13	UNINSULATED DUCTWORK THAT REQUIRES REINFORCEMENT SHALL BE CROSS-BROKEN ON ALL SIDES.
14	ALL WALL AND ROOF PENETRATIONS & UPSTAND UNDERFLASHINGS BY BUILDER. OVERFLASHINGS BY MECHANICAL CONTRACTOR
15	THERMOSTAT LOCATIONS TO BE CONFIRMED BY ARCHITECT & SERVICES ENGINEER BEFORE INSTALLATION
16	VERIFY ALL DIMENSIONS FROM MECHANICAL WORKSHOP DRAWINGS AND ACTUAL SITE MEASUREMENTS. REUSE ON ANY DISCREPANCIES BEFORE PROCEEDING WITH WORKS
17	WORKSHOP DRAWINGS MUST BE READ IN CONJUNCTION WITH ALL OTHER TRADES DRAWINGS AND PROJECT CORRESPONDENCES
18	CONFIRM DUCTWORK SIZES ON SITE FOR CO-ORDINATED HIT PRIOR TO ORDERING EQUIPMENT OR MANUFACTURE.

SYMBOL	DUCTWORK LEGENDS
	14mm VENTED SIZE, 19mm NOT VENTED SIZE, 25mm LONG INCLUDED 5mm GROMMING CAUSE OF ACTUAL SITE INSTALLATION
	UNINSULATED DUCT
	100mm EXHAUST DUCTWORK
	TOP CROSS-BROKEN DUCTWORK
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	100mm INTERNAL INSULATION DUCTWORK (REFER NOTES ON DUCT NUMBERING IN CASE NO MATCH)
	150mm EXTERNAL INSULATION









BASEMENT 2  
27  
CARPARKS  
SL 5.600

REV	DESCRIPTION	BY	DATE
16	AS BUILT	AJUS	17.03.2023
15	UPDATED RCP LAYOUT AND RELOCATED FCU UNITS	AJUS	09.07.2022
14	UPDATED BACKGROUND	AJUS	11.05.2022
13	FOR APPROVAL	AJUS	17.03.2022
12	UPDATED UNIT MODEL	AJUS	14.10.2021
11	UPDATED MODEL AND LOCATION OF FAN	AJUS	03.10.2021
10	UPDATED DRAWING	AJUS	16.08.2021
09	UPDATED DRAWING	AJUS	30.05.2021
08	UPDATED DRAWING	AJUS	17.02.2021
07	AMENDED DRAWING	AJUS	09.07.2021
06	AMENDED DRAWING	AJUS	21.05.2021
05	AMENDED DRAWING	AJUS	20.05.2021
04	UPDATED DRAWING	AJUS	12.05.2021
03	UPDATED DRAWING	AJUS	19.04.2021
02	UPDATED DRAWING	AJUS	23.03.2021
01	FOR APPROVAL	AJUS	17.03.2021

**PortCity**  
AIR CONDITIONING  
PORT CITY AIR CONDITIONING PTY LTD  
(Sunshine Coast Branch)  
A : 4/74 Bulcock Street, Caloundra, Q 4551  
P : 07 54 98 0747 E : client@portcityairconditioning.com.au  
F : 07 4972 1791 W : www.portcitygroup.com.au

PROJECT NAME  
The Patterson by Mosaic  
3-15 Archer St, Toowong, Brisbane


DRAWING NAME  
MECHANICAL SERVICES  
BASEMENT 2 FLOOR PLAN

DRAWN	ASA DRAFTING CO. LTD	DWG NO	AD
CHECK	JV	SCALE	1:50
APPROVE	M.B	DATE	17.03.2021

AS BUILT  
DRAWING M100 REVISION 16

©2023 The drawings herein are the property of PortCity Air Conditioning Pty Ltd. They are to be used only for the project and location specified. No other use or reproduction is permitted without the written consent of PortCity Air Conditioning Pty Ltd.





BASEMENT 1  
23  
CARPARKS  
SL 8600

17	AS BUILT	AJUS	17.03.2021
16	UPDATED RCP LAYOUT AND RELOCATED FCU UNITS	AJUS	09.07.2021
15	UPDATED BACKGROUND	AJUS	11.03.2021
14	FOR APPROVAL	AJUS	17.02.2021
13	UPDATED M/E MODEL	AJUS	14.10.2021
12	UPDATED MODEL AND LOCATION OF FAN	AJUS	02.10.2021
11	UPDATED DESIGN	AJUS	24.08.2021
10	UPDATED DRAWING	AJUS	10.08.2021
09	UPDATED DRAWING	AJUS	26.05.2021
08	UPDATED DRAWING	AJUS	17.02.2021
07	AMENDED DRAWING	AJUS	09.07.2021
06	AMENDED DRAWING	AJUS	27.05.2021
05	AMENDED DRAWING	AJUS	20.05.2021
04	UPDATED DRAWING	AJUS	12.05.2021
03	UPDATED DRAWING	AJUS	19.04.2021
02	UPDATED DRAWING	AJUS	22.03.2021
01	FOR APPROVAL	AJUS	17.03.2021
REV	DESCRIPTION	BY	DATE

**PortCity**  
AIR CONDITIONING  
PORT CITY AIR CONDITIONING PTY LTD  
(Sunshine Coast Branch)  
A : 4/74 Bulcock Street, Caloundra, Q 4551  
P : 07 54 96 0747 E : client@portcityairconditioning.com.au  
F : 07 4972 1791 W : www.portcitygroup.com.au

PROJECT NAME  
The Patterson by Mosaic  
3-15 Archer St, Toowong, Brisbane


DRAWING NAME  
MECHANICAL SERVICES  
BASEMENT 1 FLOOR PLAN

DRAWN	ASA DRAFTING CO. LTD	DWG NO	AD
CHECK	JV	SCALE	1:50
APPROVE	M.B	DATE	17.03.2021

AS BUILT	
DRAWING	REVISION
M101	17

© 2021 PortCity Air Conditioning Pty Ltd. All rights reserved. This drawing is to be used for the project of the client only. It is not to be used for any other purpose without the written consent of PortCity Air Conditioning Pty Ltd.





REV	DESCRIPTION	BY	DATE
17	AS BUILT	AJUS	17.03.2021
16	UPDATED RCP LAYOUT AND RELOCATED FCU UNITS	AJUS	09.07.2020
15	UPDATED BACKGROUND	AJUS	11.06.2020
14	FOR APPROVAL	AJUS	17.02.2020
13	UPDATED LINE MODEL	AJUS	14.10.2019
12	UPDATED MODEL AND LOCATION OF FAN	AJUS	02.10.2019
11	UPDATED DESIGNED	AJUS	24.08.2019
10	UPDATED DRAWING	AJUS	10.08.2019
09	UPDATED DRAWING	AJUS	26.05.2019
08	UPDATED DRAWING	AJUS	17.02.2019
07	AMENDED DRAWING	AJUS	09.07.2018
06	AMENDED DRAWING	AJUS	27.05.2018
05	AMENDED DRAWING	AJUS	20.05.2018
04	UPDATED DRAWING	AJUS	12.05.2018
03	UPDATED DRAWING	AJUS	19.04.2018
02	UPDATED DRAWING	AJUS	22.03.2018
01	FOR APPROVAL	AJUS	17.03.2018

**PortCity AIRCONDITIONING**  
 PORT CITY AIR CONDITIONING PTY LTD  
 (Sunshine Coast Branch)  
 A : 4/74 Bulcock Street, Caloundra, Q 4551  
 P : 07 54 98 0747 E : client@portcityairconditioning.com.au  
 F : 07 4972 1791 W : www.portcitygroup.com.au


PROJECT NAME  
 The Patterson by Mosaic  
 3-15 Archer St, Toowong, Brisbane

DRAWING NAME  
 MECHANICAL SERVICES  
 BASEMENT MEZZANINE FLOOR PLAN

DRAWN	ASA DRAFTING CO. LTD	DWG. NO.	AS BUILT
CHECK	J.V.	SCALE	1:50
APPROVE	M.B.	DATE	17.03.2021

DRAWING	M102	REVISION	17
---------	------	----------	----





NO	DESCRIPTION	DATE
1	AS BUILT	17.03.2021
2	AS BUILT	17.03.2021
3	AS BUILT	17.03.2021
4	AS BUILT	17.03.2021
5	AS BUILT	17.03.2021
6	AS BUILT	17.03.2021
7	AS BUILT	17.03.2021
8	AS BUILT	17.03.2021
9	AS BUILT	17.03.2021
10	AS BUILT	17.03.2021
11	AS BUILT	17.03.2021
12	AS BUILT	17.03.2021
13	AS BUILT	17.03.2021
14	AS BUILT	17.03.2021
15	AS BUILT	17.03.2021
16	AS BUILT	17.03.2021
17	AS BUILT	17.03.2021
18	AS BUILT	17.03.2021
19	AS BUILT	17.03.2021
20	AS BUILT	17.03.2021
21	AS BUILT	17.03.2021
22	AS BUILT	17.03.2021
23	AS BUILT	17.03.2021
24	AS BUILT	17.03.2021
25	AS BUILT	17.03.2021
26	AS BUILT	17.03.2021
27	AS BUILT	17.03.2021
28	AS BUILT	17.03.2021
29	AS BUILT	17.03.2021
30	AS BUILT	17.03.2021
31	AS BUILT	17.03.2021
32	AS BUILT	17.03.2021
33	AS BUILT	17.03.2021
34	AS BUILT	17.03.2021
35	AS BUILT	17.03.2021
36	AS BUILT	17.03.2021
37	AS BUILT	17.03.2021
38	AS BUILT	17.03.2021
39	AS BUILT	17.03.2021
40	AS BUILT	17.03.2021
41	AS BUILT	17.03.2021
42	AS BUILT	17.03.2021
43	AS BUILT	17.03.2021
44	AS BUILT	17.03.2021
45	AS BUILT	17.03.2021
46	AS BUILT	17.03.2021
47	AS BUILT	17.03.2021
48	AS BUILT	17.03.2021
49	AS BUILT	17.03.2021
50	AS BUILT	17.03.2021
51	AS BUILT	17.03.2021
52	AS BUILT	17.03.2021
53	AS BUILT	17.03.2021
54	AS BUILT	17.03.2021
55	AS BUILT	17.03.2021
56	AS BUILT	17.03.2021
57	AS BUILT	17.03.2021
58	AS BUILT	17.03.2021
59	AS BUILT	17.03.2021
60	AS BUILT	17.03.2021
61	AS BUILT	17.03.2021
62	AS BUILT	17.03.2021
63	AS BUILT	17.03.2021
64	AS BUILT	17.03.2021
65	AS BUILT	17.03.2021
66	AS BUILT	17.03.2021
67	AS BUILT	17.03.2021
68	AS BUILT	17.03.2021
69	AS BUILT	17.03.2021
70	AS BUILT	17.03.2021
71	AS BUILT	17.03.2021
72	AS BUILT	17.03.2021
73	AS BUILT	17.03.2021
74	AS BUILT	17.03.2021
75	AS BUILT	17.03.2021
76	AS BUILT	17.03.2021
77	AS BUILT	17.03.2021
78	AS BUILT	17.03.2021
79	AS BUILT	17.03.2021
80	AS BUILT	17.03.2021
81	AS BUILT	17.03.2021
82	AS BUILT	17.03.2021
83	AS BUILT	17.03.2021
84	AS BUILT	17.03.2021
85	AS BUILT	17.03.2021
86	AS BUILT	17.03.2021
87	AS BUILT	17.03.2021
88	AS BUILT	17.03.2021
89	AS BUILT	17.03.2021
90	AS BUILT	17.03.2021
91	AS BUILT	17.03.2021
92	AS BUILT	17.03.2021
93	AS BUILT	17.03.2021
94	AS BUILT	17.03.2021
95	AS BUILT	17.03.2021
96	AS BUILT	17.03.2021
97	AS BUILT	17.03.2021
98	AS BUILT	17.03.2021
99	AS BUILT	17.03.2021
100	AS BUILT	17.03.2021

**PORT CITY AIR CONDITIONING PTY LTD**  
(Sunshine Coast Branch)

A: 4/74 Bulcock Street, Caloundra, Q 4551  
P: 07 54 98 0747 E: [enquiries@portcityairconditioning.com.au](mailto:enquiries@portcityairconditioning.com.au)  
F: 07 4972 1791 W: [www.portcitygroup.com.au](http://www.portcitygroup.com.au)

PROJECT NAME  
The Patterson by Mosaic  
3-15 Archer St, Toowong, Brisbane


DRAWING NAME  
MECHANICAL SERVICES  
LEVEL 1 FLOOR PLAN

DRAWN	ASA DRAFTING CO. LTD	DWG. NO.	AS BUILT
CHECK	J.V.	SCALE	1:50
APPROVE	M.B.	DATE	17.03.2021

DRAWING	M103	REVISION	21
---------	------	----------	----

© 2021 PortCity Air Conditioning Pty Ltd. All rights reserved. This drawing is to be used for the construction of the project. It is not to be used for any other purpose without the written consent of PortCity Air Conditioning Pty Ltd.





REV	DESCRIPTION	BY	DATE
20	AS BUILT	AJUS	17.03.2021
19	UPDATED CHANGES OF DUCT ON LEVEL 2 & 3	AJUS	01.08.2020
18	UPDATED CHANGES OF DUCT ON LEVEL 2 & 3	AJUS	19.07.2020
17	UPDATED C/P LOCATIONS AND RELOCATED CU UNITS	AJUS	08.07.2020
16	UPDATED CHANGES OF DUCT ON LEVEL 2 & 3	AJUS	06.06.2020
15	UPDATED BACKGROUND	AJUS	11.05.2020
14	UPDATED DESIGN OF WELLNESS AND CU LOCATION	AJUS	27.02.2020
13	FIXED PIPE SIZES AND SLOPES	AJUS	03.12.2019
12	RE-ARRANGED CONDENSER UNITS	AJUS	18.11.2019
11	UPDATED LIFT MODEL	AJUS	14.10.2019
10	UPDATED MODEL AND LOCATION OF FAN	AJUS	01.10.2019
09	UPDATED DESIGN	AJUS	24.08.2019
08	UPDATED DRAWING	AJUS	30.07.2019
07	UPDATED DRAWING	AJUS	17.07.2019
06	ANALISED DRAWING	AJUS	27.06.2019
05	ANALISED DRAWING	AJUS	20.05.2019
04	UPDATED DRAWING	AJUS	12.05.2019
03	UPDATED DRAWING	AJUS	19.04.2019
02	UPDATED DRAWING	AJUS	22.03.2019
01	FOR APPROVAL	AJUS	17.03.2019

**PortCity AIRCONDITIONING**  
**PORT CITY AIR CONDITIONING PTY LTD**  
 (Sunshine Coast Branch)  
 A : 4/74 Bulcock Street, Caloundra, Q 4551  
 P : 07 54 98 0747 E : client@portcityairconditioning.com.au  
 F : 07 4972 1791 W : www.portcitygroup.com.au

PROJECT NAME  
**The Patterson by Mosaic**  
 3-15 Archer St, Toowong, Brisbane


DRAWING NAME  
**MECHANICAL SERVICES**  
**LEVEL 2 FLOOR PLAN**

DRAWN	ASA DRAFTING CO. LTD	DWG NO.	AO
CHECK	J.V	SCALE	1:50
APPROVE	M.B	DATE	17.03.2021

**AS BUILT**

DRAWING: **M104** REVISION: **20**





REV	DESCRIPTION	BY	DATE
24	AS BUILT		17.09.2021
23	UPDATED CHANGES OF DUCT ON LEVEL 2 & 3		01.06.2021
22	UPDATED CHANGES OF DUCT ON LEVEL 2 & 3		16.07.2021
21	UPDATED RCP LAYOUT AND RELOCATED CU UNITS		08.07.2021
20	UPDATED CHANGES OF DUCT ON LEVEL 2 & 3		06.06.2021
19	UPDATED BALANCE LOADS		11.05.2021
18	UPDATED BALANCE LOADS		11.05.2021
17	CHANGED THE QUANTITY OF PIPE RISERS		22.03.2021
16	UPDATED DESIGN OF WELLNET AND CU LOCATION		27.10.2021
15	FOR AIRFLOW		17.02.2021
14	FIXED PIPE ROUTE AND DROPPER		03.12.2021
13	RE-ARRANGED CONDENSER UNITS		18.11.2021
12	UPDATED UNIT MODEL		14.10.2021
11	UPDATED MODEL AND LOCATION OF FAN		11.09.2021
10	UPDATED COILS SEE		12.08.2021
09	UPDATED DESIGNED		24.08.2021
08	UPDATED DRAWING		30.07.2021
07	UPDATED DRAWING		17.07.2021
06	AMENDED DRAWING		21.05.2021
05	AMENDED DRAWING		20.05.2021
04	UPDATED DRAWING		12.05.2021
03	UPDATED DRAWING		05.04.2021
02	AMENDED DRAWING		13.04.2021

**PortCity Air Conditioning**  
**PORT CITY AIR CONDITIONING PTY LTD**  
 (Sunshine Coast Branch)  
 A : 4/74 Bullock Street, Caloundra, Q 4551  
 P : 07 54 36 0747 E : client@portcityairconditioning.com.au  
 F : 07 4972 1791 W : www.portcitygroup.com.au

PROJECT NAME  
 The Patterson by Mosaic  
 3-15 Archer St, Toowong, Brisbane

DRAWING NAME  
**MECHANICAL SERVICES**  
**LEVEL 3 FLOOR PLAN**

DRAWN	ASA DRAFTING CO. LTD	DWG NO.	AD
CHECK	J.V	SCALE	1:50
APPROVE	M.B	DATE	17.09.2021

AS BUILT

DRAWING	M105	REVISION	24
---------	------	----------	----

This drawing is the property of PortCity Air Conditioning Pty Ltd. It is to be used only for the project and location specified. No part of this drawing is to be copied, reproduced or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or by any information storage and retrieval system, without the prior written permission of PortCity Air Conditioning Pty Ltd.



SEE DWG BELOW OF PAGE FOR CONTINUATION

SEE DWG ABOVE OF PAGE FOR CONTINUATION

- NOTES:**
1. LAUNDRY EXHAUST FANS TO BE CONTROLLED VIA SEPARATE WALL SWITCH LOCATED ADJACENT TO LIGHT SWITCH ROOM CIV GREEN IN REAR CIV LIVES.
  2. KITCHEN EXHAUST FANS TO OPERATE IN CONJUNCTION WITH 3RD PARTY DOMESTIC RANGE HOOD VIA CURRENT SENSOR RELAY JUNCTION BOX IN CEILING ADJACENT TO BOOSTER FAN.
  3. GENERAL PROFILE AND BATHROOM VENTILATION FANS TO OPERATE VIA ELECTRICAL INTERLOCK WITH ROOM CEILING LIGHTING.
  4. LAUNDRY EXHAUST GRILLE TO BE THUMB WHEEL HINGED CORE TYPE WITH 10MM SLIDE FILTER BEHIND.
  5. ALL JOINTS TO BE SEALED TO MANUFACTURERS RECOMMENDATIONS.
  6. ALL EXTERNAL REG-GATE GRILLES TO HAVE HERMATIC PROOF WASH SPRING.
  7. ALL LAUNDRY, ENLITE/BATHROOM & KITCHEN EXHAUST SYSTEMS TO BE FITTED WITH METAL NON-RETURN DAMPER FOR COMPLIANCE WITH BC A2016 SECTION 3.3.

REV	DESCRIPTION	BY	DATE
16	AS BUILT	AJUS	17.03.2023
15	UPDATED RCP LAYOUT AND RELOCATED FCU UNITS	AJUS	09.07.2022
14	UPDATED BACKGROUND	AJUS	17.05.2022
13	CHANGED THE QUANTITY OF PIPES	AJUS	14.10.2021
12	UPDATED DESIGN OF BELINEET AND CU LOCATION	AJUS	27.10.2021
11	FOR APPROVAL	AJUS	17.01.2022
10	RE-ARRANGED CONDENSER UNITS	AJUS	26.06.2021
09	UPDATED UNIT MODEL	AJUS	14.10.2021
08	UPDATED MODEL AND LOCATION OF FAN	AJUS	02.10.2021
07	UPDATED RCP MODEL	AJUS	12.09.2021
06	UPDATED UNIT MODEL	AJUS	26.06.2021
05	MANAGED DRAWING	AJUS	20.05.2021
04	UPDATED DRAWING	AJUS	12.05.2021
03	UPDATED DRAWING	AJUS	19.04.2021
02	MANAGED DRAWING	AJUS	13.04.2021
01	FOR APPROVAL	AJUS	09.04.2021

**PortCity AIRCONDITIONING**  
**PORT CITY AIR CONDITIONING PTY LTD**  
 (Sunshine Coast Branch)  
 A : 4/74 Bullock Street, Caloundra, Q 4551  
 P : 07 54 58 0747 E : client@portcityairconditioning.com.au  
 F : 07 4972 1791 W : www.portcitygroup.com.au

PROJECT NAME  
**The Patterson by Mosaic**  
 3-15 Archer St, Toowong, Brisbane

DRAWING NAME  
**MECHANICAL SERVICES**  
**LEVEL 4 PODIUM TOP**  
**FLOOR PLAN**

DRAWN	ASA DRAFTING CO. LTD	DWG SIZE	A0
CHECK	J.V	SCALE	1:50
APPROVE	M.B	DATE	09/04/2021

AS BUILT  
 DRAWING M106 REVISION 16

This drawing is the property of PortCity Air Conditioning Pty Ltd. It is to be used only for the project and location specified. It is not to be reproduced, copied, or used for any other purpose without the written consent of PortCity Air Conditioning Pty Ltd.



SEE DWG BELOW OF PAGE FOR CONTINUATION

SEE DWG ABOVE OF PAGE FOR CONTINUATION

NOTE  
 THE REFRIGERANT PIPE OF LEVEL 8 DROPS FROM ROOF ABOVE TO CONNECT TO FCU UNITS OF APARTMENTS FROM CONDENSER UNITS LOCATED ON PLANT DECK WITHIN GRID LINE 4 AND GRID LINE B

NOTES:  
 1) LAUNDRY EXHAUST FANS TO BE CONTROLLED VIA SEPARATE WALL SWITCH LOCATED ADJACENT TO LIGHT SWITCH ROOM CIV GREEN IN REAR CIV LIVES.  
 2) KITCHEN EXHAUST FANS TO OPERATE IN CONJUNCTION WITH 3RD PARTY DOMESTIC RANGE HOOD VIA CURRENT SENSOR RELAY JUNCTION BOX IN CEILING ADJACENT TO BOOSTER FAN.  
 3) GENERAL PROBE AND BATHROOM VENTILATION FANS TO OPERATE VIA ELECTRICAL NETWORK WITH ROOM CEILING LIGHTING.  
 4) LAUNDRY EXHAUST GRILLE TO BE THUMB WHEEL HINGED CORE TYPE WITH 10MM SLIDE FILTER BEHIND.  
 5) ALL UNITS TO BE SEALED TO MANUFACTURERS RECOMMENDATIONS.  
 6) ALL EXTERNAL SEG GATE GRILLES TO HAVE HERMETIC PROOF WASH BEHIND.  
 7) ALL LAUNDRY, ENSUITE/BATHROOM & KITCHEN EXHAUST SYSTEMS TO BE FITTED WITH METAL NON-RETURN DAMPER FOR COMPLIANCE WITH BC2016 SECTION 3.3.

REV	DESCRIPTION	BY	DATE
16	AS BUILT		AUGUS 17.03.2021
15	UPDATED RCP LAYOUT AND RELOCATED FCU UNITS		AUGUS 09.07.2020
14	UPDATED BACKGROUND		AUGUS 11.05.2020
13	CHANGED THE QUANTITY OF PIPE RISERS		AUGUS 20.03.2020
12	UPDATED DESIGN OF WELLNET AND CU LOCATION		AUGUS 27.10.2019
11	FOR APPROVAL		AUGUS 17.01.2019
10	RE-ARRANGED CONDENSER UNITS		AUGUS 14.10.2017
09	UPDATED UNIT MODEL		AUGUS 14.10.2017
08	UPDATED MODEL AND LOCATION OF FAN		AUGUS 02.10.2017
07	UPDATED FAN MODEL		AUGUS 12.09.2017
06	UPDATED UNIT MODEL		AUGUS 26.06.2017
05	MANAGED DRAWING		AUGUS 20.03.2017
04	UPDATED DRAWING		AUGUS 12.05.2017
03	UPDATED DRAWING		AUGUS 19.04.2017
02	MANAGED DRAWING		AUGUS 13.04.2017
01	FOR APPROVAL		AUGUS 09.04.2017


**PortCity**  
**AIR CONDITIONING**  
 PORT CITY AIR CONDITIONING PTY LTD  
 (Sunshine Coast Branch)  
 A : 4/74 Bullock Street, Caloundra, Q 4551  
 P : 07 54 58 0747 E : client@portcityairconditioning.com.au  
 F : 07 4972 1791 W : www.portcitygroup.com.au

PROJECT NAME  
 The Patterson by Mosaic  
 3-15 Archer St, Toowong, Brisbane

DRAWING NAME  
 MECHANICAL SERVICES  
 LEVEL 5-9 TYPICAL  
 FLOOR PLAN

DRAWN	ASA DRAFTING CO. LTD	DWG SIZE	A0
CHECK	J.V	SCALE	1:50
APPROVE	M.B	DATE	09/04/2021

AS BUILT  
 M107  
 16





SEE DWG BELOW OF PAGE FOR CONTINUATION

SEE DWG ABOVE OF PAGE FOR CONTINUATION

- NOTES:**
1. LAUNDRY EXHAUST FANS TO BE CONTROLLED VIA SEPARATE WALL ON/OFF SWITCHED LOCATED ADJACENT TO LIGHT SWITCH ROOM CIVIL GREEN IN REAR LIVES.
  2. KITCHEN EXHAUST FANS TO OPERATE IN CONJUNCTION WITH 3RD PARTY DOMESTIC RANGE HOOD VIA CURRENT SENSOR RELAY JUNCTION BOX IN CEILING ADJACENT TO BOOSTER FAN.
  3. GENERAL PROFILE AND BATHROOM VENTILATION FANS TO OPERATE VIA ELECTRICAL INTERLOCK WITH ROOM CEILING LIGHTING.
  4. LAUNDRY EXHAUST GRILLE TO BE THUMB WHEEL HINGED CORE TYPE WITH 10MM SLIDE FILTER BEHIND.
  5. ALL JOINTS TO BE SEALED TO MANUFACTURERS RECOMMENDATIONS.
  6. ALL EXTERNAL ESC GRATE GRILLES TO HAVE HERMATIC PROOF WASH BEHIND.
  7. ALL LAUNDRY, ENLUBATHROOM & KITCHEN EXHAUST SYSTEMS TO BE FITTED WITH METAL NON-RETURN DAMPER FOR COMPLIANCE WITH BC2016 SECTION 3.5.

REV	DESCRIPTION	BY	DATE
16	AS BUILT		17.03.2023
15	UPDATED RCP LAYOUT AND RELOCATED FCU UNITS		09.07.2022
14	UPDATED BACKGROUND		11.05.2022
13	UPDATED POSITION OF WELLNET AND CU LOCATION		27.10.2021
12	FOR APPROVAL		17.01.2022
11	RE-ARRANGED CONDENSER UNITS		18.11.2021
10	UPDATED RCP MODEL		14.10.2021
09	UPDATED MODEL AND LOCATION OF FAN		02.10.2021
08	UPDATED MODEL OF FAN E4-4		17.09.2021
07	UPDATED RCP MODEL		12.09.2021
06	UPDATED RCP MODEL		26.06.2021
05	AMENDED DRAWING		20.05.2021
04	UPDATED DRAWING		12.05.2021
03	UPDATED DRAWING		19.04.2021
02	AMENDED DRAWING		13.04.2021
01	FOR APPROVAL		09.04.2021


**PortCity AIR CONDITIONING**  
**PORT CITY AIR CONDITIONING PTY LTD**  
 (Sunshine Coast Branch)  
 A : 4/74 Bulcock Street, Caloundra, Q 4551  
 P : 07 5436 0747 E : client@portcityairconditioning.com.au  
 F : 07 4972 1791 W : www.portcitygroup.com.au

PROJECT NAME  
**The Patterson by Mosaic**  
 3-15 Archer St, Toowong, Brisbane


DRAWING NAME  
**MECHANICAL SERVICES**  
**LEVEL 10 FLOOR PLAN**

DRAWN	CHECK	APPROVE	DWG SIZE	SCALE	DATE
ASA DRAFTING CO. LTD	J.V	M.B	A0	1:50	09/04/2021

**AS BUILT**  
 M108  
 16







SEE DWG BELOW OF PAGE FOR CONTINUATION

SEE DWG ABOVE OF PAGE FOR CONTINUATION

**NOTES:**

- 1) LAUNDRY EXHAUST FANS TO BE CONTROLLED VIA SEPARATE WALL SWITCH LOCATED ADJACENT TO LIGHT SWITCH ROOM CIV GREEN IN KITCHEN LIVES.
- 2) KITCHEN EXHAUST FANS TO OPERATE IN CONJUNCTION WITH 3RD PARTY DOMESTIC RANGE HOOD VIA CURRENT SENSOR RELAY JUNCTION BOX IN CEILING ADJACENT TO BOOSTER FAN.
- 3) GENERAL PROFILE AND BATHROOM VENTILATION FANS TO OPERATE VIA ELECTRICAL INTERLOCK WITH ROOM CEILING LIGHTING.
- 4) LAUNDRY EXHAUST GRILLE TO BE THUMB WHEEL HINGED CORE TYPE WITH 10MM SLIDE FILTER BEHIND.
- 5) ALL DUCTS TO BE SEALED TO MANUFACTURERS RECOMMENDATIONS.
- 6) ALL EXTERNAL SEC GRATE GRILLES TO HAVE HERMETIC PROOF WASH BEHIND.
- 7) ALL LAUNDRY, ENSUITE/BATHROOM & KITCHEN EXHAUST SYSTEMS TO BE FITTED WITH METAL NON-RETURN DAMPER FOR COMPLIANCE WITH BC2016 SECTION 3.5.

REV	DESCRIPTION	BY	DATE
15	AS BUILT	AJUS	17.03.2023
14	UPDATED CP LAYOUT AND RELOCATED FCU UNITS	AJUS	09.07.2022
13	UPDATED BACKGROUND	AJUS	11.05.2022
12	UPDATED DESIGN OF WALLNET AND CU LOCATION	AJUS	27.10.2021
11	FOR APPROVAL	AJUS	17.01.2022
10	RE-ARRANGED CONDENSER UNITS	AJUS	12.09.2021
09	UPDATED UNIT MODEL	AJUS	14.10.2021
08	UPDATED MODEL AND LOCATION OF FAN	AJUS	02.10.2021
07	UPDATED FAN MODEL	AJUS	12.09.2021
06	UPDATED UNIT MODEL	AJUS	26.06.2021
05	AMENDED DRAWING	AJUS	20.05.2021
04	UPDATED DRAWING	AJUS	12.05.2021
03	UPDATED DRAWING	AJUS	19.04.2021
02	AMENDED DRAWING	AJUS	13.04.2021
01	FOR APPROVAL	AJUS	09.04.2021

**PortCity AIRCONDITIONING**  
 PORT CITY AIR CONDITIONING PTY LTD  
 (Sunshine Coast Branch)  
 A : 4/74 Bulcock Street, Caloundra, Q 4551  
 P : 07 54 58 0747 E : client@portcityairconditioning.com.au  
 F : 07 4972 1791 W : www.portcitygroup.com.au

PROJECT NAME  
 The Patterson by Mosaic  
 3-15 Archer St, Toowong, Brisbane


DRAWING NAME  
 MECHANICAL SERVICES  
 LEVEL 11 FLOOR PLAN

DRAWN	ASA DRAFTING CO. LTD	DWG SIZE	A0
CHECK	J.V	SCALE	1:50
APPROVE	M.B	DATE	09/04/2021

DRAWING	AS BUILT	REVISION	15
	M109		15

This drawing is the property of PortCity Air Conditioning Pty Ltd. It is to be used only for the project and location specified. It is not to be reproduced, copied, or distributed without the written consent of PortCity Air Conditioning Pty Ltd. The drawing is to be used as a guide. The client is responsible for the accuracy of the information provided. The drawing is to be used as a guide. The client is responsible for the accuracy of the information provided.





SEE DWG BELOW OF PAGE FOR CONTINUATION

SEE DWG ABOVE OF PAGE FOR CONTINUATION

**NOTES:**

- 1) LAUNDRY EXHAUST FANS TO BE CONTROLLED VIA SEPARATE WALL ON/OFF SWITCHED LOCATED ADJACENT TO LIGHT SWITCH ROOM CIV GREEN IN REAR LIVES.
- 2) KITCHEN EXHAUST FANS TO OPERATE IN CONJUNCTION WITH 3RD PARTY DOMESTIC RANGE HOOD VIA CURRENT SENSOR RELAY JUNCTION BOX IN CEILING ADJACENT TO BOOSTER FAN.
- 3) GENERAL ENLITE AND BATHROOM VENTILATION FANS TO OPERATE VIA ELECTRICAL INTERLOCK WITH ROOM CEILING LIGHTING.
- 4) LAUNDRY EXHAUST GRILLE TO BE THUMB WHEEL HINGED CORE TYPE WITH 10MM SLIDE FILTER BEHIND.
- 5) ALL JOINTS TO BE SEALED TO MANUFACTURERS RECOMMENDATION.
- 6) ALL EXTERNAL SEG GRATE GRILLES TO HAVE HERMETIC PROOF WASH BEHIND.
- 7) ALL LAUNDRY, ENLITE/BATHROOM & KITCHEN EXHAUST SYSTEMS TO BE FITTED WITH METAL NON-RETURN DAMPER FOR COMPLIANCE WITH BC42016 SECTION 3.5.

REV	DESCRIPTION	BY	DATE
16	AS BUILT		17.03.2021
15	UPDATED RCP LAYOUT AND RELOCATED FCU UNITS	AJUS	09.07.2020
14	UPDATED BACKGROUND	AJUS	11.05.2020
13	UPDATED DESIGN OF WELLNET AND CU LOCATION	AJUS	27.10.2020
12	FOR APPROVAL		17.01.2021
11	RE-ARRANGED CONDENSER UNITS	AJUS	18.11.2020
10	UPDATED UNIT MODEL	AJUS	14.04.2021
09	UPDATED MODEL AND LOCATION OF FAN	AJUS	02.10.2020
08	UPDATED MODEL OF FAN E4-4	AJUS	17.09.2020
07	UPDATED FAN MODEL	AJUS	12.09.2020
06	UPDATED UNIT MODEL	AJUS	26.06.2020
05	UNREVISED DRAWING	AJUS	20.05.2020
04	UPDATED DRAWING	AJUS	12.05.2020
03	UPDATED DRAWING	AJUS	19.04.2020
02	UNREVISED DRAWING	AJUS	13.04.2020
01	FOR APPROVAL		09.04.2020

**PortCity AIR CONDITIONING**

**PORT CITY AIR CONDITIONING PTY LTD**  
(Sunshine Coast Branch)

A : 4/74 Bulcock Street, Caloundra, Q 4551  
P : 07 54 58 0747 E : client@portcityairconditioning.com.au  
F : 07 4972 1791 W : www.portcitygroup.com.au

PROJECT NAME  
**The Patterson by Mosaic**  
3-15 Archer St, Toowong, Brisbane


DRAWING NAME  
**MECHANICAL SERVICES**  
LEVEL 12 FLOOR PLAN

DRAWN	ASA DRAFTING CO. LTD	DWG SIZE	A0
CHECK	JV	SCALE	1:50
APPROVE	M.B	DATE	09/04/2021

AS BUILT

DRAWING M110 REVISION 16





SEE DWG BELOW OF PAGE FOR CONTINUATION

SEE DWG ABOVE OF PAGE FOR CONTINUATION

**NOTES:**


- 1) LAUNDRY EXHAUST FANS TO BE CONTROLLED VIA SEPARATE WALL ON/OFF SWITCHED LOCATED ADJACENT TO LIGHT SWITCH ROOM CIV GREEN IN REAR LIVES.
- 2) KITCHEN EXHAUST FANS TO OPERATE IN CONJUNCTION WITH 3RD PARTY DOMESTIC RANGE HOOD VIA CURRENT SENSOR RELAY JUNCTION BOX IN CEILING ADJACENT TO BOOSTER FAN.
- 3) GENERAL ENSUITE AND BATHROOM VENTILATION FANS TO OPERATE VIA ELECTRICAL INTERLOCK WITH ROOM CEILING LIGHTING.
- 4) LAUNDRY EXHAUST GRILLE TO BE THUMB WHEEL HINGED CORE TYPE WITH 10MM SLIDE FILTER BEHIND.
- 5) ALL JOINTS TO BE SEALED TO MANUFACTURER'S RECOMMENDATIONS.
- 6) ALL EXTERNAL SEC GRATE GRILLES TO HAVE HERMETIC PROOF WASH BEHIND.
- 7) ALL LAUNDRY, ENSUITE/BATHROOM & KITCHEN EXHAUST SYSTEMS TO BE FITTED WITH METAL NON-RETURN DAMPER FOR COMPLIANCE WITH BC2016 SECTION 3.5.

REV	DESCRIPTION	BY	DATE
15	UPDATED RCP LAYOUT AND RELOCATED FCU UNITS	AJUS	09.07.2021
14	UPDATED BACKGROUND	AJUS	11.05.2021
13	UPDATED DESIGN OF WELLNET AND CU LOCATION	AJUS	27.10.2021
12	FOR APPROVAL	AJUS	17.01.2021
11	RE-ARRANGED CONDENSER UNITS	AJUS	18.11.2021
10	UPDATED UNIT MODEL	AJUS	14.10.2021
09	UPDATED MODEL AND LOCATION OF FAN	AJUS	02.10.2021
08	UPDATED MODEL OF FAN E4-4	AJUS	17.09.2021
07	UPDATED FAN MODEL	AJUS	12.09.2021
06	UPDATED UNIT MODEL	AJUS	26.06.2021
05	UNREVISED DRAWING	AJUS	20.05.2021
04	UPDATED DRAWING	AJUS	12.05.2021
03	UPDATED DRAWING	AJUS	19.04.2021
02	UNREVISED DRAWING	AJUS	13.04.2021
01	FOR APPROVAL	AJUS	09.04.2021

<b>PORT CITY AIR CONDITIONING PTY LTD</b> (Sunshine Coast Branch) A : 4/74 Bulcock Street, Caloundra, Q 4551 P : 07 54 56 0747 E : client@portcityairconditioning.com.au F : 07 4972 1791 W : www.portcitygroup.com.au	
PROJECT NAME	The Patterson by Mosaic
3-15 Archer St, Toowong, Brisbane	
DRAWING NAME	MECHANICAL SERVICES LEVEL 13 FLOOR PLAN
DRAWN	ASA DRAFTING CO. LTD DWG SIZE A0
CHECK	J.V SCALE 1:50
APPROVE	M.B DATE 09/04/2021
DRAWING	M111
REVISION	15





SEE DWG BELOW OF PAGE FOR CONTINUATION

SEE DWG ABOVE OF PAGE FOR CONTINUATION

- NOTES:**
- 1) LAUNDRY EXHAUST FANS TO BE CONTROLLED VIA SEPARATE WALL ON/OFF SWITCHED LOCATED ADJACENT TO LIGHT SWITCH ROOM CIV GREEN IN REAR LIVES.
  - 2) KITCHEN EXHAUST FANS TO OPERATE IN CONJUNCTION WITH 3RD PARTY DOMESTIC RANGE HOOD VIA CURRENT SENSOR RELAY JUNCTION BOX IN CEILING ADJACENT TO BOOSTER FAN.
  - 3) GENERAL ENSUITE AND BATHROOM VENTILATION FANS TO OPERATE VIA ELECTRICAL INTERLOCK WITH ROOM CEILING LIGHTING.
  - 4) LAUNDRY EXHAUST GRILLE TO BE 30MM WHEEL HINGED CORE TYPE WITH 10MM SLIDE FILTER BEHIND.
  - 5) ALL AIRWAYS TO BE SEALED TO MANUFACTURER'S RECOMMENDATIONS.
  - 6) ALL EXTERNAL SEC GRATE GRILLES TO HAVE HERMETIC PROOF WASH BEHIND.
  - 7) ALL LAUNDRY, ENSUITE/BATHROOM & KITCHEN EXHAUST SYSTEMS TO BE FITTED WITH METAL NON-RETURN DAMPER FOR COMPLIANCE WITH BC2016 SECTION 3.5.

REV	DESCRIPTION	BY	DATE
16	AS BUILT		17.03.2023
15	UPDATED RCP LAYOUT AND RELOCATED FCU UNITS		AUGUS 09.07.2022
14	UPDATED BALCONY/STAIRWELL AND CEILING CORE		11.05.2022
13	UPDATED DESIGN OF WELLNET AND CEILING CORE		AUGUS 27.10.2021
12	FOR APPROVAL		AUGUS 17.01.2022
11	RE-ARRANGED CONDENSER UNITS		AUGUS 18.11.2021
10	UPDATED UNIT MODEL		AUGUS 14.10.2021
09	UPDATED MODEL AND LOCATION OF FAN		AUGUS 02.10.2021
08	UPDATED MODEL OF FAN EF-4		AUGUS 17.09.2021
07	UPDATED FAN MODEL		AUGUS 12.09.2021
06	UPDATED FAN MODEL		AUGUS 26.06.2021
05	AMENDED DRAWING		AUGUS 20.05.2021
04	UPDATED DRAWING		AUGUS 12.05.2021
03	UPDATED DRAWING		AUGUS 19.04.2021
02	AMENDED DRAWING		AUGUS 13.04.2021
01	FOR APPROVAL		AUGUS 09.04.2021

**PortCity AIR CONDITIONING**  
**PORT CITY AIR CONDITIONING PTY LTD**  
 (Sunshine Coast Branch)  
 A : 4/74 Bulcock Street, Caloundra, Q 4551  
 P : 07 54 56 0747 E : client@portcityairconditioning.com.au  
 F : 07 4972 1791 W : www.portcitygroup.com.au

PROJECT NAME  
**The Patterson by Mosaic**  
 3-15 Archer St, Toowong, Brisbane


DRAWING NAME  
**MECHANICAL SERVICES**  
**LEVEL 14**  
**FLOOR PLAN**

DRAWN	ASA DRAFTING CO. LTD	DWG SIZE	A0
CHECK	J.V	SCALE	1:50
APPROVE	M.B	DATE	09/04/2021

AS BUILT

DRAWING M112 REVISION 16





SEE DWG BELOW OF PAGE FOR CONTINUATION

SEE DWG ABOVE OF PAGE FOR CONTINUATION

- NOTES:**
- 1) LAUNDRY EXHAUST FANS TO BE CONTROLLED VIA SEPARATE WALL ON/OFF SWITCHED LOCATED ADJACENT TO LIGHT SWITCH ROOM CIV GREEN IN INDICATED LIVES.
  - 2) KITCHEN EXHAUST FANS TO OPERATE IN CONJUNCTION WITH 3RD PARTY DOMESTIC RANGE HOOD VIA CURRENT SENSOR RELAY JUNCTION BOX IN CEILING ADJACENT TO BOOSTER FAN.
  - 3) GENERAL ENROUTE AND BATHROOM VENTILATION FANS TO OPERATE VIA ELECTRICAL INTERLOCK WITH ROOM CEILING LIGHTING.
  - 4) LAUNDRY EXHAUST GRILLE TO BE THUMB WHEEL HINGED CORE TYPE WITH 10MM SLIDE FILTER BEHIND.
  - 5) ALL AIRWAYS TO BE SEALED TO MANUFACTURERS RECOMMENDATIONS.
  - 6) ALL EXTERNAL SEC GRATE GRILLES TO HAVE HERMETIC PROOF WASH BEHIND.
  - 7) ALL LAUNDRY, ENROUTE BATHROOM & KITCHEN EXHAUST SYSTEMS TO BE FITTED WITH METAL NON-RETURN DAMPER FOR COMPLIANCE WITH BC42016 SECTION 3.3.5.

REV	DESCRIPTION	BY	DATE
16	AS BUILT		17.03.2021
15	UPDATED RCP LAYOUT AND RELOCATED FCU UNITS		09.07.2021
14	UPDATED BACKGROUND		11.05.2021
13	UPDATED POSITION OF WELLNET AND CU LOCATION		27.10.2021
12	FOR APPROVAL		17.01.2021
11	RE-ARRANGED CONDENSER UNITS		18.11.2021
10	UPDATED RCP MODEL		14.10.2021
09	UPDATED MODEL AND LOCATION OF FAN		02.10.2021
08	UPDATED MODEL OF FAN E4-4		17.09.2021
07	UPDATED RCP MODEL		12.09.2021
06	UPDATED RCP MODEL		26.08.2021
05	AMENDED DRAWING		20.05.2021
04	UPDATED DRAWING		12.05.2021
03	UPDATED DRAWING		19.04.2021
02	AMENDED DRAWING		13.04.2021
01	FOR APPROVAL		09.04.2021

**PortCity AIR CONDITIONING**  
**PORT CITY AIR CONDITIONING PTY LTD**  
 (Sunshine Coast Branch)  
 A : 4/74 Bulcock Street, Caloundra, Q 4551  
 P : 07 54 56 0747 E : client@portcityairconditioning.com.au  
 F : 07 4972 1791 W : www.portcitygroup.com.au

PROJECT NAME  
**The Patterson by Mosaic**  
 3-15 Archer St, Toowong, Brisbane


DRAWING NAME  
**MECHANICAL SERVICES**  
**LEVEL 15**  
**FLOOR PLAN**

DRAWN	ASA DRAFTING CO. LTD	DWG SIZE	A0
CHECK	J.V	SCALE	1:50
APPROVE	M.B	DATE	09/04/2021

DRAWING	<b>AS BUILT</b>	REVISION	<b>16</b>
M113			

This drawing is the property of PortCity Air Conditioning Pty Ltd. It is to be used only for the project and location specified. No part of this drawing is to be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or by any information storage and retrieval system, without the prior written permission of PortCity Air Conditioning Pty Ltd.





SEE DWG BELOW OF PAGE FOR CONTINUATION

SEE DWG ABOVE OF PAGE FOR CONTINUATION

REV	DESCRIPTION	BY	DATE
11	AS BUILT		17.03.2021
10	UPDATED BACKSOUND	AJUS	17.03.2021
09	UPDATED DESIGN OF MOUNTING AND CU LOCATION	AJUS	27.10.2020
08	FOR APPROVAL	AJUS	17.01.2020
07	RE-ARRANGED CONDENSER UNITS	AJUS	18.11.2020
06	UPDATED UNIT MODEL	AJUS	14.10.2020
05	UPDATED MODEL AND LOCATION OF FAN	AJUS	03.10.2020
04	ADVANCED DRAWING	AJUS	20.05.2021
03	UPDATED DRAWING	AJUS	12.05.2021
02	UPDATED DRAWING	AJUS	16.04.2021
01	FOR APPROVAL	AJUS	13.04.2021

**PortCity AIRCONDITIONING**  
 PORT CITY AIR CONDITIONING PTY LTD  
 (Sunshine Coast Branch)  
 A : 4/74 Bulcock Street, Caloundra, Q 4551  
 P : 07 54 98 0747 E : claud@portcityairconditioning.com.au  
 F : 07 4972 1791 W : www.portcitygroup.com.au

PROJECT NAME  
 The Patterson by Mosaic  
 3-15 Archer St, Toowong, Brisbane

DRAWING NAME  
 MECHANICAL SERVICES  
 ROOF TERRACE PLAN


DRAWN	ASA DRAFTING CO. LTD	DWG NO.	AD
CHECK	J.V	SCALE	1:50
APPROVE	M.B	DATE	09/04/2021

**AS BUILT**  
 DRAWING M114 REVISION 11









REV	DESCRIPTION	BY	DATE
05	AS BUILT	AJUS	17.03.2021
04	UPDATED MODEL AND LOCATION OF FAN	AJUS	02.10.2021
03	UPDATED DRAWING	AJUS	26.07.2021
02	UPDATED DRAWING	AJUS	17.02.2021
01	FOR APPROVAL	AJUS	09.02.2021

**PortCity AIRCONDITIONING**  
 PORT CITY AIR CONDITIONING PTY LTD  
 (Sunshine Coast Branch)  
 A : 4/74 Bulcock Street, Caloundra, Q 4551  
 P : 07 54 38 0747 E : client@portcityairconditioning.com.au  
 F : 07 4972 1791 W : www.portcitygroup.com.au

PROJECT NAME  
 The Patterson by Mosaic  
 3-15 Archer St, Toowong, Brisbane


DRAWING NAME  
 MECHANICAL SERVICES  
 SECTION 4 & 5

DRAWN	ASA DRAFTING CO. LTD	DWG SIZE	A0
CHECK	LV	SCALE	1:50
APPROVE	MLB	DATE	17.03.2021

DRAWING	AS BUILT	REVISION	05
---------	----------	----------	----

© The drawing shall remain the property of PortCity Pty Ltd. It shall not be reproduced or distributed in any form without the express written permission of PortCity Pty Ltd. This drawing is to be used for the project only and is not to be used for any other purpose.





SECTION 6a  
SCALE 1:50

SECTION 6b  
SCALE 1:50

SECTION 6c  
SCALE 1:50

REV	DESCRIPTION	BY	DATE
07	AS BUILT	AJUS	17.03.2021
06	UPDATED CHANGES OF OA DUCT ON LEVEL 2 & 3	AJUS	07.08.2020
05	UPDATED CHANGES OF OA DUCT ON LEVEL 2 & 3	AJUS	18.03.2020
04	UPDATED BACKGROUND	AJUS	11.08.2020
03	UPDATED MODE AND LOCATION OF FAN	AJUS	02.10.2020
02	UPDATED DIMENSIONS	AJUS	24.08.2020
01	FOR APPROVAL	AJUS	17.03.2021

**PortCity AIR CONDITIONING**  
 PORT CITY AIR CONDITIONING PTY LTD  
 (Sunshine Coast Branch)  
 A : 4/74 Bulcock Street, Caloundra, Q 4551  
 P : 07 54 98 0747 E : sales@portcityairconditioning.com.au  
 F : 07 4972 1791 W : www.portcitygroup.com.au

PROJECT NAME  
 The Patterson by Mosaic  
 3-15 Archer St, Toowong, Brisbane

DRAWING NAME  
 MECHANICAL SERVICES  
 SECTION 6a, 6b & 6c

DRAWN	ASA DRAFTING CO. LTD	DWG. NO.	AD
CHECK	JV	SCALE	1:50
APPROVE	M.B.	DATE	17.03.2021

DRAWING AS BUILT  
 MS3 REVISION 07

© The drawing and design are the property of PortCity Pty Ltd. It has been developed for a particular project and is not to be used for any other project without the written consent of PortCity Pty Ltd. The drawing is to be used for the project only and is not to be used for any other project.