

# Apartment monitor



**ICom 7R**  
TOUCHSCREEN APARTMENT STATION

## User instructions – ICom 7R video monitor

### MAIN MENU



1. From the main menu, you can:
  - Access your intercom call log by pressing **'Intercom'**.
  - Retrieve any messages you may have from concierge by pressing **'Messages'**.
  - Adjust the ring volume by pressing **'Settings'**.


### ANSWERING INCOMING CALLS



2. The visitor dials the apartment number on the code pad outside the building finishing with BELL' symbol.

3. The video monitor inside the called apartment sounds an electronic tone and colour vision of the calling entry is displayed. You can answer the call by pressing the **audio hands-free button** to the right of the screen, and two-way communication is established between the video monitor and the external entry station.


### GRANTING ACCESS



4. If you would like to grant the visitor access to the building, press the **video monitor button with the key symbol** to the right of the screen, and the door/gate will be released.


If lift control is present, the key button also enables the lift function.

### ENDING CALLS



5. You can end the conversation by pressing the **audio hands-free button**. The video links will automatically time out.

### VIEWING MISSED CALLS & MESSAGES



6. To access missed calls:
7. Press **'Intercom'** from the main menu, then
8. Press **'Records'** from the intercom menu and a call log appears.
9. You may click on any item to view an image capture from the call made.

Messages can then be deleted by pressing the **'X'** button on the bottom of the screen.


### CALLING CONCIERGE



10. To call concierge:
11. Press **'Intercom'** from the main menu, then
12. Press **'Calls'** from intercom menu,
13. Click on **'Concierge'** from the call menu.

Please note the **'Building'** button on the call menu is not activated.

### MESSAGES FROM CONCIERGE



14. To listen to messages from concierge:
15. Press **'Messages'** on the main menu and this will take you to a call log.
16. You may click on any item in the log to retrieve the audio message.

### CAMERAS



17. Please note the **'Cameras'** function on the intercom menu is not enabled.

### SETTINGS



18. Please note the **'Settings'** function on the main menu can only be used for ring volume adjustment. All other functions are password protected and not enabled.